Einhell CLASSIC

POWER X-CHANGE

Cordless Energy Station

TC-ES 18/150/1 Li-Solo

Item No.: 1091320

Ident No.: 21014

Bar Code: 4006825684209

The Einhell Cordless Power Station TC-ES 18/150/1 Li-Solo is the compact solution for mobile power – whether at home, on the go or when camping. Compatible with the Power X-Change battery system, it delivers up to 150W via the 230V socket. A USB-A port (10W) and a USB-C PD port (60W) enable fast charging of devices like smartphones and tablets. A carry handle and softgrip surface ensure easy transport and stable positioning. The dimmable LED light doubles as a table lamp or torch. A LED indicator displays the battery status, and a dustproof cover protects the ports. Battery and charger are sold separately.

Features & Benefits

- Member of the Power X-Change family, requires 1x 18 V battery
- Portable power station for charging small devices on the go
- Powers phone, laptop & more via PXC battery
- Ports: USB-A, USB-C-PD, 230 V socket
- Pure sine wave for smooth, interference-free operation
- Dimmable LED light at inverter head
- Practical LED battery status indicator
- Covers protect ports from dust
- Softgrip surfaces and ergonomic design
- Integrated hook for easy hanging
- Supplied without battery and charger (sold separately)

POWER X-CHANGE BATTERY NOT INCLUDED

POWER X-CHANGE BATTERY NOT INCLUDED

Technical Data

- No. of battery slots	1 Pieces

Logistic Data

- Product weight (kg)	0.56
- Gross weight (kg)	0.63
- Dimensions single packaging	143 x 93 x 191 mm
- Pieces per export carton	12 Pieces
- Gross weight of export carton	9.78 kg
- Dimensions export carton	445 x 335 x 225 mm
- Container quantity (20"/40"/40"HC)	9660 | 17676 | 23244

18 V | 150 W max. POWER | PURE SINE WAVE

Illustrations can contain accessories, which are not included in standard extent of delivery
Illustration similar (in design), production-wise modifications reserved
GS mark belongs to the product itself only, excluded accessory

Available as special accessories

PXC Battery Mounting Gadget
PXC-Battery Accessory
Item No.: 4514155
Bar Code: 4006825658774
Einhell Accessory

PXC+ 18V 5-8Ah MULTI
Battery
Item No.: 4511600
Bar Code: 4006825665055
Einhell Accessory

PXC+ 18V 4,0Ah
Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory

2,0 Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory

4-6 Ah Multi-Ah Power X-Change
Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210

18V 4Ah PXC Plus Twinpack
Battery
Item No.: 4511629
Bar Code: 4006825673685
Einhell Accessory

2x18V 4,0Ah PXC-Twinpack CB
B1
Battery
Item No.: 4511489
Bar Code: 4006825638578

Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory

Power X-Car Charger 3A
Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory

18V Battery Charger 3,0A - PXC
Charger
Item No.: 4514095
Bar Code: 4006825655292
Einhell Accessory

2x 4,0Ah & Twincharger Kit 1
PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory

18V 4,0Ah PXC Starter Kit C1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory

E-Case Tasche
System Carrying Case
Item No.: 4540036
Bar Code: 4006825677966
Einhell Accessory

E-Case M
System Carrying Case
Item No.: 4540021
Bar Code: 4006825667721
Einhell Accessory

5,2 Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory

3,0 Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory

PXC 18V 3,0Ah
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory

4,0 Ah Power X-Change
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory

2x 18V 5,2Ah PXC-Twinpack
Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory

18V 3Ah PXC Plus Twinpack
Battery
Item No.: 4511631
Bar Code: 4006825673692
Einhell Accessory

2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory

Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory

Power X-Boostcharger 8A
Charger
Item No.: 4512155
Bar Code: 4006825670554
Einhell Accessory

18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory

18V 4-6Ah & 6A Boostcharger
PXC-Starter-Kit
Item No.: 4512143
Bar Code: 4006825667653
Einhell Accessory

E-Case L with wheels
System Carrying Case
Item No.: 4540014
Bar Code: 4006825660562
Einhell Accessory

E-Case S-F
System Carrying Case
Item No.: 4540011
Bar Code: 4006825653991
Einhell Accessory

E-Case Werkzeugkiste
System Carrying Case
Item No.: 4540037
Bar Code: 4006825677973
Einhell Accessory

Illustrations can contain accessories, which are not included in standard extent of delivery
Illustration similar (in design), production-wise modifications reserved
GS mark belongs to the product itself only, excluded accessory