Cordless Lawn Trimmer

GE-CT 18/28 Li TC-Solo

Item No.: 3411212

Ident No.: 21024

Bar Code: 4006825654967

The Einhell GE-CT 18/28 Li TC-Solo cordless grass trimmer is a powerful Power X-Change tool that is comfortable to use thanks to an infinitely adjustable second handle, a Softgrip, and a telescopic long handle that is individually adaptable. Its motor head has 3 tilt settings and can be rotated through 180°, and there is a flower guard to protect plants and trees. Using the "Trimmer Cart" option with click system you can easily convert without tools to a user-friendly city lawn mower with 2-setting, axial cutting height adjustment (35 - 55 mm). Delivery includes a line spool (5m) with fully automatic line feed. This product comes without battery and without a charger. One 18 V battery is needed for operation.

Features & Benefits

- Member of the Power X-Change family, 1x18V battery necessary
- Infinitely adjustable second handle
- Telescopic long handle, infinitely adjustable
- Motor head rotatable 180° for vertical surfaces + lawn edges
- Motor head tiltable at 3 settings - versatile working
- Flower guard - protecting flowers and trees against damage
- Incl. line spool (5m) with fully-automatic line feed
- Expandable with "trimmer cart" - handy city-lawn mower
- Trimmer Cart: 2-step axial cutting height adjustment (35-55mm)
- Trimmer Cart: Click system for easy & toolless change
- Softgrip - perfect comfort
- Supplied without battery and charger (available separately)

Technical Data

- Revolutions of thread	8000 rpm
- Cutting width of thread	280 mm
- Thread length	500 cm
- Thread diameter	1.6 mm
- Readjustment of thread	Full automatic
- Cutting feature	Single line

Logistic Data

- Product weight	2.1 kg
- Gross weight single packaging	7 kg
- Dimensions single packaging	405 x 205 x 1045 mm
- Pieces per export carton	2 Pieces
- Gross weight export carton	15.17 kg
- Dimensions export carton	1060 x 425 x 425 mm

Illustrations can contain accessories, which are not included in standard extent of delivery
Illustration similar (in design), production-wise modifications reserved
GS mark belongs to the product itself only, excluded accessory

Available as special accessories

Spare line spool GE-CT 18/28
Lawn Trimmer Accessory
Item No.: 3405116
Bar Code: 4006825655216
Einhell Accessory

PXC+ 18V 5-8Ah MULTI
Battery
Item No.: 4511600
Bar Code: 4006825665055
Einhell Accessory

PXC+ 18V 4,0Ah
Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory

PXC+ 18V 4,0Ah SEALED
Battery
Item No.: 4511627
Bar Code: 4006825673227
Einhell Accessory

PXC 18V 3,0Ah
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory

4,0 Ah Power X-Change
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory

2x 18V 5,2Ah PXC-Twinpack
Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory

18V 3Ah PXC Plus Twinpack
Battery
Item No.: 4511631
Bar Code: 4006825673692
Einhell Accessory

2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory

Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory

Power X-Boostcharger 8A
Charger
Item No.: 4512155
Bar Code: 4006825670554
Einhell Accessory

18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory

2x 4,0Ah & Twincharger Kit 1
PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory

18V 2,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory

5,2 Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory

3,0 Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory

PXC 18V 4,0Ah
Battery
Item No.: 4514079
Bar Code: 4006825674316
Einhell Accessory (Discounter)

PXC+ 18V 3,0Ah SEALED
Battery
Item No.: 4511618
Bar Code: 4006825672794
Einhell Accessory

2,0 Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory

4-6 Ah Multi-Ah Power X-Change
Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210

18V 4Ah PXC Plus Twinpack
Battery
Item No.: 4511629
Bar Code: 4006825673685
Einhell Accessory

2x18V 4,0Ah PXC-Twinpack CB
B1
Battery
Item No.: 4511489
Bar Code: 4006825638578

Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory

Power X-Car Charger 3A
Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory

18V Battery Charger 3,0A - PXC
Charger
Item No.: 4514095
Bar Code: 4006825655292
Einhell Accessory

18V 4,0Ah PXC Starter Kit A1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory

18V 4-6Ah & 6A Boostcharger
PXC-Starter-Kit
Item No.: 4512143
Bar Code: 4006825667653
Einhell Accessory

5,2 Ah PXC Starter-Kit
PXC-Starter-Kit
Item No.: 4512147
Bar Code: 4006825675153
Einhell Accessory

Illustrations can contain accessories, which are not included in standard extent of delivery
Illustration similar (in design), production-wise modifications reserved
GS mark belongs to the product itself only, excluded accessory

4Ah PLUS PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512159
Bar Code: 4006825680331
Einhell Accessory

Battery-Running-Times

One Battery for All	trimming[1] (min.)
1.5 Ah	30
2.0 Ah	40
2.5 Ah	45
3.0 Ah	50
4.0 Ah	60
5.2 Ah	70
6.0 Ah	90
8.0 Ah	120

Test setup:

1) lawn

Illustrations can contain accessories, which are not included in standard extent of delivery
Illustration similar (in design), production-wise modifications reserved
GS mark belongs to the product itself only, excluded accessory