



Einhell

ACCESSORY



Cordless Sweeper Accessory

4 tlg. Seitenbürsten-Set

Item No.: 2352060

Ident No.: 21014

Bar Code: 4006825680713

The original Einhell 4-piece lateral brush set is a matching accessory or spare part for the Einhell TE-FS 18 Li battery brush. Its sturdy bristles sweep up dust and dirt from all hard floors, also enabling cleaning close to the edge. The replacement brushes can be easily exchanged by using a screw and a screwdriver and secured on the cordless broom. 4x original Einhell lateral brushes for the Einhell TE-FS 18 Li cordless broom and a screw for fixing are supplied.

Features & Benefits

- Original Einhell 4-piece chisel set
- Suitable for Einhell TE-FS 18 Li cordless push sweeper
- Suitable for cleaning close to edges on hard floors
- Incl. 4x side brushes
- Incl. 1x screw for fixing to battery brush

Technical Data

- Diameter 7.1 cm
- Quantity 4 Pieces



Logistic Data

- Product weight (kg) 0.006
- Gross weight (kg) 0.07
- Dimensions single packaging 106 x 59 x 111 mm
- Pieces per export carton 100 Pieces
- Gross weight of export carton 4.5 kg
- Dimensions export carton 385 x 510 x 335 mm
- Container quantity (20"/40"/40"HC) 45500 | 94500 | 106400