



Einhell

CLASSIC



Cordless Scarifier / Aerator

GC-SC 18/28 Li-Solo

Item No.: 3420604

Ident No.: 21010

Bar Code: 4006825655223

The Einhell cordless scarifier GC-SC 18/28 Li-Solo offers wireless freedom in the home green and is recommended for areas up to 200 m². The batteries, chargers and system devices of the PXC series can be flexibly combined with each other. The cordless scarifier is driven by a brushless electric motor, the housing is made of impact-resistant plastic. It can optionally be extended to a 3-in-1 combi unit with fan roller and basket. The ball-bearing roller has 12 rotating knives. The 3-stage working depth adjustment with transport position as well as the foldable and height-adjustable guide rail allow comfortable working. Large wheels also protect the lawn. An 18 V battery is required for operation. Delivery does not include battery or charger.

Features & Benefits

- Member of the Power X-Change family, 1x18V batteries necessary
- Powerful brushless motor
- Ball-bearing scarifier drum with 12 rotating knives.
- Scarifying depth adjustment, 3 levels + transport position
- Foldable and height adjustable guide rail.
- Wide wheels exert less stress on the lawn
- Impact-resistant plastic housing
- Recommended for lawn areas up to 200 m² (depending on batteries)
- Supplied without battery and charger (available separately)
- Optional extensible with aerator roller and catch bag



Technical Data

- Working width 280 mm
- Number of knives 12 Pieces
- Wheel diameter front 150 mm
- Wheel diameter rear 100 mm

Logistic Data

- Tool weight 6.65 kg
- Gross Weight 8.45 kg
- Dimensions single packaging 509 x 484 x 243 mm
- Pieces per export carton 1 Pieces
- Gross weight of export carton 8.2 kg
- Dimensions export carton 518 x 490 x 245 mm
- Container quantity (20"/40"/40"HC) 396 | 828 | 920



Available as special accessories



2x 3,0Ah & Twincharger Kit
PXC-Starter-Kit
Item No.: 4512083
Bar Code: 4006825638509
Einhell Accessory



18V 4-6Ah Multi-Ah PXC Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210
Einhell Accessory



18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



18V 4,0Ah Power X-Change 1
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



18V 4,0Ah PXC Starter Kit 1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



18V 2,5Ah Power X-Change
Battery
Item No.: 4511516
Bar Code: 4006825650518
Einhell Accessory



Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



18V 5,2Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



Power X-Car Charger 3A
Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



2x 18V 2,5Ah PXC-Twinpack CB
Battery
Item No.: 4511524
Bar Code: 4006825656206
Einhell Accessory



Areator roller GC-SC 18/28 Li
Scarifier Accessory
Item No.: 3405941
Bar Code: 4006825658804
Einhell Accessory



Catch Bag GC-SC 18/28 Li
Scarifier Accessory
Item No.: 3405940
Bar Code: 4006825658798
Einhell Accessory



Scarifier rolle GC-SC 18/28 Li
Scarifier Accessory
Item No.: 3405942
Bar Code: 4006825658811
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB 1
Battery
Item No.: 4511489
Bar Code: 4006825638578
Einhell Accessory




Power X-Boostcharger 6A
Charger
Item No.: 4512064
Bar Code: 4006825629019
Einhell Accessory



18V 3,0Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory

Battery-Running-Times

One Battery for All	 scarifying ¹ (m ²)
1.5 Ah	60
2.0 Ah	80
2.5 Ah	100
3.0 Ah	120
4.0 Ah	160
5.2 Ah	210
6.0 Ah	240
8.0 Ah	320

Test setup:

1) dethatch