



Einhell

ACCESSORY



Cordless Sweeper Accessory
Sweeping Roller TE-FS 18 Li

Item No.: 2352061

Ident No.: 21014

Bar Code: 4006825680720

The original Einhell TE-FS 18 Li sweeping roller is a suitable accessory or spare part for the Einhell TE-FS 18 Li cordless broom. Their sturdy bristles sweep dust and dirt off all hard floors, both indoors and outdoors, as well as from needle-punched nonwoven carpets, into the collection container of the cordless broom. The brush roller can be removed from the battery brush without tools and then exchanged or cleaned. An original Einhell sweeping roller for the Einhell TE-FS 18 Li cordless broom will be delivered.

Features & Benefits

- Original Einhell sweeping roller
- Suitable for Einhell TE-FS 18 Li cordless push sweeper
- Brush roller with robust bristles
- Tool-free change
- For all hard floors and needle felt carpets

Technical Data

- | | |
|-----------------|-------|
| - Working width | 25 cm |
| - Quantity | 1 |

Logistic Data

