



Einhell

PROFESSIONAL



Cordless Sanding Roller
TP-BR 18/32 Li BL - Solo

Item No.: 4468000

Ident No.: 21013

Bar Code: 4006825679380

The Einhell Professional cordless brush sander TP-BR 18/32 Li BL-Solo is a versatile tool for sanding, polishing and cleaning, for example, wood, metal and hard-wearing stone. The tool is driven by an Einhell Brushless motor for extra power and longer running time. Once you register online, the brushless motor has a 10-year guarantee. The Power X-Change cordless brush sander comes with a brass wire brush, other brushes are available separately. The power can be regulated via electronic speed control. The handy design makes it possible to work close to edges. Removable dust screens protect the inside of the tool from contamination. Battery and charger not included.

Features & Benefits

- Member of the Power X-Change family, 1x 18 V battery required
- Brushless motor – more power and longer run time
- Brushless – 10-year warranty on motor after registration
- Effortless removal, even close to the edge
- Continuous operation lock for comfortable working
- Quick, toolless adjustment of the protective plate
- Material & application-adapted working thanks to electronic speed control
- Overload and restart protection for safety and to protect the tool
- Handle with soft grip for comfortable handling
- Additional handle with soft grip
- Incl. brass wire brush for working with wood, metal and stone
- Incl. hexagon key for easy brush exchange
- Does not include battery or charger (available separately)



Technical Data

- Voltage 18 V
- Idle speed 900 - 3200 min⁻¹
- Brush diameter 120 mm
- Brush width 100 mm

Logistic Data

- Product weight (kg) 2.29
- Gross weight (kg) 5.5
- Dimensions single packaging 392 x 240 x 239 mm
- Pieces per export carton 3 Pieces
- Gross weight of export carton 17.5 kg
- Dimensions export carton 745 x 415 x 260 mm
- Container quantity (20"/40"/40"HC) 1026 | 2016 | 2535



BEST PERFORMANCE
≥ 3.0 Ah BATTERY

18 V

ELECTRONIC

Available as special accessories




Bürste Messingdraht 120x100
Sanding Roller Accessory
Item No.: 4468014
Bar Code: 4006825681833
Einhell Accessory




Bürste Schleiflamellen 120x100
Sanding Roller Accessory
Item No.: 4468013
Bar Code: 4006825681826
Einhell Accessory



Bürste Kunstfaser 120x100mm
Sanding Roller Accessory
Item No.: 4468010
Bar Code: 4006825681796
Einhell Accessory



Bürste Nylon 120x100
Sanding Roller Accessory
Item No.: 4468011
Bar Code: 4006825681802
Einhell Accessory



Bürste Schleifstreifen 120x100
Sanding Roller Accessory
Item No.: 4468012
Bar Code: 4006825681819
Einhell Accessory



5,2 Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



PXC+ 18V 5-8Ah MULTI
Battery
Item No.: 4511600
Bar Code: 4006825665055
Einhell Accessory



PXC+ 18V 4,0Ah
Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory



PXC 18V 3,0Ah
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory



3,0 Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



2,0 Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



4,0 Ah Power X-Change
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



4-6 Ah Multi-Ah Power X-Change
Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210



2x 18V 5,2Ah PXC-Twinpack
Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB
B1
Battery
Item No.: 4511489
Bar Code: 4006825638578



2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



Power X-Car Charger 3A
Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1
PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory



18V 2,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory



E-Case L with wheels
System Carrying Case
Item No.: 4540014
Bar Code: 4006825660562
Einhell Accessory



E-Case Tasche
System Carrying Case
Item No.: 4540036
Bar Code: 4006825677966
Einhell Accessory



E-Case S-F
System Carrying Case
Item No.: 4540011
Bar Code: 4006825653991
Einhell Accessory



E-Case M
System Carrying Case
Item No.: 4540021
Bar Code: 4006825667721
Einhell Accessory



E-Case Werkzeugkiste
System Carrying Case
Item No.: 4540037
Bar Code: 4006825677973
Einhell Accessory

Battery-Running-Times



One Battery for All	sanding ¹ (m)
1.5 Ah	8
2.0 Ah	11
2.5 Ah	13
3.0 Ah	16
4.0 Ah	21
5.2 Ah	27
6.0 Ah	32
8.0 Ah	42

For best performance select a battery with at least 3.0 Ah

Test setup:

1) softwood - wooden beam 10 cm - Max. electronic speed