



The Einhell cordless angle grinder TC-WS 18 Li-Solo is ideal for cutting metal and stone. As part of the Power X-Change family, it requires an 18 V battery. The disc guard with a quick-release lever, slim design, and adjustable auxiliary handle enable flexible working. With a disc diameter of up to 125 mm and a cutting depth of 33 mm, it offers versatile applications. Soft start, restart protection, and overload protection ensure safety and durability. A special support surface prevents tipping over. Delivery does not include battery, charger, and cutting disc.

Features & Benefits

- Member of the Power X-Change family, requires 1x 18 V battery
- Soft start and restart protection for enhanced safety
- Additional handle adjustable in 3 positions
- Overload protection prevents overheating
- Disc guard for flexible working
- Raised support surface for safe placement
- Includes cutting guard – suitable for various tasks
- Delivery without cutting disc
- Delivery without battery and charger (available separately)





Technical Data

- | | |
|-------------------------------------|------------------------|
| - Disc size | 125 mm |
| - No-load speed (idle speed) Max. | 8500 min ⁻¹ |
| - Max. cutting depth | 33 mm |



Logistic Data

- | | |
|--------------------------------------|--------------------|
| - Product weight (kg) | 1.7 |
| - Gross weight (kg) | 2.16 |
| - Dimensions single packaging | 350 x 145 x 120 mm |
| - Pieces per export carton | 4 Pieces |
| - Gross weight of export carton | 10.6 kg |
| - Dimensions Export Carton | 488 x 378 x 187 mm |
| - Container quantity (20"/40"/40"HC) | 3020 6500 7540 |



Available as special accessories

	Trennschutz TC-WS 18 Li Angle Grinder Accessory Item No.: 4450060 Bar Code: 4006825675542 No Name		5,2 Ah Power X-Change Plus Battery Item No.: 4511437 Bar Code: 4006825616606 Einhell Accessory
	PXC+ 18V 5-8Ah MULTI Battery Item No.: 4511600 Bar Code: 4006825665055 Einhell Accessory		PXC 18V 4,0Ah Battery Item No.: 4514079 Bar Code: 4006825674316 Einhell Accessory (Discounter)
	PXC+ 18V 4,0Ah SEALED Battery Item No.: 4511627 Bar Code: 4006825673227 Einhell Accessory		PXC+ 18V 4,0Ah Battery Item No.: 4511553 Bar Code: 4006825660869 Einhell Accessory
	PXC+ 18V 3,0Ah SEALED Battery Item No.: 4511618 Bar Code: 4006825672794 Einhell Accessory		PXC 18V 3,0Ah Battery Item No.: 4511341 Bar Code: 4006825590593 Einhell Accessory
	3,0 Ah Power X-Change Plus Battery Item No.: 4511501 Bar Code: 4006825644197 Einhell Accessory		2,0 Ah Power X-Change Battery Item No.: 4511395 Bar Code: 4006825610369 Einhell Accessory
	4,0 Ah Power X-Change Battery Item No.: 4511396 Bar Code: 4006825610376 Einhell Accessory		4-6 Ah Multi-Ah Power X-Change Plus Battery Item No.: 4511502 Bar Code: 4006825644210
	2x 18V 5,2Ah PXC-Twinpack Battery Item No.: 4511526 Bar Code: 4006825656695 Einhell Accessory		18V 4Ah PXC Plus Twinpack Battery Item No.: 4511629 Bar Code: 4006825673685 Einhell Accessory
	18V 3Ah PXC Plus Twinpack Battery Item No.: 4511631 Bar Code: 4006825673692 Einhell Accessory		2x18V 4,0Ah PXC-Twinpack CB B1 Battery Item No.: 4511489 Bar Code: 4006825638578
	2x2 Power X-Quattrocharger 4A Charger Item No.: 4512102 Bar Code: 4006825649536 Einhell Accessory		Power X-Fastcharger 4A Charger Item No.: 4512103 Bar Code: 4006825650228 Einhell Accessory
	Power X-Twincharger 3A Charger Item No.: 4512069 Bar Code: 4006825629729 Einhell Accessory		Power X-Car Charger 3A Charger Item No.: 4512113 Bar Code: 4006825655377 Einhell Accessory
	Power X-Boostcharger 8A Charger Item No.: 4512155 Bar Code: 4006825670554 Einhell Accessory		18V Battery Charger 3,0A - PXC Charger Item No.: 4514095 Bar Code: 4006825655292 Einhell Accessory
	18V 2,5Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512097 Bar Code: 4006825646962 Einhell Accessory		2x 4,0Ah & Twincharger Kit 1 PXC-Starter-Kit Item No.: 4512112 Bar Code: 4006825655766 Einhell Accessory
	18V 4-6Ah & 6A Boostcharger PXC-Starter-Kit Item No.: 4512143 Bar Code: 4006825667653 Einhell Accessory		18V 2,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512040 Bar Code: 4006825613681 Einhell Accessory
	5,2 Ah PXC Starter-Kit PXC-Starter-Kit Item No.: 4512147 Bar Code: 4006825675153 Einhell Accessory		18V 4,0Ah PXC Starter Kit B1 PXC-Starter-Kit Item No.: 4512042 Bar Code: 4006825613704 Einhell Accessory



4Ah PLUS PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512159
Bar Code: 4006825680331
Einhell Accessory