



Cordl. Wet/Dry Vacuum Cleaner

TE-VC 36/30 Li S-Solo

ltem No.: 2347140

Ident No.: 11018

Bar Code: 4006825635874

The Einhell TE-VC 36/30 Li S-Solo cordless wet and dry vacuum cleaner is a member of the Power X-Change series. For optimum use of the battery there are two speeds: ECO and BOOST. Both the 30 I stainless steel tank and the stainless steel telescopic tube (Ø 36 mm) are robust in design. The accessory holder for neat storage and water drain screw make it a practical product to use. The blow connection is for blow-cleaning hard-to-reach areas. Easy transportation is ensured by the large wheels and castors. The product is supplied with a heavy-duty suction hose (Ø 36 mm, 2.5 m length) and a large combination nozzle for carpets and smooth flooring. The battery and charger are available separately.

Features & Benefits

- Member of the Power X-Change family, 2x18V batteries necessary
- 2 speeds (ECO/BOOST) for optimal battery use
- High suction power with simultaneous wireless freedom
- Stainless steel tank with 30 I capacity
- Blow connection for blow-cleaning hard-to-reach areas
- 2 large wheels & 2 castors for better mobility
- Practical accessories holder for clean stowage and operations
- Water drain screw for draining the sucked water
- Telescopic stainless steel suction tube Ø 36 mm
- Incl. heavy-duty suction hose Ø 36 mm, 2.5 m
- Incl. big comfort nozzle for carpets/smooth floors
- Air regulator on the handle
- 1 foam filter for wet vacuuming, 1 pleated filter and 1 paper bag
- Supplied without battery and charger (available separately)
- Recommendation for best results: 3.0 Ah batteries or higher

Technical Data

- Volume	30 L
- Suction power max.	150 mbar
- Suction hose length	250 cm
- Suction hose diameter	36 mm
- Sound pressure level Lpa	76 dB (A)

Logistic Data

- Gross weight (kg)	11.71
- Pieces per export carton	1 Pieces
- Container quantity (20"/40"/40"HC)	222 456 608



250 cm

x 36 mm

2 x 18 V

ECO

OO mbar

Available as special accessories



Set Of Nozzles 2 Wet/Dry Vacuum Cleaner Access. Item No.: 2351255 Bar Code: 4006825635676 **Einhell Accessory**

Wet/Dry Vacuum Cleaner Access. Item No.: 2351140 Bar Code: 4006825231151

5 pcs. Accessory Kit 64mm Wet/Dry Vacuum Cleaner Access. Item No.: 2362010

Bar Code: 4006825604290 **Einhell Accessory**

Power X-Boostcharger 6A

Bar Code: 4006825629019 **Einhell Accessory**

Charger Item No.: 4512064

Fabric Filter

Einhell Accessory









Wet/Dry Vacuum Cleaner Access. Item No.: 2351225 Bar Code: 4006825630084 Einhell Accessory

Soft Upholstery Brush

Car Cleaning Set Wet/Dry Vacuum Cleaner Access. Item No.: 2351245 Bar Code: 4006825630121 **Einhell Accessory**

Small Universal Nozzle Wet/Dry Vacuum Cleaner Access. Item No.: 2351210

Hard Upholstery Brush Wet/Dry Vacuum Cleaner Access. Item No.: 2351220

Bar Code: 4006825630053

Bar Code: 4006825630077

Einhell Accessory

Einhell Accessory







18V 2,0Ah Power X-Change Battery Item No.: 4511395 Bar Code: 4006825610369 Einhell Accessory



18V 3,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512041 Bar Code: 4006825613698 Einbell Accessed **Einhell Accessory**



18V 5,2Ah Power X-Change Plus Battery Item No.: 4511437 Bar Code: 4006825616606 Einhell Accessory



Suction Hose Wet/Dry Vacuum Cleaner Access. Item No.: 2362000 Bar Code: 4006825543018 Einhell Accessory



Power X-Twincharger 3A Charger Item No.: 4512069 Bar Code: 4006825629729 **Einhell Accessory**











Bar Code: 4006825630091 **Einhell Accessory**

Long Crevice Nozzle Wet/Dry Vacuum Cleaner Access. Item No.: 2351205 Bar Code: 4006825630046 **Einhell Accessory**

Bar Code: 4006825644098 **Einhell Accessory**



18V 4,0Ah Power X-Change Bar Code: 4006825610376



18V 4,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512042 Bar Code: 4006825613704 **Einhell Accessory**





Drill Adaptor Wet/Dry Vacuum Cleaner Access. Item No.: 2351233 Bar Code: 4006825653960 Einhell Accessory

Premium Suction Hose Wet/Dry Vacuum Cleaner Access. Item No.: 2362005 Bar Code: 4006825651980 Einhell Accessory



Pleated Filter Wet/Dry Vacuum Cleaner Access. Item No.: 2351110 Bar Code: 4006825231090 **Einhell Accessory**

Pleated Filter With Lid Wet/Dry Vacuum Cleaner Access. Item No.: 2351113 Bar Code: 4006825566512 **Einhell Accessory**

Dirt Bag Filter 30l (5 pcs.) Wet/Dry Vacuum Cleaner Access. Item No.: 2351170 Bar Code: 4006825528763 **Einhell Accessory**



Round Carpet Brush Wet/Dry Vacuum Cleaner Access. Item No.: 2351230

Set Of Nozzles 1 Wet/Dry Vacuum Cleaner Access. Item No.: 2351235 Bar Code: 4006825630107 Einhell Accessory

Universal Floor Nozzle Wet/Dry Vacuum Cleaner Access. Item No.: 2351215 Bar Code: 4006825630060 **Einhell Accessory**

Foamfilter (5 pcs) Wet/Dry Vacuum Cleaner Access. Item No.: 2351132





GS mark belongs to the product itself only, excluded accessory Page 2

Battery-Running-Times

One Battery for All	vacuuming ¹ (min.)	vacuuming² (min.)
1.5 Ah	6	8
2.0 Ah	8	11
2.5 Ah	10	13
3.0 Ah	12	16
4.0 Ah	16	22
5.2 Ah	21	28
6.0 Ah	24	33

For best performance select a battery with at least 3.0 Ah

Test setup:

1) BOOST

2) ECO

Illustrations can contain accessories, which are not included in standard extent of delivery Illustration similar (in design), production-wise modifications reserved GS mark belongs to the product itself only, excluded accessory Generated at: 17.11.2020 15:59 Page 3