Einhell

EXPERT

POWER X-CHANGE

Cordless Lawn Trimmer

GE-CT 18/25-1 Li-Solo

Item No.: 3411256

Ident No.: 21014

Bar Code: 4006825684117

The Einhell cordless trimmer GE-CT 18/25-1 Li-Solo is a powerful lawn care tool from the Power X-Change family. With the motor head – which can be rotated by 180° and tilted to 3 positions – along with its edging function, you can trim lawn edges and hard-to-reach areas. The Flowerguard keeps the tool at a suitably safe distance from flowers and ornamental plants. The cordless trimmer cutting mechanism can be switched between blades and trimmer line. This trimmer has an infinitely adjustable telescopic guide bar and an additional handle with an integrated blade storage compartment. Delivery includes 20 x plastic blades and 1 x trimmer line spool. Battery and charger not included.

Features & Benefits

- A member of the Power XChange family; 1 x 18 V battery required
- 180° rotatable motor head: For vertical surfaces/lawn edges
- 3-way tiltable motor head for flexible working
- Infinitely telescopic guide bar
- Infinitely adjustable second handle
- Compartment for 20 blades integrated into second handle
- Flowerguard protects plants and trees from damage
- Soft grip surfaces for comfortable handling
- Robust blade holder for longer blade life
- Incl. 20 x plastic blades
- Incl. 1 x trimmer line spool
- Different attachment are easily interchangeable
- Battery and charger not included (available separately)



Technical Data

- Revolutions of knife	8400 rpm
- Cutting width of knife	25 cm
- Number of knives	20 Pieces
- Revolutions of thread	8400 rpm
- Cutting width of thread	25 cm
- Thread length	5 m
- Thread diameter	1.6 mm
- Readjustment of thread	Tipp automatic
- Cutting feature	Single line

Logistic Data

- Product weight	2 kg
- Gross weight single packaging	3.11 kg
- Dimensions single packaging	1015 x 200 x 127 mm
- Pieces per export carton	4 Pieces
- Gross weight export carton	14.4 kg
- Dimensions export carton	1030 x 415 x 270 mm



Illustrations can contain accessories, which are not included in standard extent of delivery
Illustration similar (in design), production-wise modifications reserved
GS mark belongs to the product itself only, excluded accessory
Generated at: 24.11.2025 10:42

Available as special accessories

PXC Battery Mounting Gadget
PXC-Battery Accessory
Item No.: 4514155
Bar Code: 4006825658774
Einhell Accessory

Thread Head f. GE-CT 18/25 Li
Lawn Trimmer Accessory
Item No.: 3405175
Bar Code: 4006825680454
Einhell Accessory

Spareknife-Box GE-CT 18/25 Li
Lawn Trimmer Accessory
Item No.: 3405739
Bar Code: 4006825681147
Einhell Accessory

PXC+ 18V 5-8Ah MULTI
Battery
Item No.: 4511600
Bar Code: 4006825665055
Einhell Accessory

PXC+ 18V 4,0Ah
Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory

PXC 18V 2,0Ah
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory

PXC+ 18V 4-6Ah MULTI
Battery
Item No.: 4511502
Bar Code: 4006825644210
Einhell Accessory

PXC+ 18V 4,0Ah SEALED
Battery
Item No.: 4511627
Bar Code: 4006825673227
Einhell Accessory

18V 4Ah PXC Plus Twinpack
Battery
Item No.: 4511629
Bar Code: 4006825673685
Einhell Accessory

2x18V 4,0Ah PXC-Twinpack CB C1
Battery
Item No.: 4511489
Bar Code: 4006825638578

Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory

Power X-Car Charger 3A
Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory

18V Battery Charger 3,0A - PXC
Charger
Item No.: 4514095
Bar Code: 4006825655292
Einhell Accessory

2x 4,0Ah & Twincharger Kit 1
PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory

Fadenspule GE-CT 18/25 Li
Lawn Trimmer Accessory
Item No.: 3405113
Bar Code: 4006825680393
Einhell Accessory

Spareknife-Set GE-CT 18/25 Li
Lawn Trimmer Accessory
Item No.: 3405738
Bar Code: 4006825681130
Einhell Accessory

PXC 18V 5,2Ah
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory

PXC+ 18V 3,0Ah
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory

PXC 18V 3,0Ah
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory

PXC 18V 4,0Ah
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory

PXC+ 18V 3,0Ah SEALED
Battery
Item No.: 4511618
Bar Code: 4006825672794
Einhell Accessory

2x 18V 5,2Ah PXC-Twinpack
Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory

18V 3Ah PXC Plus Twinpack
Battery
Item No.: 4511631
Bar Code: 4006825673692
Einhell Accessory

2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory

Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory

Power X-Boostcharger 8A
Charger
Item No.: 4512155
Bar Code: 4006825670554
Einhell Accessory

18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory

18V 4-6Ah & 6A Boostcharger
PXC-Starter-Kit
Item No.: 4512143
Bar Code: 4006825667653
Einhell Accessory

Illustrations can contain accessories, which are not included in standard extent of delivery
Illustration similar (in design), production-wise modifications reserved
GS mark belongs to the product itself only, excluded accessory

18V 4,0Ah PXC Starter Kit C1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory

Battery-Running-Times

One Battery for All	trimming[1] (null)
1.5 Ah	32
2.0 Ah	42
2.5 Ah	53
3.0 Ah	63
4.0 Ah	84
5.2 Ah	110
6.0 Ah	126
8.0 Ah	168

Test setup:

1) lawn - knife

Illustrations can contain accessories, which are not included in standard extent of delivery
Illustration similar (in design), production-wise modifications reserved
GS mark belongs to the product itself only, excluded accessory