



# Einhell

## PROFESSIONAL



**Cordless Hedge Trimmer**  
**GP-CH 18/50 Li BL-Solo**

**Item No.: 3410950**

Ident No.: 21014

Bar Code: 4006825679748

The Einhell Professional cordless hedge trimmer GP-CH 18/50 Li BL-Solo is a valuable helper in any garden. The device is driven by a Brushless motor for enhanced power and longer runtime. Once you register online, the brushless motor has a 10-year guarantee. Two speed settings, ECO & MAX POWER mode, power the precise laser-cut and diamond-ground steel blades with a cutting length of 50 cm. The anti-lock braking system ensures optimum safety at work. The removable clippings collector makes it possible to remove the clippings quickly. A stable quiver to protect the knives is included. Battery and charger device not included.

## Features & Benefits

- Member of the Power X-Change family, 1 x 18 V battery required
- Brushless motor – more power and longer run time
- Brushless – 10-year motor guarantee after registration
- 2 speed levels for optimal battery use
- Laser-cut and diamond-ground steel blades
- Anti-jam system for optimal safety at work
- Cuttings collector for removing cutting material
- Impact protection for blades
- High-quality blade cover made of aluminium
- Metal transmission for a long service life
- Ergonomic, slim front handle with micro switch
- Extensive hand protection for safe working
- Comfortable hold thanks to integrated softgrip surfaces
- Incl. Protective case for transport and storage
- Delivery without battery and charger (available separately)



## Technical Data

- Blade length 560 mm
- Cutting length 500 mm
- Spacing between teeth 20 mm
- Cuts per minute 3060 min<sup>-1</sup>

## Logistic Data

- Product weight 2.45 kg
- Gross weight single packaging 3.6 kg
- Dimensions single packaging 985 x 253 x 175 mm
- Pieces per export carton 4 Pieces
- Gross weight export carton 15.4 kg
- Dimensions Export Carton 1000 x 520 x 250 mm
- Container quantity (20"/40"/40"HC) 792 | 1656 | 1840



## Available as special accessories



18V 2,5Ah PXC Starter Kit  
PXC-Starter-Kit  
Item No.: 4512097  
Bar Code: 4006825646962  
Einhell Accessory



18V 4,0Ah PXC Starter Kit A1  
PXC-Starter-Kit  
Item No.: 4512042  
Bar Code: 4006825613704  
Einhell Accessory



2x2 Power X-Quattrocharger 4A  
Charger  
Item No.: 4512102  
Bar Code: 4006825649536  
Einhell Accessory



Power X-Fastcharger 4A  
Charger  
Item No.: 4512103  
Bar Code: 4006825650228  
Einhell Accessory



Power X-Twincharger 3A  
Charger  
Item No.: 4512069  
Bar Code: 4006825629729  
Einhell Accessory



Power X-Car Charger 3A  
Charger  
Item No.: 4512113  
Bar Code: 4006825655377  
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1  
PXC-Starter-Kit  
Item No.: 4512112  
Bar Code: 4006825655766  
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack  
Battery  
Item No.: 4511526  
Bar Code: 4006825656695  
Einhell Accessory



PXC Battery Mounting Gadget  
PXC-Battery Accessory  
Item No.: 4514155  
Bar Code: 4006825658774  
Einhell Accessory



18V 4-6Ah & 6A Boostcharger  
PXC-Starter-Kit  
Item No.: 4512143  
Bar Code: 4006825667653  
Einhell Accessory



Power X-Boostcharger 8A  
Charger  
Item No.: 4512155  
Bar Code: 4006825670554  
Einhell Accessory



5,2 Ah Power X-Change Plus  
Battery  
Item No.: 4511437  
Bar Code: 4006825616606  
Einhell Accessory



PXC+ 18V 5-8Ah MULTI  
Battery  
Item No.: 4511600  
Bar Code: 4006825665055  
Einhell Accessory



18V 4Ah PXC Plus Twinpack  
Battery  
Item No.: 4511629  
Bar Code: 4006825673685  
Einhell Accessory



18V 3Ah PXC Plus Twinpack  
Battery  
Item No.: 4511631  
Bar Code: 4006825673692  
Einhell Accessory



18V Battery Charger 3,0A - PXC  
Charger  
Item No.: 4514095  
Bar Code: 4006825655292  
Einhell Accessory



PXC+ 18V 4,0Ah SEALED  
Battery  
Item No.: 4511627  
Bar Code: 4006825673227  
Einhell Accessory



PXC+ 18V 4,0Ah  
Battery  
Item No.: 4511553  
Bar Code: 4006825660869  
Einhell Accessory



PXC+ 18V 3,0Ah SEALED  
Battery  
Item No.: 4511618  
Bar Code: 4006825672794  
Einhell Accessory



PXC 18V 3,0Ah  
Battery  
Item No.: 4511341  
Bar Code: 4006825590593  
Einhell Accessory



3,0 Ah Power X-Change Plus  
Battery  
Item No.: 4511501  
Bar Code: 4006825644197  
Einhell Accessory



2,0 Ah Power X-Change  
Battery  
Item No.: 4511395  
Bar Code: 4006825610369  
Einhell Accessory




4,0 Ah Power X-Change  
Battery  
Item No.: 4511396  
Bar Code: 4006825610376  
Einhell Accessory



4-6 Ah Multi-Ah Power X-Change  
Plus  
Battery  
Item No.: 4511502  
Bar Code: 4006825644210

# Battery-Running-Times

One Battery for All		
	cutting <sup>1</sup> (min.)	cutting <sup>2</sup> (min.)
1.5 Ah	29.5	20
2.0 Ah	39	27
2.5 Ah	49	33
3.0 Ah	59	40
4.0 Ah	78	53
5.2 Ah	102	69
6.0 Ah	118	80
8.0 Ah	156	106

**Test setup:**

1) no-load - ECO - hedge trimmer

2) no-load - BOOST