



Einhell

EXPERT

POWER X-CHANGE

Cordless Chain Saw

FORTEXXA 18/300 Set

Item No.: 4600011

Ident No.: 21013

Bar Code: 4006825672435

The Einhell FORTEXXA 18/300 Set cordless chainsaw is a member of the Power X-Change family. The chain saw is driven by a PurePOWER brushless electric motor, is equipped with an OREGON quality blade and chain and has a tool-free adjustable chain tension/change. The chain catcher and the kickback protection with instant chain brake ensure safety and the automatic chain lubrication via the large oil filling opening for care. The claw stop is made of metal, the ergonomic handle is equipped with softgrip. The chain speed is adjustable, it can be switched between full power and Eco mode. Delivery does not include battery or charger. The scope of delivery includes a second chain for changing.

Features & Benefits

- Member of the Power X-Change family, 1x 18V battery required
- Brushless motor - more power and longer running time
- PurePOWER Brushless - 10 years motor warranty after registration
- High-quality chain and bar from OREGON
- Speed setting depending on the application
- Selection of HIGH power (8.9 m/s) and ECO power (6 m/s)
- Kickback protection with instant chain brake
- Toolless chain tensioning and changing
- Ergonomic handle with softgrip
- Sturdy stop claws made of metal
- Big filler opening
- Automatic chain lubrication
- Chain catcher
- Recommendation for optimum results: 4.0 Ah rechargeable battery
- Delivery incl. 2nd chain for changing
- Supplied without battery and charger (available separately)



Technical Data

- Sword length 300 mm
- Max. cutting length 27 cm
- Chain cutting speed 8.9 m/s
- Oil tank capacity 160 mL

Logistic Data

- Product weight (kg) 4.03 kg
- Gross weight (kg) 5.54 kg
- Dimensions single packaging 255 x 477 x 282 mm
- Pieces per export carton 4 Pieces
- Gross weight export carton 22.75 kg
- Dimensions Export Carton 580 x 500 x 535 mm
- Container quantity (20"/40"/40"HC) 656 | 1376 | 1720



Available as special accessories



18V 4-6Ah Multi-Ah PXC Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210
Einhell Accessory



18V 2,0Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



18V 4,0Ah PXC Starter Kit 1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



18V 2,5Ah Power X-Change
Battery
Item No.: 4511516
Bar Code: 4006825650518
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB 1
Battery
Item No.: 4511489
Bar Code: 4006825638578
Einhell Accessory



18V 3,0 Ah Power-X-Change 2
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory



18V 3,0Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



18V 4,0Ah Power X-Change 1
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



Power X-Car Charger 3A
Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



Power X-Boostcharger 6A
Charger
Item No.: 4512064
Bar Code: 4006825629019
Einhell Accessory





Ersatzkette 30cm 1,1 45T 3/8
Chain Saw Accessory
Item No.: 4500192
Bar Code: 4006825663532
Einhell Accessory



18V 5,2Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory

Battery-Running-Times

One Battery for All		
	sawing ¹ (pieces)	sawing ² (pieces)
1.5 Ah	53	59
2.0 Ah	70	78
2.5 Ah	88	98
3.0 Ah	105	117
4.0 Ah	140	156
5.2 Ah	182	203
6.0 Ah	210	234
8.0 Ah	280	312

For best performance select a battery with at least 4.0 Ah

Test setup:

1) wood - scantling 70x70 mm - BOOST

2) wood - scantling 70x70 mm - ECO