



# Einhell

# CLASSIC

## POWER X-CHANGE

Cordless Drill

**TC-CD 18/38 Li - Solo**

**Item No.: 4514365**

Ident No.: 21015

Bar Code: 4006825686159

The Einhell Cordless Drill Driver TC-CD 18/38 Li-Solo is a compact member of the Power X-Change family. With up to 38 Nm torque, 21 torque settings and a drilling stage, it is a reliable helper for various screwdriving and drilling tasks. Speed electronics enable precise adjustment of power to suit the material and application, while the torque slip clutch prevents over-tightening of screws. Drill and screwdriver bits can be changed quickly thanks to the 10 mm double-sleeve quick-change chuck and Quick Stop function. An LED light ensures good visibility. Supplied without battery or charger.

## Features & Benefits

- Member of the Power X-Change family, 1x 18 V battery required
- Metal gearbox for powerful drilling and screwdriving
- Speed control for work suited to the material
- Torque slip coupling prevents screw over-tightening
- 10 mm quick-release chuck for fast tool changes
- Quick-stop for fast and easy tool changes
- Integrated LED lights up the working area
- Ergonomic design with soft grip
- Supplied without battery and charger (sold separately)



**PXC BATTERY**  
BATTERY & CHARGER  
NOT INCLUDED

## Technical Data

- Number of gears 1
- Idle speed (gear 1) 550 min<sup>-1</sup>
- Max. torque hard 38 Nm
- Number of torque steps 21+1 settings
- Drill chuck 10 mm | double sleeve



LED

## Logistic Data

- Product weight 1.03 kg
- Gross weight single packaging 1.52 kg
- Dimensions single packaging 198 x 95 x 227 mm
- Pieces per export carton 4 Pieces
- Gross weight export carton 6.6 kg
- Dimensions export carton 400 x 215 x 245 mm
- Container quantity (20"/40"/40"HC) 5000 | 10680 | 12400

**PXC BATTERY**  
BATTERY & CHARGER  
NOT INCLUDED

**18 V**

**38 Nm  
HIGH  
POWER**



## Available as special accessories



E-Case L with wheels  
System Carrying Case  
Item No.: 4540014  
Bar Code: 4006825660562  
Einhell Accessory



E-Case Tasche  
System Carrying Case  
Item No.: 4540036  
Bar Code: 4006825677966  
Einhell Accessory



E-Case S-F  
System Carrying Case  
Item No.: 4540011  
Bar Code: 4006825653991  
Einhell Accessory



E-Case M  
System Carrying Case  
Item No.: 4540021  
Bar Code: 4006825667721  
Einhell Accessory



E-Case Werkzeugkiste  
System Carrying Case  
Item No.: 4540037  
Bar Code: 4006825677973  
Einhell Accessory



5,2 Ah Power X-Change Plus  
Battery  
Item No.: 4511437  
Bar Code: 4006825616606  
Einhell Accessory



PXC+ 18V 5-8Ah MULTI  
Battery  
Item No.: 4511600  
Bar Code: 4006825665055  
Einhell Accessory



3,0 Ah Power X-Change Plus  
Battery  
Item No.: 4511501  
Bar Code: 4006825644197  
Einhell Accessory



PXC+ 18V 4,0Ah  
Battery  
Item No.: 4511553  
Bar Code: 4006825660869  
Einhell Accessory



2,0 Ah Power X-Change  
Battery  
Item No.: 4511395  
Bar Code: 4006825610369  
Einhell Accessory



4,0 Ah Power X-Change  
Battery  
Item No.: 4511396  
Bar Code: 4006825610376  
Einhell Accessory



4-6 Ah Multi-Ah Power X-Change  
Plus  
Battery  
Item No.: 4511502  
Bar Code: 4006825644210



PXC 18V 2,5Ah  
Battery  
Item No.: 4511516  
Bar Code: 4006825650518  
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack  
Battery  
Item No.: 4511526  
Bar Code: 4006825656695  
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB  
C1  
Battery  
Item No.: 4511489  
Bar Code: 4006825638578



2x2 Power X-Quattrocharger 4A  
Charger  
Item No.: 4512102  
Bar Code: 4006825649536  
Einhell Accessory



Power X-Fastcharger 4A  
Charger  
Item No.: 4512103  
Bar Code: 4006825650228  
Einhell Accessory



Power X-Twincharger 3A  
Charger  
Item No.: 4512069  
Bar Code: 4006825629729  
Einhell Accessory



Power X-Car Charger 3A  
Charger  
Item No.: 4512113  
Bar Code: 4006825655377  
Einhell Accessory



Power X-Boostcharger 8A  
Charger  
Item No.: 4512155  
Bar Code: 4006825670554  
Einhell Accessory



18V 2,5Ah PXC Starter Kit  
PXC-Starter-Kit  
Item No.: 4512097  
Bar Code: 4006825646962  
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1  
PXC-Starter-Kit  
Item No.: 4512112  
Bar Code: 4006825655766  
Einhell Accessory



18V 4-6Ah & 6A Boostcharger  
PXC-Starter-Kit  
Item No.: 4512143  
Bar Code: 4006825667653  
Einhell Accessory



18V 4,0Ah PXC Starter Kit C1  
PXC-Starter-Kit  
Item No.: 4512042  
Bar Code: 4006825613704  
Einhell Accessory

# Battery-Running-Times



screwing<sup>1</sup>  
(pieces)

One Battery for All

1.5 Ah	230
2.0 Ah	305
2.5 Ah	380
3.0 Ah	460
4.0 Ah	610
5.2 Ah	790
6.0 Ah	920
8.0 Ah	1220

Test setup:

1) softwood - 6x60 mm