

GP-LS 18/28 Li BL
Cordless Pruning Shears

USAGE

1) Off → Standby



2) Standby → On



WIDTH ADJUSTMENT

3) Cutting Width



4) Off

automatic



On → **Auto Standby**: 30 sec
Standby → **Auto shutoff**: 10 Min

manual



On → Off:
press 3 sec



On → Auto Standby:
Start-up lock + 5 sec