



# Einhell

# ACCESSORY

System Carrying Case

**E-Case M**

Item No.: 4540021

Ident No.: 21024

Bar Code: 4006825667721

The Einhell E-Case M is a member of Einhell's modular E-Case system. The case is suitable for storing and transporting machines and tools. The locking system for easy connection of stacked cases enables safe transport and easy storage. The case is made of polypropylene, which is splash-proof, heat-resistant and impact-resistant thanks to the high-quality material. The inner height of 25 cm is optimised for large Einhell products. A foldable ergonomic handle ensures comfortable wearing. The case can be equipped with a padlock and contains an insert for hand tools and stickers for labelling.

## Features & Benefits

- Member of the modular E-Case-System from Einhell:
- practical system case for storage/transport of machines and tools
- Locking system for connecting stacked cases
- ensures easy storage and transport
- High-quality material polypropylene ensures heat resistance, stiffness and impact resistance
- inner height of 25 cm is optimized for bulky einhell products
- Easy to use as opening of stacked cases is possible
- Splash-proof design for save storage and transport
- foldable + ergonomic handle for comfortable carrying,
- e.g. while pulling of the car trunk
- padlock applicable as anti-theft device
- including 1x tray to store hand tools
- including inscribable sticker - to always know the contents



## Technical Data

- Inner dimensions (E-Case M) 280 x 415 x 250 mm
- Max. payload 90 kg



## Logistic Data

- Product weight (kg) 2.71
- Gross weight (kg) 3.4
- Dimensions single packaging 451 x 344 x 323 mm
- Pieces per export carton 1 Pieces
- Gross weight of export carton 4.27 kg
- Dimensions export carton 470 x 345 x 320 mm
- Container quantities (20"/40"/40"HC) 564 | 1182 | 1350

### E-CASE-SYSTEM


















The following Power X-Change devices fit into E-Case M
















(1x Power X-Charger + 2x 3,0 Ah PXC Plus Akku)



| Item no       | Tpg code   | Description              | Description 2                  | Product picture   |
|---------------|------------|--------------------------|--------------------------------|---|
| 3408017_21010 | PT-C-BT-02 | TC-RA 18 Li BT - Solo    | Cordless Radio                 |    |
| 4260025_21010 | PT-C-BT-03 | TC-SY 18/60 Li-Solo      | Cl.Paint Spray Sys (Spray Gun) |    |
| 4514150_11019 | PT-C-BT-10 | TC-SR 18 Li BT - Solo    | Cordless Speaker               |    |
| 4020467_21011 | PT-C-DT-01 | PRESSITO 18/21           | Cordless Air Compressor        |    |
| 4020420_21011 | PT-C-DT-01 | PRESSITO 18/25           | Cordless Air Compressor        |    |
| 4513812_21021 | PT-C-EW-01 | TE-HD 18 Li-Solo         | Cordless Rotary Hammer         |  |
| 4513970_21023 | PT-C-EW-01 | TE-HD 18/12 Li - Solo    | Cordless Rotary Hammer         |  |
| 4513925_11018 | PT-C-EW-02 | TE-CD 18/40 Li-Solo      | Cordless Drill                 |  |
| 4513997_21010 | PT-C-EW-02 | TE-CD 18/40 Li BL - Solo | Cordless Drill                 |  |
| 4514210_21010 | PT-C-EW-02 | TP-CD 18/60 Li BL - Solo | Cordless Drill                 |  |
| 4513927_21021 | PT-C-EW-02 | TC-CD 18/35 Li - Solo    | Cordless Drill                 |  |
| 4513887_21032 | PT-C-EW-02 | TP-CD 18/50 Li BL-Solo   | Cordless Drill                 |  |
| 4510034_21021 | PT-C-EW-06 | TE-CI 18/1 Li-Solo       | Cordless Impact Driver         |  |

|               |            |                           |                               |   |
|---------------|------------|---------------------------|-------------------------------|---|
| 4326290_21010 | PT-C-EW-09 | TE-AP 18/26 Li - Solo     | Cordless All Purpose Saw      |     |
| 4326310_21043 | PT-C-EW-09 | TP-AP 18/28 Li BL - Solo  | Cordless All Purpose Saw      |    |
| 4326315_21013 | PT-C-EW-09 | TE-AP 18/13 Li - Solo     | Cordless All Purpose Saw      |    |
| 4326300_21043 | PT-C-EW-09 | TE-AP 18/22 Li-Solo       | Cordless All Purpose Saw      |    |
| 4326300_21043 | PT-C-EW-09 | TE-AP 18/22 Li-Solo       | Cordless All Purpose Saw      |    |
| 4514114_11018 | PT-C-EW-11 | TE-CL 18/2000 LiAC - Solo | Cordless Light                |    |
| 4514115_11019 | PT-C-EW-11 | TC-CL 18/1800 Li - Solo   | Cordless Light                |    |
| 4514145_11019 | PT-C-EW-11 | TE-CL 18/2500 LiAC-solo   | Cordless Light                |   |
| 4514130_21041 | PT-C-EW-11 | TC-CL 18 Li H-Solo        | Cordless Light                |  |
| 4514180_21013 | PT-C-EW-11 | TE-CL 18/1000 S Li - Solo | Cordless Light                |  |
| 4465170_21020 | PT-C-EW-12 | TC-MG 18 Li-Solo          | Cordless Multifunctional Tool |  |
| 4465160_21043 | PT-C-EW-12 | VARRITO                   | Cordless Multifunctional Tool |  |
| 4331210_21021 | PT-C-EW-13 | TP-CS 18/190 Li BL - Solo | Cordless Circular Saw         |  |
| 4331207_21021 | PT-C-EW-13 | TE-CS 18/165-1 Li - Solo  | Cordless Circular Saw         |  |
| 4331220_21032 | PT-C-EW-13 | TE-CS 18/150 Li - Solo    | Cordless Circular Saw         |  |

|               |            |                              |                          |   |
|---------------|------------|------------------------------|--------------------------|---|
| 4321200_21031 | PT-C-EW-14 | TE-JS 18/80 Li-Solo          | Cordless Jig Saw         |     |
| 4321260_21011 | PT-C-EW-14 | TP-JS 18/135 Li BL - Solo    | Cordless Jig Saw         |    |
| 4321209_21031 | PT-C-EW-14 | TC-JS 18 Li - Solo           | Cordless Jig Saw         |    |
| 4513926_21020 | PT-C-EW-15 | TE-CD 18/48 Li-i-Solo        | Cordless Impact Drill    |    |
| 4514205_21010 | PT-C-EW-15 | TP-CD 18/60 Li-i BL Solo     | Cordless Impact Drill    |    |
| 4513860_21041 | PT-C-EW-15 | TP-CD 18 Li-i Brushless-Solo | Cordless Impact Drill    |    |
| 4513942_21032 | PT-C-EW-15 | TP-CD 18/50 Li-i BL-Solo     | Cordless Impact Drill    |    |
| 4460708_21020 | PT-C-EW-16 | TE-OS 18/150 Li Solo         | Cordless Multiple Sander |   |
| 4431130_11017 | PT-C-EW-17 | TC-AG 18/115 Li-Solo         | Cordless Angle Grinder   |  |
| 4431165_21011 | PT-C-EW-17 | TE-AG 18/115 Q Li Solo       | Cordless Angle Grinder   |  |
| 4431110_21041 | PT-C-EW-17 | TE-AG 18/115 Li-Solo         | Cordless Angle Grinder   |  |
| 4431155_21012 | PT-C-EW-17 | TP-AG 18/125 CE Q Li - Solo  | Cordless Angle Grinder   |  |
| 4431144_21053 | PT-C-EW-17 | AXXIO 18/150                 | Cordless Angle Grinder   |  |
| 4431150_21043 | PT-C-EW-17 | AXXIO 18/115 Q               | Cordless Angle Grinder   |  |
| 4431140_21064 | PT-C-EW-17 | AXXIO 18/125                 | Cordless Angle Grinder   |  |

|               |            |                           |                            |   |
|---------------|------------|---------------------------|----------------------------|---|
| 4431151_21054 | PT-C-EW-17 | AXXIO 18/125 Q            | Cordless Angle Grinder     |     |
| 4460720_11018 | PT-C-EW-18 | TE-OS 18/230 Li Solo      | Cordless Orbital Sander    |    |
| 4460725_11018 | PT-C-EW-18 | TC-OS 18/187 Li Solo      | Cordless Orbital Sander    |    |
| 4514160_21011 | PT-C-EW-30 | TE-DA 18/760 Li Solo      | Cordless Drain Cleaner     |    |
| 4257785_21034 | PT-C-EW-45 | FIXETTO 18/40 S           | Cordless Tacker            |    |
| 4522200_11018 | PT-C-EW-47 | TE-CG 18 Li - Solo        | Cordless Hot Glue Gun      |    |
| 3408001_11017 | PT-C-EW-49 | TE-CB 18/180 Li-Solo      | Cordless Blower            |    |
| 4462010_21031 | PT-C-EW-51 | TE-RS 18 Li-Solo          | Cordless Rotating Sander   |  |
| 4345400_11019 | PT-C-EW-56 | TE-PL 18/82 Li - Solo     | Cordless Planer            |  |
| 4520500_11019 | PT-C-EW-58 | TE-HA 18 Li - Solo        | Cordless Hot Air Gun       |  |
| 4466270_21011 | PT-C-EW-60 | TP-BS 18/457 Li BL - Solo | Cordless Belt Sander       |  |
| 4513960_21023 | PT-C-EW-61 | TE-ID 18 Li - Solo        | Cordless Hammer Drill      |  |
| 4257790_21010 | PT-C-EW-63 | TE-CN 18 Li - Solo        | Cordless Nailer            |  |
| 4257795_21011 | PT-C-EW-63 | FIXETTO 18/50 N           | Cordless Nailer            |  |
| 4331100_21022 | PT-C-EW-64 | TE-CS 18/89 Li - Solo     | Cordless Mini Circular Saw |  |

|               |            |                            |                                |   |
|---------------|------------|----------------------------|--------------------------------|---|
| 4350412_21011 | PT-C-EW-65 | TP-ET 18 Li BL - Solo      | Cordless Palm Router           |     |
| 4350630_21011 | PT-C-EW-71 | TE-BJ 18 Li - Solo         | Cordless Biscuit Joiner        |    |
| 4350411_21023 | PT-C-EW-72 | TP-RO 18 Li BL - Solo      | Cordless Router                |    |
| 4460731_21012 | PT-C-EW-75 | TE-OS 18/113 Li - Solo     | Cordless Palm Sander           |    |
| 4350800_21013 | PT-C-EW-76 | TP-MA 36/30 Li BL - Solo   | Cordless Wall Liner            |    |
| 4419360_21012 | PT-C-EW-82 | TE-MT 18/34 Li Solo        | Cl.Grind./Engraving Tool(stat) |    |
| 4468000_21013 | PT-C-EW-84 | TP-BR 18/32 Li BL - Solo   | Cordless Sanding Roller        |    |
| 4510040_21041 | PT-C-EW-91 | TP-CW 18 Li Brushless-Solo | Cordless Impact Wrench         |  |
| 4510080_21011 | PT-C-EW-91 | IMPAXXO 18/230             | Cordless Impact Wrench         |  |
| 4510070_21023 | PT-C-EW-91 | IMPAXXO 18/450             | Cordless Impact Wrench         |  |
| 2347120_21031 | PT-C-RT-01 | TE-VC 18 Li-Solo           | Cordless Vacuum Cleaner        |  |
| 2347190_21011 | PT-C-RT-01 | TE-HV 18/06 Li - Solo      | Cordless Vacuum Cleaner        |  |
| 3437100_21023 | PT-C-RT-02 | BRILLIANTO                 | Cordless Window Cleaner        |  |
| 4020460_11017 | PT-CE-DT-1 | PRESSITO                   | Hybrid-Compressor              |  |
| 4020430_21011 | PT-CE-DT-1 | PRESSITO 18/25 Hybrid      | Hybrid-Compressor              |  |

|               |            |                               |                                |   |
|---------------|------------|-------------------------------|--------------------------------|---|
| 4514120_21021 | PT-Z-81    | TC-CP 18 Li USB-Solo          | USB-Battery-Adapter            |     |
| 4512102_11019 | PT-Z-83    | 2x2 Power X-Quattrocharger 4A | Charger                        |    |
| 4512103_11019 | PT-Z-83    | Power X-Fastcharger 4A        | Charger                        |    |
| 4512069_21020 | PT-Z-83    | Power X-Twincharger 3A        | Charger                        |    |
| 4512155_21012 | PT-Z-83    | Power X-Boostcharger 8A       | Charger                        |    |
| 2093301_11017 | GT-C-AZ-01 | CE-CB 18/254 Li-Solo          | Cordless Car Polisher          |    |
| 2093320_21021 | GT-C-AZ-05 | CE-CP 18/180 Li E-Solo        | Cl. Polishing/Sanding Machine  |    |
| 2071010_21010 | GT-C-AZ-06 | CE-CC 18 Li-Solo              | Cordless Car Air Compressor    |  |
| 3410382_21021 | GT-C-GT-01 | GC-CG 18/1 Li-Solo            | Cordless Grass Shear           |  |
| 3410313_21010 | GT-C-GT-04 | GE-CG 18/100 Li-Solo          | Cordless Grass- and Bush Shear |  |
| 3410370_21021 | GT-C-GT-04 | GC-CG 18 Li-Solo              | Cordless Grass- and Bush Shear |  |
| 3415410_11018 | GT-C-GT-06 | GE-US 18 Li-Solo              | Universal Spreader             |  |
| 4499940_21031 | GT-C-GT-20 | GE-CS 18 Li-Solo              | Cordless Chain Sharpener       |  |
| 3408290_21023 | GT-C-GT-25 | GE-GS 18/150 Li-Solo          | Cordless Pruning Saw           |  |
| 3408300_21032 | GT-C-GT-26 | GE-LS 18 Li-Solo              | Cordless Pruning Shears        |  |

|               |            |                               |                                |   |
|---------------|------------|-------------------------------|--------------------------------|---|
| 3425240_21012 | GT-C-GT-28 | GE-WS 18/10 Li-Solo           | Cordless Pressure Sprayer      |     |
| 4600020_21011 | GT-C-GT-38 | FORTEXXA 18/20 TH             | Top-handled Cordless Chain Saw |    |
| 2320120_21014 | GT-C-GT-45 | GC-OL 18/1500 Li-Solo         | Cordless Outdoor Light         |    |
| 4181560_21011 | GT-C-WT-01 | GE-SP 18 LL Li - Solo         | Cordless Clear Water Pump      |    |
| 4181500_21021 | GT-C-WT-01 | GE-SP 18 Li - Solo            | Cordless Clear Water Pump      |    |
| 4181580_21011 | GT-C-WT-04 | GE-DP 18/25 Li - Solo         | Cordless Dirt Water Pump       |    |
| 4181590_21012 | GT-C-WT-04 | GE-DP 18/25 LL Li - Solo      | Cordless Dirt Water Pump       |    |
| 3408310_21010 | GT-Z-31    | GE-PB 36/18 Li                | Battery Belt                   |  |
| 3410835_11016 | GT-Z-32    | Pruner Unit f. GE-HH18/45Li T | Multifunctional Tool-GT Acces. |  |
| 2070110_21010 | PT-C-EW-04 | CE-AP 18 Li-Solo              | Cordless Air Pump              |  |
| 3408035_21011 | PT-C-EW-48 | GE-CF 18/2200 Li - Solo       | Cordless Fan                   |  |