



Einhell

POWER X-CHANGE

Cordless Garden Pump

AQUINNA 18/28

Item No.: 4180440

Ident No.: 21012

Bar Code: 4006825668711

The Einhell cordless garden pump AQUINNA 18/28 is a powerful pump from the flexibly combinable Power X-Change family for cordless use. It has two power modes. In addition, the garden pump is equipped with a large water filler screw for filling and a drainage screw for frost protection. The slim and compact cordless pump is easily transported via the carrying handle and fixed to a permanent place of use with the help of the fastening holes. It is equipped with two robust metal threaded connections. Delivery does not include battery or charger.

Features & Benefits

- Member of the Power X-Change family, 1x 18 V battery required
- Power level selector: 2 power modes
- Practical water filler screw for easy filling
- Frost protection thanks to easy emptying via water drainage screw
- Overload protection protects the motor against overheating damage
- High-quality, durable metal suction and pressure connection
- Easy transport and high mobility thanks to carrying handle
- Pump base with bore for secure, permanent attachment
- Robust mechanical seal for long service life.
- Delivery does not include a battery or charger (sold separately)



Technical Data

- Max. delivery height	25 m
- Max. delivery pressure	2.5 bar
- Max. delivery rate	2800 l/h
- Max. suction height	6 m
- Max. water temperature	35 °C
- Pressure connection type	33,3 mm (G1 IG)
- Suction connection type	33,3 mm (R1 AG)

Logistic Data

- Product weight	2.55 kg
- Gross weight	3.4 kg
- Dimensions single packaging	476 mm x 185 mm x 250 mm
- Pieces per export carton	4 pcs
- Gross weight of export carton	14.5 kg
- Dimensions export carton	485 mm x 380 mm x 510 mm
- Container quantities (20"/40"/40"HC)	1152 pcs 2304 pcs 2880 pcs



Available as special accessories



Saugschlauch 4 m Messing
Pump Accessory
Item No.: 4173630
Bar Code: 4006825549133
Einhell Accessory



Saugschlauch 7 m Messing
Pump Accessory
Item No.: 4173640
Bar Code: 4006825549171
Einhell Accessory



Adapter 33,3 mm (1") AG
Pump Accessory
Item No.: 4173761
Bar Code: 4006825662733
Einhell Accessory



accessoryset suction & press (OFF)
Pump Accessory
Item No.: 4173763
Bar Code: 4006825663273
Einhell Accessory



PXC 18V 2,0Ah
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



PXC 18V 5,2Ah
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



PXC+ 18V 4-6Ah MULTI
Battery
Item No.: 4511502
Bar Code: 4006825644210
Einhell Accessory



PXC+ 18V 4,0Ah
Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory



2x 18V 4,0Ah PXC-Twinpack CB
Battery
Item No.: 4511489
Bar Code: 4006825638578
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



18V Battery Charger 3,0A - PXC
Charger
Item No.: 4514095
Bar Code: 4006825655292
Einhell Accessory



18V 4,0Ah PXC Starter Kit C1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



2x 5,2Ah & Twincharger Kit
PXC-Starter-Kit
Item No.: 4512108
Bar Code: 4006825652376
Einhell Accessory



Suction hose 4 m, Plastic
Pump Accessory
Item No.: 4173635
Bar Code: 4006825549058
Einhell Accessory



Suction hose 7 m, Plastic
Pump Accessory
Item No.: 4173645
Bar Code: 4006825549102
Einhell Accessory



accessoryset pressure side (OFF)
Pump Accessory
Item No.: 4173762
Bar Code: 4006825663266
Einhell Accessory



PXC 18V 3,0Ah
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory



PXC 18V 4,0Ah C01
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



PXC+ 18V 3,0Ah
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



PXC 18V 2,5Ah
Battery
Item No.: 4511516
Bar Code: 4006825650518
Einhell Accessory



PXC+ 18V 5-8Ah MULTI
Battery
Item No.: 4511600
Bar Code: 4006825665055
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack
Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory



2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



Power X-Car Charger 3A
Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



18V 2,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory



18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1
PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory



18V 4-6Ah & 6A Boostcharger
PXC-Starter-Kit
Item No.: 4512143
Bar Code: 4006825667653
Einhell Accessory

Battery-Running-Times

Battery Capacity	2.0 Ah	2.5 Ah	3.0 Ah	4.0 Ah	5.2 Ah	6.0 Ah	8.0 Ah
Performance	18 min	22 min	27 min	36 min	47 min	54 min	72 min
Max. running time per battery charge: ECO mode							
ECO mode: Longer battery life with reduced performance.							
Performance	14 min	17 min	20 min	28 min	36 min	40 min	56 min
Max. running time per battery charge: BOOST mode							
BOOST mode: Maximum performance with reduced battery life.							