



Einhell

POWER X-CHANGE

Cordless Garden Pump AQUINNA 18/30 F LED

Item No.: 4180430

Ident No.: 21012

Bar Code: 4006825668513

The Einhell cordless garden pump AQUINNA 18/30 F LED is a powerful pump from the flexibly combinable Power X-Change family for cordless use. The cordless pump can be equipped with one or two 18 V batteries via Double Runtime technology. If one battery is empty, the power supply automatically switches to the second battery. The pump has an energy-saving mode and a Boost mode. In addition, the garden pump is equipped with an LED charge level indicator, a dirt and water level indicator, a pre-filter, a non-return valve, a water fill and drainage screw, a carrying handle and fixing holes. Delivery does not include battery or charger.

Features & Benefits

- Member of the Power X-Change family, 1x 18 V battery required
- Double Runtime technology: 2 battery slots, double runtime
- Suitable for all Power X-Change batteries
- High pump performance combined with cordless freedom
- LED battery charge indicator directly on the device
- 2 power settings
- Pre-filter for protection against impurities in the inducted water
- Large water filler screw for easy commissioning
- Frost protection thanks to easy emptying via water drainage screw
- Vent screw ensures efficient suction
- Water level indicator – Determine water level at a glance
- Dirt indicator – quickly detect dirty filters
- Overload protection to protect the motor from overheating
- Carrying handle for easy transport
- Pump base with bore for secure, permanent attachment
- High-quality, durable metal suction and pressure connection
- Non-return valve for preventing water backflow
- Robust mechanical seal for long service life.
- Delivery does not include a battery or charger (sold separately)



Technical Data

- Max. delivery height	28 m
- Max. delivery pressure	2.8 bar
- Max. delivery rate	3000 l/h
- Max. suction height	6 m
- Max. water temperature	35 °C
- Pressure connection type	33,3 mm (G1 IG)
- Suction connection type	33,3 mm (R1 AG)

Logistic Data

- Product weight	3.9 kg
- Gross weight	5.2 kg
- Dimensions single packaging	528 mm x 234 mm x 315 mm
- Pieces per export carton	3 pcs
- Gross weight of export carton	16.8 kg
- Dimensions export carton	715 mm x 540 mm x 330 mm
- Container quantities (20"/40"/40"HC)	672 pcs 1386 pcs 1536 pcs



Available as special accessories



Saugschlauch 4 m Messing
Pump Accessory
Item No.: 4173630
Bar Code: 4006825549133
Einhell Accessory



Saugschlauch 7 m Messing
Pump Accessory
Item No.: 4173640
Bar Code: 4006825549171
Einhell Accessory



Adapter 33,3 mm (1") AG
Pump Accessory
Item No.: 4173761
Bar Code: 4006825662733
Einhell Accessory



accessoryset suction & press (OFF)
Pump Accessory
Item No.: 4173763
Bar Code: 4006825663273
Einhell Accessory



PXC 18V 2,0Ah
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



PXC 18V 5,2Ah
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



PXC+ 18V 4-6Ah MULTI
Battery
Item No.: 4511502
Bar Code: 4006825644210
Einhell Accessory



PXC+ 18V 4,0Ah
Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory



2x 18V 4,0Ah PXC-Twinpack CB
Battery
Item No.: 4511489
Bar Code: 4006825638578
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



18V Battery Charger 3,0A - PXC
Charger
Item No.: 4514095
Bar Code: 4006825655292
Einhell Accessory



18V 4,0Ah PXC Starter Kit C1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



2x 5,2Ah & Twincharger Kit
PXC-Starter-Kit
Item No.: 4512108
Bar Code: 4006825652376
Einhell Accessory



Suction hose 4 m, Plastic
Pump Accessory
Item No.: 4173635
Bar Code: 4006825549058
Einhell Accessory



Suction hose 7 m, Plastic
Pump Accessory
Item No.: 4173645
Bar Code: 4006825549102
Einhell Accessory



accessoryset pressure side (OFF)
Pump Accessory
Item No.: 4173762
Bar Code: 4006825663266
Einhell Accessory



PXC 18V 3,0Ah
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory



PXC 18V 4,0Ah C01
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



PXC+ 18V 3,0Ah
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



PXC 18V 2,5Ah
Battery
Item No.: 4511516
Bar Code: 4006825650518
Einhell Accessory



PXC+ 18V 5-8Ah MULTI
Battery
Item No.: 4511600
Bar Code: 4006825665055
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack
Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory



2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



Power X-Car Charger 3A
Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



18V 2,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory



18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1
PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory



18V 4-6Ah & 6A Boostcharger
PXC-Starter-Kit
Item No.: 4512143
Bar Code: 4006825667653
Einhell Accessory

Battery-Running-Times

Battery Capacity	2.0 Ah	2.5 Ah	3.0 Ah	4.0 Ah	5.2 Ah	6.0 Ah	8.0 Ah
Performance	19 min	23 min	28 min	38 min	48 min	56 min	76 min
Max. running time per battery charge: ECO mode - 1 battery							
ECO mode: Longer battery life with reduced performance.							
Performance	15 min	17 min	20 min	30 min	36 min	40 min	60 min
Max. running time per battery charge: BOOST mode - 1 battery							
BOOST mode: Maximum performance with reduced battery life.							
Performance	30 min	34 min	40 min	60 min	72 min	80 min	120 min
Max. running time per battery charge: BOOST mode - 2 batteries							
BOOST mode: Maximum performance with reduced battery life.							
Performance	38 min	46 min	56 min	76 min	96 min	112 min	152 min
Max. running time per battery charge: ECO mode - 2 batteries							
ECO mode: Longer battery life with reduced performance.							