Einhell

EXPERT

POWER X-CHANGE

Cordless Grass- and Bush Shear

GE-CG 18/100 Li T (1x 2,5Ah)

Item No.: 3410316

Ident No.: 21024

Bar Code: 4006825680829

The Einhell GE-CG 18/100 Li T (1x 2,5 Ah) cordless grass and shrub shears are a powerful member of the smart Power X-Change family. The grass cutting blade (100 mm) is ideal for lawn edges, while the laser-cut and diamond-ground shrub shear blades (200 mm) are perfect for trimming bushes and hedges. The blades can be exchanged without tools. In use, the Softgrip provides perfect handling and ergonomics. The covered gearbox housing protects against accidental contact with transmission oil. Included in the scope of delivery are a telescopic extension for particularly ergonomic appication as well as a 2.5 Ah Power X-Change battery and a charging device.

Features & Benefits

- Member of the Power X-Change family, 1x 18 V battery required
- Grass cutting blade, perfect for caring for lawn edges
- Shrub shear blade for hedge and bush care
- Easy and tool-free blade change
- Laser-cut and diamond-ground blades
- Includes telescopic extension for particularly ergonomic use
- Extension handle with 5 tilt positions
- Covered transmission housing protects against contact with transmission oil
- Softgrip provides optimal grip and ergonomics
- Delivery with 2.5 Ah Power X-Change battery and charging device

Technical Data

- Cutting width with grass shear knife	100 mm
- Cutting length with shrub cutting knife	200 mm
- Cutting thickness with shrub cutting knife	8 mm
- Spacing between teeth of shrub cutting knife	8 mm
- Accumulator	18 V | 2500 mAh | Li-Ion
- Number of accumulators	1 Pieces



Logistic Data

- Product weight	0 kg
- Gross weight single packaging	3.9 kg
- Dimensions single packaging	191 x 136 x 935 mm
- Pieces per export carton	4 Pieces
- Gross weight export carton	15.6 kg
- Dimensions export carton	950 x 400 x 288 mm
- Container quantity (20"/40"/40"HC)	1032 | 2128 | 2376

Illustrations can contain accessories, which are not included in standard extent of delivery
Illustration similar (in design), production-wise modifications reserved
GS mark belongs to the product itself only, excluded accessory

Available as special accessories

18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory

2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory

Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory

2x 4,0Ah & Twincharger Kit 1
PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory

PXC Battery Mounting Gadget
PXC-Battery Accessory
Item No.: 4514155
Bar Code: 4006825658774
Einhell Accessory

18V 4-6Ah & 6A Boostcharger
PXC-Starter-Kit
Item No.: 4512143
Bar Code: 4006825667653
Einhell Accessory

5,2 Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory

18V 4Ah PXC Plus Twinpack
Battery
Item No.: 4511629
Bar Code: 4006825673685
Einhell Accessory

18V Battery Charger 3,0A - PXC
Charger
Item No.: 4514095
Bar Code: 4006825655292
Einhell Accessory

PXC+ 18V 4,0Ah
Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory

PXC 18V 3,0Ah
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory

2,0 Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory

4-6 Ah Multi-Ah Power X-Change
Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210

18V 4,0Ah PXC Starter Kit A1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory

Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory

Power X-Car Charger 3A
Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory

2x 18V 5,2Ah PXC-Twinpack
Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory

2x18V 4,0Ah PXC-Twinpack CB
A1
Battery
Item No.: 4511489
Bar Code: 4006825638578

Power X-Boostcharger 8A
Charger
Item No.: 4512155
Bar Code: 4006825670554
Einhell Accessory

PXC+ 18V 5-8Ah MULTI
Battery
Item No.: 4511600
Bar Code: 4006825665055
Einhell Accessory

18V 3Ah PXC Plus Twinpack
Battery
Item No.: 4511631
Bar Code: 4006825673692
Einhell Accessory

PXC+ 18V 4,0Ah SEALED
Battery
Item No.: 4511627
Bar Code: 4006825673227
Einhell Accessory

PXC+ 18V 3,0Ah SEALED
Battery
Item No.: 4511618
Bar Code: 4006825672794
Einhell Accessory

3,0 Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory

4,0 Ah Power X-Change
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory

Illustrations can contain accessories, which are not included in standard extent of delivery
Illustration similar (in design), production-wise modifications reserved
GS mark belongs to the product itself only, excluded accessory