



Einhell

PROFESSIONAL



Robot Lawn Mower

FREELEXO SMART 750

Item No.: 3413811


Ident No.: 21033

Bar Code: 400682566543

The robotic mower FREELEXO SMART 750 is part of the Power X-Change family, so the 3.0 Ah lithium-ion battery can be combined with all PXC devices. Thanks to the smart function, the robotic mower can automatically determine the mowing times according to lawn size and weather conditions. It establishes a mobile internet connection, can be controlled from anywhere and connected to other Einhell SMART devices via an app. In addition, the multi-zone/spot mower is equipped with a cutting height adjustment, a PIN anti-theft device and with rain, shock, tilt and lifting sensors, through which it can handle gradients of up to 35%. Returns to the charging station automatically. Delivery incl. installation equipment for 750 m² lawn area.

Features & Benefits

- Member of the Power X-Change family, 1x 18V battery required
- Brushless motor - more power and longer running time
- PurePOWER Brushless - 10 year motor warranty after registration
- SMART: Mowing time calculation according to garden size & weather
- SMART: Controllable from anywhere thanks to internet connection
- SMART: Networkable with all Einhell SMART devices
- Individual robotic mower control via app possible
- Mowing times can be programmed depending on the weather or day
- Intuitive keypad with LCD display
- Sensors: Rain sensor and bump, tilt and lift sensors
- PIN code for theft protection
- Multi-zone mowing for complex gardens
- Mowing programme for secondary areas
- Spot mowing and edge mowing mode
- ECO mode of the charging station
- Cutting height adjustment (20-60 mm)
- Suitable for inclines up to 35°
- Automatic return to charging station with charging process
- Incl. installation equipment for 750 m² lawn area
- Incl. 1x Power X-Change 3.0 Ah Plus battery pack
- Incl. 175 m boundary wire and 245 fixing hooks
- Incl. 3 spare blades and 4 connecting clamps



Technical Data

- | | |
|-----------------------------|--------------------------|
| - Power | 18 V |
| - Accumulator | 18 V 3000 mAh Li-Ion |
| - Cutting width | 18 cm |
| - Slope | 35 % |
| - Cutting height adjustment | 20 mm - 60 mm |
| - Recommended area | 750 m ² |
| - Perimeter wire | 175 m |
| - Hooks | 245 Pieces |
| - Spare blades | 3 |
| - Connecting clamps | 4 Pieces |

Logistic Data

| | |
|--|--------------------|
| - Product weight (kg) | 8.9 |
| - Gross weight (kg) | 16.7 |
| - Dimensions single packaging | 702 x 458 x 320 mm |
| - Pieces per export carton | 1 Pieces |
| - Gross weight of export carton | 17.5 kg |
| - Dimensions export carton | 700 x 450 x 335 mm |
| - Container quantities (20"/40"/40"HC) | 294 602 688 |

Available as special accessories



4-6 Ah Multi-Ah Power X-Change Plus Battery
Item No.: 4511502
Bar Code: 4006825644210



4,0 Ah Power X-Change Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



Perimeter wire 50 m
Robot Lawn Mower Accessory
Item No.: 3414021
Bar Code: 4006825648782
Einhell Accessory



Fastening hook 100 psc
Robot Lawn Mower Accessory
Item No.: 3414023
Bar Code: 4006825648805
Einhell Accessory



Power X-Fastcharger 4A Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



Power X-Twincharger 3A Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



18V 3,0 Ah Power-X-Change 1 Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1 PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory



5,2Ah & 4A Fastcharger PXC-Starter-Kit
Item No.: 4512114
Bar Code: 4006825656787
Einhell Accessory



Repair Kit
Robot Lawn Mower Accessory
Item No.: 3414026
Bar Code: 4006825657968
Einhell Accessory



Power X-Caravan Charger 3A Charger
Item No.: 4512136
Bar Code: 4006825664010
Einhell Accessory



18V 4-6Ah & 6A Boostcharger PXC-Starter-Kit
Item No.: 4512143
Bar Code: 4006825667653
Einhell Accessory



2,0 Ah Power X-Change Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



18V 2,5Ah PXC Starter Kit PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



Spare blades 12 psc
Robot Lawn Mower Accessory
Item No.: 3414020
Bar Code: 4006825648775
Einhell Accessory



Connecting clamps 4 psc
Robot Lawn Mower Accessory
Item No.: 3414022
Bar Code: 4006825648799
Einhell Accessory



2x2 Power X-Quattrocharger 4A Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



2x 5,2Ah & Twincharger Kit PXC-Starter-Kit
Item No.: 4512108
Bar Code: 4006825652376
Einhell Accessory



robot lawn mower garage
Robot Lawn Mower Accessory
Item No.: 3414024
Bar Code: 4006825654417
Einhell Accessory



Power X-Car Charger 3A Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory



Cleaning Kit
Robot Lawn Mower Accessory
Item No.: 3414025
Bar Code: 4006825657951
Einhell Accessory



3,0 Ah Power X-Change Plus Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



18V 5-8Ah Multi-Ah PXC Plus Battery
Item No.: 4511600
Bar Code: 4006825665055
Einhell Accessory



5,2 Ah Power X-Change Plus Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



18V 2,0Ah PXC Starter Kit PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory



18V Battery Charger 3,0A - PXC Charger
Item No.: 4514095
Bar Code: 4006825655292
Einhell Accessory