



Einhell

ACCESSORY

System Carrying Case

E-Case S-F

Item No.: 4540011

Ident No.: 21034

Bar Code: 4006825653991

Features & Benefits

- Member of the modular E-Case system from Einhell
- System case for storing/transporting machines & tools
- Locking system for securely connecting stacked cases
- Easy storage and transport of stacked cases
- Sturdy construction for loads up to 25 kg
- Foldable, ergonomic handle for comfortable carrying
- Ease of use: Stacked cases can be opened
- Heat-resistant and impact-resistant
- Made of high-quality polypropylene
- Splash-proof design
- Can be equipped with a padlock as an anti-theft device
- Includes foam insert to protect sensitive devices



Technical Data

- Inner dimensions (E-Case S with foam 420 x 280 x 95 mm insert)

Logistic Data

- | | |
|--|--------------------|
| - Product weight (kg) | 1.72 |
| - Gross weight (kg) | 1.84 |
| - Dimensions single packaging | 440 x 327 x 128 mm |
| - Pieces per export carton | 4 Pieces |
| - Gross weight of export carton | 8.46 kg |
| - Dimensions export carton | 465 x 355 x 565 mm |
| - Container quantities (20"/40"/40"HC) | 1232 2576 2816 |



CONNECTABLE



EASY TRANSPORTATION



MAX. 25 KG




INCL.




OBJECTS NOT INCL.

E-CASE-SYSTEM



CONNECTABLE



FOAM INLAY



max. 25 kg

Available as special accessories



Plastic Compartments Set
System Carrying Case
Item No.: 4540012
Bar Code: 4006825654004
Einhell Accessory



Grid Foam Set
System Carrying Case
Item No.: 4540013
Bar Code: 4006825656749
Einhell Accessory

The following Power X-Change devices fit into E-Case S-F

(1x Power X-Charger + 2x 3,0 Ah PXC Plus Akku)



Item no	Tpg code	Description	Description 2	Product picture
3408017_21010	PT-C-BT-02	TC-RA 18 Li BT - Solo	Cordless Radio	
1091310_21014	PT-C-BT-06	TE-ES 18/150/1 Li-C-Solo	Cordless Energy Station	
1091310_21014	PT-C-BT-06	TE-ES 18/150/1 Li-C-Solo	Cordless Energy Station	
1091320_21014	PT-C-BT-06	TC-ES 18/150/1 Li-Solo	Cordless Energy Station	
1091320_21014	PT-C-BT-06	TC-ES 18/150/1 Li-Solo	Cordless Energy Station	
4514150_11019	PT-C-BT-10	TC-SR 18 Li BT - Solo	Cordless Speaker	
4513812_21021	PT-C-EW-01	TE-HD 18 Li-Solo	Cordless Rotary Hammer	
4513970_21023	PT-C-EW-01	TE-HD 18/12 Li - Solo	Cordless Rotary Hammer	
4514107_21015	PT-C-EW-01	TC-BH 18-3B Li - Solo	Cordless Rotary Hammer	
4513925_11018	PT-C-EW-02	TE-CD 18/40 Li-Solo	Cordless Drill	
4513997_21010	PT-C-EW-02	TE-CD 18/40 Li BL - Solo	Cordless Drill	
4514210_21010	PT-C-EW-02	TP-CD 18/60 Li BL - Solo	Cordless Drill	
4513927_21021	PT-C-EW-02	TC-CD 18/35 Li - Solo	Cordless Drill	

4513887_21032	PT-C-EW-02	TP-CD 18/50 Li BL-Solo	Cordless Drill	
4514335_21014	PT-C-EW-02	TP-CD 18/70-C Li BL - Solo	Cordless Drill	
4514345_21015	PT-C-EW-02	TE-CD 18/50 Li - Solo	Cordless Drill	
4514365_21015	PT-C-EW-02	TC-CD 18/38 Li - Solo	Cordless Drill	
4510034_21021	PT-C-EW-06	TE-CI 18/1 Li-Solo	Cordless Impact Driver	
4510085_21013	PT-C-EW-06	TP-CI 18/220 Li BL - Solo	Cordless Impact Driver	
4510095_21014	PT-C-EW-06	TP-CI 18/250-C Li BL - Solo	Cordless Impact Driver	
4510044_21014	PT-C-EW-06	TE-CI 18/160 Li-Solo	Cordless Impact Driver	
4326290_21010	PT-C-EW-09	TE-AP 18/26 Li - Solo	Cordless All Purpose Saw	
4326315_21013	PT-C-EW-09	TE-AP 18/13 Li - Solo	Cordless All Purpose Saw	
4326315_21013	PT-C-EW-09	TE-AP 18/13 Li - Solo	Cordless All Purpose Saw	
4326300_21043	PT-C-EW-09	TE-AP 18/22 Li-Solo	Cordless All Purpose Saw	
4326300_21043	PT-C-EW-09	TE-AP 18/22 Li-Solo	Cordless All Purpose Saw	
4326295_21014	PT-C-EW-09	TP-AP 18/32 Li BL - Solo	Cordless All Purpose Saw	
4432010_21014	PT-C-EW-10	TE-UC 18/6 Li - Solo	Cordless Multicutter	

4432010_21014	PT-C-EW-10	TE-UC 18/6 Li - Solo	Cordless Multicutter	
4514145_11019	PT-C-EW-11	TE-CL 18/2500 LiAC-solo	Cordless Light	
4514091_21011	PT-C-EW-11	TC-AL 18 Li - Solo	Cordless Light	
4514180_21013	PT-C-EW-11	TE-CL 18/1000 S Li - Solo	Cordless Light	
4514180_21013	PT-C-EW-11	TE-CL 18/1000 S Li - Solo	Cordless Light	
4514115_21024	PT-C-EW-11	TC-CL 18/1800 Li - Solo	Cordless Light	
4514130_21055	PT-C-EW-11	TC-CL 18 Li H-Solo	Cordless Light	
4514130_21055	PT-C-EW-11	TC-CL 18 Li H-Solo	Cordless Light	
4514152_21015	PT-C-EW-11	TE-CL 18/2500 Li - Solo	Cordless Light	
4465170_21020	PT-C-EW-12	TC-MG 18 Li-Solo	Cordless Multifunctional Tool	
4465170_21020	PT-C-EW-12	TC-MG 18 Li-Solo	Cordless Multifunctional Tool	
4465195_21013	PT-C-EW-12	TE-MG 18/1 Li - Solo	Cordless Multifunctional Tool	
4465195_21013	PT-C-EW-12	TE-MG 18/1 Li - Solo	Cordless Multifunctional Tool	
4465197_21015	PT-C-EW-12	TC-MFW 18 Li-Solo	Cordless Multifunctional Tool	
4465197_21015	PT-C-EW-12	TC-MFW 18 Li-Solo	Cordless Multifunctional Tool	

4465160_21055	PT-C-EW-12	VARRITO	Cordless Multifunctional Tool	
4465160_21055	PT-C-EW-12	VARRITO	Cordless Multifunctional Tool	
4465190_21025	PT-C-EW-12	TP-MG 18 Li BL - Solo	Cordless Multifunctional Tool	
4331230_21014	PT-C-EW-13	TE-CS 18/165-2 Li - Solo	Cordless Circular Saw	
4331240_21014	PT-C-EW-13	TP-CS 18/136-C Li BL - Solo	Cordless Circular Saw	
4321260_21011	PT-C-EW-14	TP-JS 18/135 Li BL - Solo	Cordless Jig Saw	
4321209_21031	PT-C-EW-14	TC-JS 18 Li - Solo	Cordless Jig Saw	
4321270_21013	PT-C-EW-14	TE-JS 18/100 Li - Solo	Cordless Jig Saw	
4321270_21013	PT-C-EW-14	TE-JS 18/100 Li - Solo	Cordless Jig Saw	
4513926_21020	PT-C-EW-15	TE-CD 18/48 Li-i-Solo	Cordless Impact Drill	
4514205_21010	PT-C-EW-15	TP-CD 18/60 Li-i BL Solo	Cordless Impact Drill	
4513860_21041	PT-C-EW-15	TP-CD 18 Li-i Brushless-Solo	Cordless Impact Drill	
4513860_21041	PT-C-EW-15	TP-CD 18 Li-i Brushless-Solo	Cordless Impact Drill	
4513942_21032	PT-C-EW-15	TP-CD 18/50 Li-i BL-Solo	Cordless Impact Drill	
4514315_21013	PT-C-EW-15	TP-CD 18/70 Li-i BL - Solo	Cordless Impact Drill	

4514019_21014	PT-C-EW-15	TE-CD 18/50 Li-i-Solo	Cordless Impact Drill	
4514340_21014	PT-C-EW-15	TP-CD 18/70-C Li-i BL - Solo	Cordless Impact Drill	
4514346_21015	PT-C-EW-15	TE-CD 18/52 Li-i - Solo	Cordless Impact Drill	
4514234_21015	PT-C-EW-15	TC-SBS 18 Li - Solo	Cordless Impact Drill	
4431168_21013	PT-C-EW-17	TE-AG 18/125-2 Li - Solo	Cordless Angle Grinder	
4431168_21013	PT-C-EW-17	TE-AG 18/125-2 Li - Solo	Cordless Angle Grinder	
4431175_21013	PT-C-EW-17	TP-AG 18/125 F Li BL - Solo	Cordless Angle Grinder	
4431175_21013	PT-C-EW-17	TP-AG 18/125 F Li BL - Solo	Cordless Angle Grinder	
4431150_21043	PT-C-EW-17	AXXIO 18/115 Q	Cordless Angle Grinder	
4431154_21024	PT-C-EW-17	AXXIO 18/115	Cordless Angle Grinder	
4431144_21064	PT-C-EW-17	AXXIO 18/150	Cordless Angle Grinder	
4431140_21064	PT-C-EW-17	AXXIO 18/125	Cordless Angle Grinder	
4431140_21064	PT-C-EW-17	AXXIO 18/125	Cordless Angle Grinder	
4431151_21054	PT-C-EW-17	AXXIO 18/125 Q	Cordless Angle Grinder	
4431130_21034	PT-C-EW-17	TC-AG 18/115 Li-Solo	Cordless Angle Grinder	

4431130_21034	PT-C-EW-17	TC-AG 18/115 Li-Solo	Cordless Angle Grinder	
4431110_21054	PT-C-EW-17	TE-AG 18/115 Li-Solo	Cordless Angle Grinder	
4431155_21024	PT-C-EW-17	TP-AG 18/125 CE Q Li - Solo	Cordless Angle Grinder	
4431160_21024	PT-C-EW-17	AXXIO 36/230 Q	Cordless Angle Grinder	
4514410_21024	PT-C-EW-17	TC-AG 18/8500 Li - Solo	Cordless Angle Grinder	
4431161_21015	PT-C-EW-17	TP-AG 36/230-22 Li BL - Solo	Cordless Angle Grinder	
4460725_11018	PT-C-EW-18	TC-OS 18/187 Li Solo	Cordless Orbital Sander	
4257785_21044	PT-C-EW-45	FIXETTO 18/40 S	Cordless Tacker	
4257785_21044	PT-C-EW-45	FIXETTO 18/40 S	Cordless Tacker	
4522200_11018	PT-C-EW-47	TE-CG 18 Li - Solo	Cordless Hot Glue Gun	
4520500_11019	PT-C-EW-58	TE-HA 18 Li - Solo	Cordless Hot Air Gun	
4513960_21023	PT-C-EW-61	TE-ID 18 Li - Solo	Cordless Hammer Drill	
4257790_21010	PT-C-EW-63	TE-CN 18 Li - Solo	Cordless Nailer	
4257800_21014	PT-C-EW-63	TE-CN 18/32 Li - Solo	Cordless Nailer	
4257800_21014	PT-C-EW-63	TE-CN 18/32 Li - Solo	Cordless Nailer	

4257795_21024	PT-C-EW-63	FIXETTO 18/50 N	Cordless Nailer	
4257795_21024	PT-C-EW-63	FIXETTO 18/50 N	Cordless Nailer	
4350412_21011	PT-C-EW-65	TP-ET 18 Li BL - Solo	Cordless Palm Router	
4514320_21024	PT-C-EW-73	TE-RW 18/60 Li-Solo	Cordless Ratchet Wrench	
4461000_21012	PT-C-EW-74	TE-BF 18 Li - Solo	Cordless Belt File	
4460731_21012	PT-C-EW-75	TE-OS 18/113 Li - Solo	Cordless Palm Sander	
4331400_21013	PT-C-EW-80	TP-PS 18/165 Li BL - Solo	Cordless Plunge Cut Saw	
4432000_21013	PT-C-EW-83	TP-CO 18/76-C Li BL - Solo	Cordless Cut-Off Grinder	
4432000_21013	PT-C-EW-83	TP-CO 18/76-C Li BL - Solo	Cordless Cut-Off Grinder	
4468000_21013	PT-C-EW-84	TP-BR 18/32 Li BL - Solo	Cordless Sanding Roller	
4468000_21013	PT-C-EW-84	TP-BR 18/32 Li BL - Solo	Cordless Sanding Roller	
4520400_21014	PT-C-EW-89	TE-SI 18/480 Li E - Solo	Cordless Soldering Iron	
4520400_21014	PT-C-EW-89	TE-SI 18/480 Li E - Solo	Cordless Soldering Iron	
4510040_21041	PT-C-EW-91	TP-CW 18 Li Brushless-Solo	Cordless Impact Wrench	
4510040_21041	PT-C-EW-91	TP-CW 18 Li Brushless-Solo	Cordless Impact Wrench	

4510070_21023	PT-C-EW-91	IMPAXXO 18/450	Cordless Impact Wrench	
4510080_21023	PT-C-EW-91	IMPAXXO 18/230	Cordless Impact Wrench	
4510090_21014	PT-C-EW-91	TP-CW 18/260-C Li BL - Solo	Cordless Impact Wrench	
4510090_21014	PT-C-EW-91	TP-CW 18/260-C Li BL - Solo	Cordless Impact Wrench	
4510065_21014	PT-C-EW-91	TP-CW 18/750-C Li BL - Solo	Cordless Impact Wrench	
4510065_21014	PT-C-EW-91	TP-CW 18/750-C Li BL - Solo	Cordless Impact Wrench	
4510055_21014	PT-C-EW-91	TP-CW 18/350-C Li BL - Solo	Cordless Impact Wrench	
4510055_21014	PT-C-EW-91	TP-CW 18/350-C Li BL - Solo	Cordless Impact Wrench	
4510048_21014	PT-C-EW-91	TP-CW 18/270 Li BL-Solo	Cordless Impact Wrench	
4510052_21015	PT-C-EW-91	TC-SGS 18 Li 3N - Solo	Cordless Impact Wrench	
4510052_21015	PT-C-EW-91	TC-SGS 18 Li 3N - Solo	Cordless Impact Wrench	
4514148_21013	PT-Z-81	TC-CP 18 Li USB A/C-Solo	USB-Battery-Adapter	
4512103_11019	PT-Z-83	Power X-Fastcharger 4A	Charger	
4512069_21020	PT-Z-83	Power X-Twincharger 3A	Charger	
4512155_21012	PT-Z-83	Power X-Boostcharger 8A	Charger	

4512169_21015	PT-Z-83	PXC-Fastcharger 3,5A	Charger	
2071010_21010	GT-C-AZ-06	CE-CC 18 Li-Solo	Cordless Car Air Compressor	
2071025_21014	GT-C-AZ-06	CE-CC 18/23 D Li-Solo	Cordless Car Air Compressor	
2071025_21014	GT-C-AZ-06	CE-CC 18/23 D Li-Solo	Cordless Car Air Compressor	
3410382_21021	GT-C-GT-01	GC-CG 18/1 Li-Solo	Cordless Grass Shear	
3410313_21010	GT-C-GT-04	GE-CG 18/100 Li-Solo	Cordless Grass- and Bush Shear	
3410370_21021	GT-C-GT-04	GC-CG 18 Li-Solo	Cordless Grass- and Bush Shear	
3408290_21023	GT-C-GT-25	GE-GS 18/150 Li-Solo	Cordless Pruning Saw	
3408300_21032	GT-C-GT-26	GE-LS 18 Li-Solo	Cordless Pruning Shears	
3408320_21013	GT-C-GT-26	GP-LS 18/28 Li BL-Solo	Cordless Pruning Shears	
3425240_21012	GT-C-GT-28	GE-WS 18/10 Li-Solo	Cordless Pressure Sprayer	
4600065_21015	GT-C-GT-40	GC-AAKS 18 Li - Solo	Cordless Pruning Chain Saw	
2320120_21014	GT-C-GT-45	GC-OL 18/1500 Li-Solo	Cordless Outdoor Light	
2320120_21014	GT-C-GT-45	GC-OL 18/1500 Li-Solo	Cordless Outdoor Light	
3408310_21010	GT-Z-31	GE-PB 36/18 Li	Battery Belt	

2070110_21010	PT-C-EW-04	CE-AP 18 Li-Solo	Cordless Air Pump	
3408061_21013	PT-C-EW-48	GC-CF 18/110 Li-Solo	Cordless Fan	