







FORTEXXA 18/35 - Solo

Item No.: 4600013

Ident No.: 21014

Bar Code: 4006825682458

The Einhell cordless chainsaw FORTEXXA 18/35 - Solo is a member of the Power X-Change family and is driven by an Einhell PurePOWER Brushless motor for more power and longer running time. Once you register online, the brushless motor has a 10-year guarantee. The tool is equipped with an OREGON quality guide bar and chain, and features tool-free chain tensioning/replacement. A chain catcher and kickback protection with instant chain brake ensure safety, which automatic chain lubrication takes care of maintenance. The claw stop is of metal construction. The chain speed can be switched between full power (8.9 m/s) and ECO mode (6 m/s). Battery and charger not included.

WER CHANGE

#### Features & Benefits

- Member of the Power X-Change family; 1x18 V battery required
- Brushless motor more power and longer run time
- Brushless 10-year warranty on motor after registration
- OREGON quality guide bar and chain
- Chain speed can be adjusted according to the application
- Select between full power (8.9 m/s) and ECO mode (6 m/s)
- Kickback protection with instant chain brake
- Tool-free chain tensioning and chain replacement
- Ergonomic handle with soft grip
- Claw stop of metal construction
- Large oil-fill opening
- Automatic chain lubrication
- Chain catcher pin
- Recommendation for optimal results: 6.0 Ah battery and above
- Comes without battery or charger (available separately)

#### **Technical Data**

- Sword length 350 mm 33 cm - Max. cutting length - Chain cutting speed 8.9 m/s 160 mL - Oil tank capacity

# **Logistic Data**

- Product weight (kg) 4.03 kg - Gross weight (kg) 5.38 kg

- Dimensions single packaging 255 x 477 x 282 mm

- Pieces per export carton 4 Pieces - Gross weight export carton 23.75 kg

- Dimensions Export Carton 580 x 500 x 535 mm - Container quantity (20"/40"/40"HC) 656 | 1376 | 1720





















## Available as special accessories



Spare Bar 35cm 1,1 Chain Saw Accessory Item No.: 4500197 Bar Code: 4006825632248 Einhell Accessory



2x2 Power X-Quattrocharger 4A Charger Item No.: 4512102

Bar Code: 4006825649536 **Einhell Accessory** 



Power X-Twincharger 3A Charger Item No.: 4512069 Bar Code: 4006825629729 **Einhell Accessory** 

Power X-Caravan Charger 3A Charger Item No.: 4512136 Bar Code: 4006825664010 Einhell Accessory



Power X-Boostcharger 8A Charger Item No.: 4512155 Bar Code: 4006825670554 Einhell Accessory





18V Battery Charger 3,0A - PXC

Charger Item No.: 4514095 Bar Code: 4006825655292

Einhell Accessory



Spare Chain 35cm 1,1 52T 3/8 Chain Saw Accessory Item No.: 4500196 Bar Code: 4006825632231 Einhell Accessory



Power X-Fastcharger 4A Charger Item No.: 4512103 Bar Code: 4006825650228 Einhell Accessory



Power X-Car Charger 3A Charger Item No.: 4512113 Bar Code: 4006825655377 Einhell Accessory



18V 4-6Ah & 6A Boostcharger PXC-Starter-Kit Item No.: 4512143 Bar Code: 4006825667653 Einhell Accessory



PXC+ 18V 5-8Ah MULTI Battery Item No.: 4511600 Bar Code: 4006825665055 Einhell Accessory



4-6 Ah Multi-Ah Power X-Change Plus Battery Item No.: 4511502 Bar Code: 4006825644210

### **Battery-Running-Times**

One Battery for All	sawing <sup>1</sup>	sawing <sup>2</sup>
	(pieces)	(pieces)
1.5 Ah	53	59
2.0 Ah	70	78
2.5 Ah	88	98
3.0 Ah	105	117
4.0 Ah	140	156
5.2 Ah	182	203
6.0 Ah	210	234
8.0 Ah	280	312

#### Test setup:

1) wood - scantling 70x70 mm - BOOST

2) wood - scantling 70x70 mm - ECO