



# Einhell

# EXPERT

## POWER X-CHANGE

### Cordless Sliding Mitre Saw

### TE-SM 36/10 L Li-Solo

Item No.: 4300885

Ident No.: 21011

Bar Code: 4006825665239

The Einhell TE-SM 36/10 L Li-Solo cordless sliding mitre saw, as a member of the PXC family, has an unlimited radius of operation: No need for a plug socket and no cable required. It has a smooth draw function and a high-quality carbide-tipped precision saw blade for cordless sawing. The X-Tend workpiece supports are easy to adjust with one hand. The clamping device is for secure fastening. The turntable has a precise angle adjustment facility for angular cuts with exact locking positions and the saw head can also be tilted up to 45° to the left. A cutting line laser and an LED light help make light work of performing cuts. Delivery without battery and charger.

## Features & Benefits




- Member of the Power X-Change family
- Boundless reach of action, no annoying cable, nothing to wind
- A smoothly running drag function for wide workpieces
- Turntable with precise angle setting for angular cuts
- Saw head tilts up to 45° to the left for mitre cutting
- X-Tend work supports with ergonomic single hand operation facilit
- High-grade precision saw blade
- Laser and LED for easy and safe use
- Clamping device for holding the workpiece securely in position
- Includes dust bag to keep the workplace clean

## Technical Data

- No-load speed ( idle speed )	3800 min <sup>-1</sup>
- Saw blade	254 x 30 mm
- Mitre cut	45° - 0°
- Swiveling range	47° - 47°
- Cutting capacity 90° x 90°	340 x 85 mm
- Cutting capacity 90° x 45°	240 x 85 mm
- Cutting capacity 45° x 90°	340 x 47 mm
- Cutting capacity 45° x 45°	240 x 47 mm
- Diameter of suction adapter	36 mm

## Logistic Data

- Product weight (kg)	13.8 kg
- Gross weight (kg)	16.8 kg
- Dimensions single packaging	810 x 610 x 430 mm
- Pieces per export carton	1 Pieces
- Gross weight of export carton	16.8 kg
- Dimensions export carton	810 x 610 x 430 mm
- Container quantity (20"/40"/40"HC)	125   260   315



## Available as special accessories



E-Stand  
Stationary Saw Accessory  
Item No.: 4310620  
Bar Code: 4006825584974  
Einhell Accessory



MSS 1610  
Stationary Saw Accessory  
Item No.: 4310615  
Bar Code: 4006825637496  
Einhell Accessory



4-6 Ah Multi-Ah Power X-Change Plus Akku Battery  
Item No.: 4511502  
Bar Code: 4006825644210



18V 2,5Ah PXC Starter Kit PXC-Starter-Kit  
Item No.: 4512097  
Bar Code: 4006825646962  
Einhell Accessory



4,0 Ah Power X-Change Akku Battery  
Item No.: 4511396  
Bar Code: 4006825610376  
Einhell Accessory



18V 4,0Ah PXC Starter Kit 1 PXC-Starter-Kit  
Item No.: 4512042  
Bar Code: 4006825613704  
Einhell Accessory



2x2 Power X-Quattrocharger 4A Charger  
Item No.: 4512102  
Bar Code: 4006825649536  
Einhell Accessory



18V 2,5Ah Power X-Change Battery  
Item No.: 4511516  
Bar Code: 4006825650518  
Einhell Accessory



Power X-Fastcharger 4A Charger  
Item No.: 4512103  
Bar Code: 4006825650228  
Einhell Accessory



2x 5,2Ah & Twincharger Kit PXC-Starter-Kit  
Item No.: 4512108  
Bar Code: 4006825652376  
Einhell Accessory



Power X-Twincharger 3A Charger  
Item No.: 4512069  
Bar Code: 4006825629729  
Einhell Accessory



Power X-Car Charger 3A Charger  
Item No.: 4512113  
Bar Code: 4006825655377  
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1 PXC-Starter-Kit  
Item No.: 4512112  
Bar Code: 4006825655766  
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack Battery  
Item No.: 4511526  
Bar Code: 4006825656695  
Einhell Accessory



5,2Ah & 4A Fastcharger PXC-Starter-Kit  
Item No.: 4512114  
Bar Code: 4006825656787  
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB 1 Battery  
Item No.: 4511489  
Bar Code: 4006825638578  
Einhell Accessory



MSS 1608  
Stationary Saw Accessory  
Item No.: 4310614  
Bar Code: 4006825660050  
Einhell Accessory



Sbl D 254x30x3,2 T48 Stationary Saw Accessory  
Item No.: 49589551  
Bar Code: 4009315895512  
Einhell Accessory



Sbl D 254x30x1,8 T42 Stationary Saw Accessory  
Item No.: 49589361  
Bar Code: 4009315893617  
Einhell Accessory



Sbl D 254x30x3,2 T60 Stationary Saw Accessory  
Item No.: 49589561  
Bar Code: 4009315895611  
Einhell Accessory



Sbl Set D 254x30x3,2 T24/42/60 Stationary Saw Accessory  
Item No.: 49589307  
Bar Code: 4006825662009  
Einhell Accessory



Power X-Boostcharger 6A Charger  
Item No.: 4512064  
Bar Code: 4006825629019  
Einhell Accessory



18V 3,0 Ah Power-X-Change 2 Battery  
Item No.: 4511341  
Bar Code: 4006825590593  
Einhell Accessory



18V 5-8Ah Multi-Ah PXC Plus Battery  
Item No.: 4511600  
Bar Code: 4006825665055  
Einhell Accessory



18V 4-6Ah & 6A Boostcharger PXC-Starter-Kit  
Item No.: 4512143  
Bar Code: 4006825667653  
Einhell Accessory



5,2 Ah Power X-Change Plus Akku Battery  
Item No.: 4511437  
Bar Code: 4006825616606



3,0 Ah Power X-Change Plus Akku Battery  
Item No.: 4511501  
Bar Code: 4006825644197



18V 4,0Ah Power-X-Change Plus Battery  
Item No.: 4511553  
Bar Code: 4006825660869  
Einhell Accessory



18V 2.0Ah PXC Starter Kit  
 PXC-Starter-Kit  
 Item No.: 4512040  
 Bar Code: 4006825613681  
 Einhell Accessory





2,0 Ah Power X-Change Akku  
 Battery  
 Item No.: 4511395  
 Bar Code: 4006825610369  
 Einhell Accessory



18V Battery Charger 3,0A - PXC  
 Charger  
 Item No.: 4514095  
 Bar Code: 4006825655292  
 Einhell Accessory

## Battery-Running-Times

One Battery for All	 cutting <sup>1</sup> (number of)	 cutting <sup>2</sup> (number of)
1.5 Ah	268	131
2.0 Ah	358	175
2.5 Ah	447	219
3.0 Ah	537	263
4.0 Ah	716	350
5.2 Ah	931	456
6.0 Ah	1074	526
8.0 Ah	1432	701

**Test setup:**

1) laminate - laminate 195x8mm

2) softwood - scantling 60x60 mm