



Einhell

EXPERT

POWER X-CHANGE

Cordless Mitre Saw

TE-MS 18/8 Li-Solo

Item No.: 4300893

Ident No.: 21012

Bar Code: 4006825671391

The Einhell cordless mitre saw TE-MS 18/8 Li-Solo is the perfect tool for every DIYer. Its powerful 18 V motor spins the heavy-duty 40-tooth, Ø 216 mm carbide-tipped blade to quickly and cleanly cut through the material at hand. This provides a cutting width of up to 120 mm and a cutting depth of up to 60 mm. The saw table, which can be rotated 47° to the left and right, and the pivoted saw head, which can also be tilted 45° to the left, enable perfect mitre cuts to be achieved. The chip collector and Ø 36 mm extractor connection keep the work area clean. The tool does not include a battery or charger.

Features & Benefits

- Member of the Power X-Change family, 1x 18 V battery required
- Unlimited range of use without the hassle of cables
- Turntable with lock-in positions at the most common angles
- Saw head can be tilted up to 45° to the left for mitre cuts
- Easy-to-read angle scale
- Table extensions on both sides for longer workpieces
- Incl. clamping device to hold the workpiece in place
- Easily accessible spindle lock for simple blade exchange
- High-quality HW/TCT saw blade for perfectly clean cuts
- Chip collector behind blade for a cleaner working space
- Incl. extractor connection (36 mm)
- Supplied without battery and charger (sold separately)



Technical Data

- No-load speed (idle speed) 3000 min⁻¹
- Saw blade Ø216 x Ø30 mm
- Number of saw teeth 40 Pieces
- Mitre cut 45° - 0°
- Swivelling range 47° - 47°
- Cutting capacity 90° x 90° 120 x 60 mm
- Cutting capacity 90° x 45° 80 x 60 mm
- Cutting capacity 45° x 90° 120 x 45 mm
- Cutting capacity 45° x 45° 80 x 45 mm
- Diameter of suction adapter 36 mm

Logistic Data

- Product weight (kg) 7.4
- Gross weight (kg) 10
- Dimensions single packaging 528 x 360 x 345 mm
- Pieces per export carton 1 Pieces
- Gross weight of export carton 9.9 kg
- Dimensions export carton 525 x 360 x 320 mm
- Container quantity (20"/40"/40"HC) 433 | 908 | 1112



Available as special accessories



E-Stand
Stationary Saw Accessory
Item No.: 4310620
Bar Code: 4006825584974
Einhell Accessory



MSS 1610
Stationary Saw Accessory
Item No.: 4310615
Bar Code: 4006825637496
Einhell Accessory



4-6 Ah Multi-Ah Power X-Change Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210



18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



4,0 Ah Power X-Change
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



18V 3,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512041
Bar Code: 4006825613698
Einhell Accessory



18V 4,0Ah PXC Starter Kit A1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



2x 5,2Ah & Twincharger Kit
PXC-Starter-Kit
Item No.: 4512108
Bar Code: 4006825652376
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



18V 3,0 Ah Power-X-Change 1
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory



Power X-Car Charger 3A
Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1
PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack
Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory



5,2Ah & 4A Fastcharger
PXC-Starter-Kit
Item No.: 4512114
Bar Code: 4006825656787
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB
A1
Battery
Item No.: 4511489
Bar Code: 4006825638578



MSS 1608
Stationary Saw Accessory
Item No.: 4310614
Bar Code: 4006825660050
Einhell Accessory



3,0 Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



Sbl D 216x30x2,4 T48
Stationary Saw Accessory
Item No.: 49588251
Bar Code: 4009315882512
Einhell Accessory



Sbl D 216x30x2,4 T60
Stationary Saw Accessory
Item No.: 49588261
Bar Code: 4009315882611
Einhell Accessory



Sbl Set D 216x30x2,4 T24/42/60
Stationary Saw Accessory
Item No.: 49587806
Bar Code: 4006825661996
Einhell Accessory

Power X-Caravan Charger 3A
Charger
Item No.: 4512136
Bar Code: 4006825664010
Einhell Accessory



18V 5-8Ah Multi-Ah PXC Plus
Battery
Item No.: 4511600
Bar Code: 4006825665055
Einhell Accessory



18V 4-6Ah & 6A Boostcharger
PXC-Starter-Kit
Item No.: 4512143
Bar Code: 4006825667653
Einhell Accessory



Power X-Boostcharger 8A
Charger
Item No.: 4512155
Bar Code: 4006825670554
Einhell Accessory



5,2 Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



18V 4,0Ah Power-X-Change Plus
Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory




2,0 Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



18V Battery Charger 3,0A - PXC
Charger
Item No.: 4514095
Bar Code: 4006825655292
Einhell Accessory

Battery-Running-Times

One Battery for All	 sawing ¹ (pieces)
1.5 Ah	98
2.0 Ah	131
2.5 Ah	164
3.0 Ah	197
4.0 Ah	262
5.2 Ah	341
6.0 Ah	393
8.0 Ah	524

For best performance select a battery with at least 2.5 Ah

Test setup:

1) softwood - scantling 60x60 mm