



Einhell

EXPERT PLUS



Cordless Drill

TE-CD 18 Li E-Solo

Item No.: 4513870

Ident No.: 21021

Bar Code: 4006825617740

The Einhell TE-CD 18 Li E solo cordless drill driver combines a powerful motor with high-grade metal gearing together with high-grade Power X-Change technology. All the rechargeable batteries and chargers in the series of systems can be used with every Power X-Change tool. Thanks to the two-speed gearing and electronic torque preselector, the power can be finely dosed to meet the job's requirements. In combination with the 13 mm quick-change drill chuck and automatic spindle lock you can swap fitted tools with ease. An LED light provides optimum illumination. An ergonomic design with Softgrip ensures a firm hold. A practical belt clip is also integrated. This product comes without batteries and without a charger.


Features & Benefits

- Member of the Power X-Change family
- High-grade quick-change drill chuck for fast bit change
- Optimum force thanks to electronic torque setting
- 2-speed gearing for powerful screwdriving and fast drilling
- Automatic spindle lock for easy tool change
- Powerful motor and high-grade metal gearing
- Ergonomic handle for easy working
- Incl. LED lamp to perfectly illuminate the working area
- Complete with practical belt clip
- Supplied without battery and charger (available separately)




Technical Data

- Number of gears 2
- Idle speed (gear 1) 0-400 min⁻¹
- Idle speed (gear 2) 0-1400 min⁻¹
- Max. torque hard 47 Nm
- Number of torque steps 9 settings
- Drill chuck 13 mm | single sleeve



Logistic Data

- Product weight 1.14 kg
- Gross weight single packaging 1.44 kg
- Dimensions single packaging 223 x 88 x 211 mm
- Pieces per export carton 5 Pieces
- Gross weight export carton 8.08 kg
- Dimensions export carton 475 x 240 x 232 mm
- Container quantity (20"/40"/40"HC) 5290 | 10585 | 12855



Available as special accessories



18V 2,0Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



18V 4,0Ah Power X-Change 1
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



18V 4,0Ah PXC Starter Kit 1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



18V 5,2Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



18V 2,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory




Power X-Boostcharger 6A
Charger
Item No.: 4512064
Bar Code: 4006825629019
Einhell Accessory



18V 3,0 Ah Power-X-Change 2
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory

Battery-Running-Times

One Battery for All	 screwing ¹ (pieces)
1.5 Ah	230
2.0 Ah	300
2.5 Ah	380
3.0 Ah	450
4.0 Ah	600
5.2 Ah	790
6.0 Ah	900
8.0 Ah	1200

Test setup:

1) screws - spruce wood