



Einhell

EXPERT

POWER X-CHANGE

Cordless Palm Sander
TE-OS 18/113 Li - Solo
Item No.: 4460731

Ident No.: 21012

Bar Code: 4006825671094

The Einhell TE-OS 18/113 Li-Solo cordless palm sander is a powerful member of the flexible Power X-Change family. The powerful cordless palm sander has an oscillating circuit of 1.8 mm and comes with an already mounted sanding plate (101 x 113 mm) and 2x sandpaper (P120). The sandpaper can be attached using hook-and-loop fastening or the clamping device. The sander has a connection for external suction and an internal extraction system with dust collector. Its compact design with softgrip surfaces ensures comfortable use and optimal guidance of the orbital sander. Comes without battery or charging device.

Features & Benefits

- Member of the Power X-Change family, 1 x 18 V battery required
- Powerful Orbital Sander with Large Orbital Circuit
- Compact design for better control when grinding
- Perfect for sanding flat surfaces
- Fast sandpaper change thanks to hook-and-loop fastening
- Clamping device: For sandpaper without hook-and-loop fastening
- Internal dust extraction with dust trap and pleated filter
- Connection for external dust extraction
- Safe and comfortable use thanks to softgrip surfaces
- Incl. 2x sandpaper (P120)
- Comes without battery or charger (sold separately)




Technical Data

- Voltage: 18 V
- Oscillating speed: 22000 min⁻¹
- Oscillating circuit: 1.8 mm
- sanding surface: 113 x 101 mm



Logistic Data

- Product weight (kg): 1.03
- Gross weight (kg): 1.65
- Dimensions single packaging: 180 x 172 x 182 mm
- Pieces per export carton: 6 Pieces
- Gross weight of export carton: 10.5 kg
- Dimensions export carton: 532 x 192 x 387 mm
- Containerquantity (20" /40"/ 40HC): 3960 | 8040 | 9504



Available as special accessories



12 Schleifpapier-Set 102x114mm
Orbital Sander Accessory
Item No.: 4460733
Bar Code: 4006825678369
Einhell Accessory



PXC+ 18V 5-8Ah MULTI
Battery
Item No.: 4511600
Bar Code: 4006825665055
Einhell Accessory



PXC 18V 3,0Ah
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory



2,0 Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



4-6 Ah Multi-Ah Power X-Change
Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210



2x18V 4,0Ah PXC-Twinpack CB
B1
Battery
Item No.: 4511489
Bar Code: 4006825638578



Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



Power X-Car Charger 3A
Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



18V 4,0Ah PXC Starter Kit A1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



18V 2,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory



E-Case M
System Carrying Case
Item No.: 4540021
Bar Code: 4006825667721
Einhell Accessory



5,2 Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



PXC+ 18V 4,0Ah
Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory



3,0 Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



4,0 Ah Power X-Change
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack
Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory



2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1
PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory



E-Case L with wheels
System Carrying Case
Item No.: 4540014
Bar Code: 4006825660562
Einhell Accessory

Battery-Running-Times



One Battery for All

running time¹
(min.)

1.5 Ah	34
2.0 Ah	45
2.5 Ah	56
3.0 Ah	67
4.0 Ah	89
5.2 Ah	116
6.0 Ah	133
8.0 Ah	178

Test setup:

1) no-load