



# Einhell

## EXPERT

### POWER X-CHANGE

### Cordless Lawn Mower GE-CM 43 Li M Kit (2x4,0Ah)

Item No.: 3413130

Ident No.: 21041

Bar Code: 4006825610338

The GE-CM 43 Li M cordless lawn mower is a high-quality, reliable and extremely powerful tool which cares for larger lawns without being connected to a socket. With the new Power X-Change battery system from Einhell the lawn mower has two powerful 18 V battery packs with 4.0 Ah for long work sessions without any bothersome power cables. For simple, individual adjustment of the cutting height there is a central 6-level cutting height adjustment facility. In addition the cuttings can be finely shredded by a mulching kit before they are evenly distributed over the lawn.

## Features & Benefits

- Twin-Pack Technology: 2x18V Power X-Change batteries - more power
- Brushless motor - more power and prolonged operation
- Central cutting height adjustment, 6 levels (25-75mm)
- Height-adjustable long handle with 3 settings
- Space saving storage thanks to foldable long handle
- Integrated carry-handle for easy transport
- Highwheeler - grass protecting, large wheels
- Filling level indication from the grass collection box
- High quality, blow tough plastic housing
- Including mulching plug
- Recommended for lawn areas up to 600 m<sup>2</sup>
- Supplied with 2x 4,0Ah battery and 2x high-speed charger




## Technical Data

- Accumulator 18 V (2x) | 4000 mAh | Li-Ion
- Charging time 75min
- Cutting width 43 cm
- Cutting height adjustment 6 | 25/35/45/55/65/75 mm | central
- Capacity of catching device 63 L
- Wheel diameter front 160 mm
- Wheel diameter rear 250 mm

## Logistic Data

- Gross weight (kg) 21.3
- Product weight (kg) 16.5
- Dimensions single packaging 825 x 480 x 445 mm
- Pieces per export carton 1 Pieces
- Gross weight export carton 21.3 kg
- Dimensions export carton 825 x 480 x 445 mm
- Container quantity (20"/40"/40"HC) 165 | 330 | 390



## Available as special accessories

	Spare Blade f. GE-CM 43 Li Lawn Mower Accessory Item No.: 3405451 Bar Code: 4006825610604 Einhell Grey		Power X-Boostcharger 6A Charger Item No.: 4512064 Bar Code: 4006825629019 Einhell Accessory
	2x 3,0Ah & Twincharger Kit PXC-Starter-Kit Item No.: 4512083 Bar Code: 4006825638509 Einhell Accessory		18V 4-6Ah Multi-Ah PXC Plus Battery Item No.: 4511502 Bar Code: 4006825644210 Einhell Accessory
	18V 2,5Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512097 Bar Code: 4006825646962 Einhell Accessory		18V 2,0Ah Power X-Change Battery Item No.: 4511395 Bar Code: 4006825610369 Einhell Accessory
	18V 4,0Ah Power X-Change 1 Battery Item No.: 4511396 Bar Code: 4006825610376 Einhell Accessory		18V 4,0Ah PXC Starter Kit 1 PXC-Starter-Kit Item No.: 4512042 Bar Code: 4006825613704 Einhell Accessory
	12V 2,0Ah Li-Battery Battery Item No.: 4511472 Bar Code: 4006825634655 Einhell Accessory		2x2 Power X-Quattrocharger 4A Charger Item No.: 4512102 Bar Code: 4006825649536 Einhell Accessory
	18V 2,5Ah Power X-Change Battery Item No.: 4511516 Bar Code: 4006825650518 Einhell Accessory		Power X-Fastcharger 4A Charger Item No.: 4512103 Bar Code: 4006825650228 Einhell Accessory
	18V 5,2Ah Power X-Change Plus Battery Item No.: 4511437 Bar Code: 4006825616606 Einhell Accessory		2x 5,2Ah & Twincharger Kit PXC-Starter-Kit Item No.: 4512108 Bar Code: 4006825652376 Einhell Accessory
	Power X-Twincharger 3A Charger Item No.: 4512069 Bar Code: 4006825629729 Einhell Accessory		18V Battery Charger 3,0A - PXC Charger Item No.: 4514095 Bar Code: 4006825655292 Einhell Accessory
	Power X-Car Charger 3A Charger Item No.: 4512113 Bar Code: 4006825655377 Einhell Accessory		2x 4,0Ah & Twincharger Kit PXC-Starter-Kit Item No.: 4512112 Bar Code: 4006825655766 Einhell Accessory
	2x 18V 2,5Ah PXC-Twinpack CB Battery Item No.: 4511524 Bar Code: 4006825656206 Einhell Accessory		2x 18V 5,2Ah PXC-Twinpack Battery Item No.: 4511526 Bar Code: 4006825656695 Einhell Accessory
	5,2Ah & 4A Fastcharger PXC-Starter-Kit Item No.: 4512114 Bar Code: 4006825656787 Einhell Accessory		2x18V 4,0Ah PXC-Twinpack CB 1 Battery Item No.: 4511489 Bar Code: 4006825638578 Einhell Accessory
	18V 2,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512040 Bar Code: 4006825613681 Einhell Accessory		18V 4,0Ah Power-X-Change Plus Battery Item No.: 4511553 Bar Code: 4006825660869 Einhell Accessory
	18V 3,0Ah Power X-Change Plus Battery Item No.: 4511501 Bar Code: 4006825644197 Einhell Accessory		18V 3,0 Ah Power-X-Change 2 Battery Item No.: 4511341 Bar Code: 4006825590593 Einhell Accessory

# Battery-Running-Times



One Battery for All

lawn mowing<sup>1</sup>  
(m<sup>2</sup>)

1.5 Ah	225
2.0 Ah	300
2.5 Ah	350
3.0 Ah	450
4.0 Ah	600
5.2 Ah	750
6.0 Ah	900

Test setup:

1) -