Cordless Lawn Mower

RASARRO 36/250 (2x2,5 Ah)

Item No.: 3413305

Ident No.: 21024

Bar Code: 4006825670813

The Einhell cordless lawn mower RASARRO 36/250 (2x2.5 Ah) is a powerful device for wireless home garden maintenance. The mower is part of the flexibly combinable Power X-Change family and is powered by two 18 V batteries using 36 V twin pack technology. The five-stage central cutting height adjustment (25–65 mm) allows individual adjustment of the cutting height. The 30-litre collection basket is fitted with a fill level indicator. The mower has a cutting width of 34 cm and has a height-adjustable, foldable guide bar. The cordless lawn mower is recommended for areas up to 250 m². Delivery incl. 2x2.5 Ah Power X-Change batteries and 2x chargers.

Features & Benefits

- Member of the Power X-Change family, 2x 18V battery required
- TWIN-PACK technology: 2x18V Power X-Change batteries - more power
- 5-level central cutting height adjustment (25-65 mm)
- Ergonomic shaped handle area for fatigue-free working
- Individually height-adjustable guide rail
- Foldable guide rail for space-saving storage
- Sturdy and lightweight aluminium guide rail
- 30 L grass collection box with fill level indicator
- Integrated carrying handle for easy transport
- Recommended for lawn areas up to 250 m²
- Lawn-protecting wheels
- Supplied with 2x 2.5 Ah PXC battery and 2x charger

Technical Data

- Accumulator	18 V (2x) | 2500 mAh | Li-Ion
- Idle speed	3400 min^-1
- Cutting width	34 cm
- Cutting height adjustment	5 | 25-65 mm | central
- Capacity of catching device	30 L
- Wheel diameter front	150 mm
- Wheel diameter rear	180 mm



Logistic Data

- Gross weight (kg)	16.8
- Product weight (kg)	12.87
- Dimensions single packaging	766 x 442 x 383 mm
- Pieces per export carton	1 Pieces
- Gross weight export carton	16.8 kg
- Dimensions export carton	755 x 450 x 380 mm
- Container quantity (20"/40"/40"HC)	234 | 468 | 546

Illustrations can contain accessories, which are not included in standard extent of delivery
Illustration similar (in design), production-wise modifications reserved
GS mark belongs to the product itself only, excluded accessory
Generated at: 10.03.2025 09:25

Available as special accessories

Spare Blade GE-CM 33 Li+36/34
Lawn Mower Accessory
Item No.: 3405452
Bar Code: 4006825610611
Einhell Accessory

PXC+ 18V 5-8Ah MULTI
Battery
Item No.: 4511600
Bar Code: 4006825665055
Einhell Accessory

PXC+ 18V 4,0Ah
Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory

PXC 18V 3,0Ah
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory

2,0 Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory

4-6 Ah Multi-Ah Power X-Change Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210

18V 4Ah PXC Plus Twinpack
Battery
Item No.: 4511629
Bar Code: 4006825673685
Einhell Accessory

2x18V 4,0Ah PXC-Twinpack CB B1
Battery
Item No.: 4511489
Bar Code: 4006825638578

Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory

Power X-Car Charger 3A
Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory

18V Battery Charger 3,0A - PXC
Charger
Item No.: 4514095
Bar Code: 4006825655292
Einhell Accessory

18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory

18V 4-6Ah & 6A Boostcharger
PXC-Starter-Kit
Item No.: 4512143
Bar Code: 4006825667653
Einhell Accessory

5,2 Ah PXC Starter-Kit
PXC-Starter-Kit
Item No.: 4512147
Bar Code: 4006825675153
Einhell Accessory

5,2 Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory

PXC+ 18V 4,0Ah SEALED
Battery
Item No.: 4511627
Bar Code: 4006825673227
Einhell Accessory

PXC+ 18V 3,0Ah SEALED
Battery
Item No.: 4511618
Bar Code: 4006825672794
Einhell Accessory

3,0 Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory

4,0 Ah Power X-Change
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory

2x 18V 5,2Ah PXC-Twinpack
Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory

18V 3Ah PXC Plus Twinpack
Battery
Item No.: 4511631
Bar Code: 4006825673692
Einhell Accessory

2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory

Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory

Power X-Boostcharger 8A
Charger
Item No.: 4512155
Bar Code: 4006825670554
Einhell Accessory

Power X-Twincharger 4A
Charger
Item No.: 4512161
Bar Code: 4006825680638
Einhell Accessory

2x 4,0Ah & Twincharger Kit 1
PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory

18V 2,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory

18V 4,0Ah PXC Starter Kit B1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory

Illustrations can contain accessories, which are not included in standard extent of delivery
Illustration similar (in design), production-wise modifications reserved
GS mark belongs to the product itself only, excluded accessory

4Ah PLUS PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512159
Bar Code: 4006825680331
Einhell Accessory

Illustrations can contain accessories, which are not included in standard extent of delivery
Illustration similar (in design), production-wise modifications reserved
GS mark belongs to the product itself only, excluded accessory