



850W BELT SANDER RT-BS-75

QUICK START GUIDE

Easy steps to getting started.

1. Ensure all items, including your manual are removed from the packaging before discarding.
2. **Important!** Always pull the power plug before making adjustments to the equipment.

Push the dust collection box (14) to the dust extractor connection (6). For better dust extraction, connect the belt sander to a dust extraction unit (not supplied). To do so, slide the dust extractor adapter on to the connection for the dust extractor (6) and connect it to the dust extraction unit.

3. Adjust the additional handle by slacken the screw (1) and move the additional handle (2) to its optimal position and then retighten the screw (1).
4. To change the sanding belt (13) pull the clamping lever to the outside. Ensure that the direction of the sanding belt (arrows on the inside of the sanding belt) is identical to the direction of the belt sander (arrow over the rear drive roller). Pull the used sanding belt off the drive rollers and slide the new sanding belt on. Press the clamping lever to the rear to tension the sanding belt.
5. To adjust the position of the sanding belt (13) turn the belt sander upside down. Switch on the belt sander and turn the setting screw (8) to position the belt in a way that the sanding belt is at the centre of the two drive rollers.
6. Switch on the belt sander by pressing the ON/ OFF switch. Secure the ON/ OFF switch for continuous power by pushing the locking button (4). To switch it off, press the ON/ OFF switch.
7. Important! When using the folding belt cover (9) the pushbutton (7) has to be pressed. To fold the belt cover (9), press the pushbutton (7) and at the same time swing the cover (9) upwards. After releasing the pushbutton (7) the belt cover (9) will lock in its position.
8. For further instructions how to use the belt sander, refer to Section 6.3 of the User Guide.

9. IF YOU ARE IN ANY DOUBT PLEASE REFER TO THE DETAILED INSTRUCTIONS WITHIN OUR MANUAL.

