



# Einhell

**EXPERT Plus**

**POWER X-CHANGE**

## GE-CH 1855/1 Li Kit (1x2,0Ah)

### Cordless Hedge Trimmer

Item No.: 3410503

Ident No.: 11027

Bar Code: 4006825615784

The GE-CH 1855/1 Li Kit cordless hedge trimmer is a very efficient tool which provides good service for the trimming of hedges, shrubs and bushes on large grounds where there is no connection to the electric power grid. With the new Power X-Change battery system from Einhell, the hedge trimmer has an 18 V battery pack with 2.0 Ah for long work sessions. For a long service life the gearing is made of metal, for clean cutting results the blades are made of laser-cut and diamond-ground steel.


### Features

- Battery system - Power X-Change
- Battery charge level indicator with 3 LEDs
- Battery can be used for other Power X-Change products
- System high-speed charger included
- Blades made of laser-cut and diamond-ground steel
- Adjustable additional handle
- Swivel handle
- Handy
- Metal gearing for a long life
- Two-hand safety switch
- Aluminium cover on cutters
- Bumper guard with holder for wall mount
- Cutting collector
- Sturdy cutter guard for storage and transportation



### Technical Data

- Max. running time	80 min
- Charging time	40min
- Cutting length	550 mm
- Blade length	620 mm
- Spacing between teeth	18 mm
- Cuts per minute	2200 min <sup>-1</sup>
- Accumulator	18 V   2000 mAh   Li-Ion
- Number of accumulators	1 Pieces



### Logistic Data

- Product weight	2.6
- Gross weight single packaging	3.7 kg
- Dimensions single packaging	1005 x 130 x 170 mm
- Pieces per export carton	4 Pieces
- Gross weight export carton	15 kg
- Dimensions Export Carton	1040 x 290 x 275 mm
- Container quantity (20"/40"/40"HC)	1344   2880   3240
- Product weight	2.6 kg

## Available as special accessories



18V 3,0 Ah Power-X-Change  
Battery  
Item No.: 4511341  
Bar Code: 4006825590593  
Einhell Accessory



18V 4,0 Ah Power-X-Change  
Battery  
Item No.: 4511396  
Bar Code: 4006825610376  
Einhell Accessory



18V 3,0Ah PXC Starter Kit  
PXC-Starter-Kit  
Item No.: 4512041  
Bar Code: 4006825613698  
Einhell Accessory



18V 2,6Ah P-X-C Plus  
Battery  
Item No.: 4511436  
Bar Code: 4006825616590  
Einhell Accessory

18V 5,2 Ah P-X-C Plus  
Battery  
Item No.: 4511437  
Bar Code: 4006825616606  
Einhell Accessory



18V 2,0 Ah Power-X-Change  
Battery  
Item No.: 4511395  
Bar Code: 4006825610369  
Einhell Accessory



18V 2,0Ah PXC Starter Kit  
PXC-Starter-Kit  
Item No.: 4512040  
Bar Code: 4006825613681  
Einhell Accessory



18V 4,0Ah PXC Starter Kit  
PXC-Starter-Kit  
Item No.: 4512042  
Bar Code: 4006825613704  
Einhell Accessory



18V 30min Power-X-Change  
PXC-Charger  
Item No.: 4512011  
Bar Code: 4006825587029  
Einhell Accessory