



# Einhell

# EXPERT

## POWER X-CHANGE

Robot Lawn Mower

**FREELEXO 750 LCD BT+**

**Item No.: 3413981**

Ident No.: 21010

Bar Code: 4006825655049

The Robot Lawn Mower FREELEXO 750 LCD BT+ is part of the Power X-Change family, so the 3.0 Ah lithium ion battery pack is fully compatible with all units in the PXC range. FREELEXO can be controlled via Bluetooth using the dedicated app and an intuitive keypad with LCD display. Mowing times can be programmed for each day and a separate program started for secondary areas. The multi-zone/spot lawn mower is also equipped with cutting height adjustment from 20-60 mm, PIN coded anti-theft protection, and sensors to help it cope with rain, impact, tilt and lift on slopes of up to 35%. In ECO mode, the mower automatically returns to the charging station when required. The unit comes with installation equipment for a lawn size of 750 m<sup>2</sup>.


## Features & Benefits

- PXC system battery - can also be used for other PXC products
- App control using Bluetooth-user-defined robot lawnmower control
- Intuitive keypad with LCD display
- Programmable operating time for each specific day
- Safety sensor system thanks to impact, tilt and lift sensors
- PIN code anti-theft protection
- Rain sensor
- ECO mode for the charging station
- Multizone mowing - for complex gardens
- Spot mowing
- Mowing program for border areas
- Cutting height adjustment facility (20-60mm)
- Suitable for inclines up to 35%
- Automatic return to charging unit and charging
- Incl. installation equipment for 750 m<sup>2</sup> lawns
- Incl. 3.0 Ah PXC rechargeable battery
- 175 m perimeter wire
- 245 fastening hooks
- 3 spare blades
- 4 connecting clamps



## Technical Data

- Power	18 V
- Battery	18 V   3000 mAh   Li-Ion
- Cutting width	18 cm
- Slope	35 %
- Cutting height adjustment	20 mm - 60 mm
- Recommended area	750 m <sup>2</sup>
- Perimeter wire	175 m
- Hooks	245 Pieces
- Spare blades	Yes, three pieces
- Connecting clamps	4 Pieces



# Logistic Data

- Product weight (kg)	11
- Gross weight (kg)	16.4
- Dimensions single packaging	690 x 430 x 305 mm
- Pieces per export carton	1 Pieces
- Gross weight of export carton	16.4 kg
- Dimensions export carton	700 x 440 x 315 mm
- Container quantities (20"/40"/40"HC)	294   602   688

## Available as special accessories

	Power X-Boostcharger 6A Charger Item No.: 4512064 Bar Code: 4006825629019 Einhell Accessory		2x 3,0Ah & Twincharger Kit PXC-Starter-Kit Item No.: 4512083 Bar Code: 4006825638509 Einhell Accessory
	18V 4-6Ah Multi-Ah PXC Plus Battery Item No.: 4511502 Bar Code: 4006825644210 Einhell Accessory		18V 3,0Ah Power X-Change Plus Battery Item No.: 4511501 Bar Code: 4006825644197 Einhell Accessory
	18V 2,5Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512097 Bar Code: 4006825646962 Einhell Accessory		Installation Kit 500m2 Robot Lawn Mower Accessory Item No.: 3414010 Bar Code: 4006825646863 Einhell Accessory
	Installation Kit 800m2 Robot Lawn Mower Accessory Item No.: 3414011 Bar Code: 4006825646870 Einhell Accessory		Installation Kit 1200m2 Robot Lawn Mower Accessory Item No.: 3414012 Bar Code: 4006825646887 Einhell Accessory
	18V 2,0Ah Power X-Change Battery Item No.: 4511395 Bar Code: 4006825610369 Einhell Accessory		18V 4,0Ah Power X-Change Battery Item No.: 4511396 Bar Code: 4006825610376 Einhell Accessory
	Ersatzklingen 12 Stk Robot Lawn Mower Accessory Item No.: 3414020 Bar Code: 4006825648775 Einhell Accessory		Begrenzungsdraht 50 m Robot Lawn Mower Accessory Item No.: 3414021 Bar Code: 4006825648782 Einhell Accessory
	Verbindungsklemmen 4 Stk Robot Lawn Mower Accessory Item No.: 3414022 Bar Code: 4006825648799 Einhell Accessory		Befestigungshaken 100 Stk Robot Lawn Mower Accessory Item No.: 3414023 Bar Code: 4006825648805 Einhell Accessory
	2x2 Power X-Quattrocharger 4A Charger Item No.: 4512102 Bar Code: 4006825649536 Einhell Accessory		18V 2,5Ah Power X-Change Battery Item No.: 4511516 Bar Code: 4006825650518 Einhell Accessory
	Power X-Fastcharger 4A Charger Item No.: 4512103 Bar Code: 4006825650228 Einhell Accessory		18V 5,2Ah Power X-Change Plus Battery Item No.: 4511437 Bar Code: 4006825616606 Einhell Accessory
	Power X-Twincharger 3A Charger Item No.: 4512069 Bar Code: 4006825629729 Einhell Accessory		Mähroboter Garage Robot Lawn Mower Accessory Item No.: 3414024 Bar Code: 4006825654417 Einhell Accessory
	18V Battery Charger 3,0A - PXC Charger Item No.: 4514095 Bar Code: 4006825655292 Einhell Accessory		2x 18V 2,5Ah PXC-Twinpack CB Battery Item No.: 4511524 Bar Code: 4006825656206 Einhell Accessory
	2x 18V 5,2Ah PXC-Twinpack Battery Item No.: 4511526 Bar Code: 4006825656695 Einhell Accessory		Cleaning Set Robot Lawn Mower Accessory Item No.: 3414025 Bar Code: 4006825657951 Einhell Accessory
	Reparaturset Robot Lawn Mower Accessory Item No.: 3414026 Bar Code: 4006825657968 Einhell Accessory		2x18V 4,0Ah PXC-Twinpack CB 1 Battery Item No.: 4511489 Bar Code: 4006825638578 Einhell Accessory
	18V 4,0Ah PXC Starter Kit 2 PXC-Starter-Kit Item No.: 4512042 Bar Code: 4006825613704 Einhell Accessory		