



# Einhell

## PROFESSIONAL



Cordless Chain Saw

**GP-LC 36/40 Li BL-Solo**

**Item No.: 4600050**

Ident No.: 21024

Bar Code: 4006825678406

The Einhell Professional Cordless Chain Saw GP-LC 36/40 Li BL-Solo is a reliable assistant for felling medium to large trees. It is powered by the Einhell Brushless Motor for increased power and longer runtime. After online registration, the motor is covered by a 10-year warranty. The chainsaw features a 38 cm cutting length and is equipped with a high-quality OREGON chain with 1.3 mm thickness, 56 drive links, and 3/8" chain pitch. The saw chain is continuously and automatically lubricated from the 230 ml oil tank. For optimal protection, the batteries can be securely mounted on the side of the device. Delivery does not include battery and charger.

## Features & Benefits

- Member of the Power X-Change family, 2x 18 V battery required
- Twin-Pack technology: 2x18V Power X-Change batteries - more power
- Brushless motor - more power and longer running time
- Brushless - 10-year motor warranty after registration
- Toolless chain tensioning and changing
- High-quality OREGON guide bar and sharp chain
- Perfectly balanced battery positioning
- Side positioning of the battery for optimal protection
- Automatic chain lubrication
- LED battery charge indicator for monitoring battery capacity
- Ergonomic handle with softgrip
- Sturdy stop claws made of metal
- Oil tank with gauge glass for automatic chain lubrication
- Kickback guard and instant chain brake
- Chain catcher for user protection
- Recommendation for optimal results: 2x 5.2 Ah battery or larger
- Delivery without battery and charger (available separately)





## Technical Data

- |                       |        |
|-----------------------|--------|
| - Sword length        | 400 mm |
| - Max. cutting length | 38 cm  |
| - Chain cutting speed | 19 m/s |
| - Oil tank capacity   | 230 mL |

## Logistic Data

- |                                      |                    |
|--------------------------------------|--------------------|
| - Product weight (kg)                | 4.8 kg             |
| - Gross weight (kg)                  | 6.3 kg             |
| - Dimensions single packaging        | 273 x 515 x 240 mm |
| - Pieces per export carton           | 2 Pieces           |
| - Gross weight export carton         | 13.5 kg            |
| - Dimensions Export Carton           | 540 x 510 x 290 mm |
| - Container quantity (20"/40"/40"HC) | 616   1232   1408  |



## Available as special accessories



PXC Battery Mounting Gadget  
PXC-Battery Accessory  
Item No.: 4514155  
Bar Code: 4006825658774  
Einhell Accessory



Spare bar 40cm 1,3  
Chain Saw Accessory  
Item No.: 4500156  
Bar Code: 4006825548778  
Einhell Accessory



PXC+ 18V 5-8Ah MULTI  
Battery  
Item No.: 4511600  
Bar Code: 4006825665055  
Einhell Accessory



PXC+ 18V 4,0Ah  
Battery  
Item No.: 4511553  
Bar Code: 4006825660869  
Einhell Accessory



PXC 18V 3,0Ah  
Battery  
Item No.: 4511341  
Bar Code: 4006825590593  
Einhell Accessory



2,0 Ah Power X-Change  
Battery  
Item No.: 4511395  
Bar Code: 4006825610369  
Einhell Accessory



4-6 Ah Multi-Ah Power X-Change  
Plus  
Battery  
Item No.: 4511502  
Bar Code: 4006825644210



18V 4Ah PXC Plus Twinpack  
Battery  
Item No.: 4511629  
Bar Code: 4006825673685  
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB  
B1  
Battery  
Item No.: 4511489  
Bar Code: 4006825638578



Power X-Fastcharger 4A  
Charger  
Item No.: 4512103  
Bar Code: 4006825650228  
Einhell Accessory



Power X-Car Charger 3A  
Charger  
Item No.: 4512113  
Bar Code: 4006825655377  
Einhell Accessory



18V Battery Charger 3,0A - PXC  
Charger  
Item No.: 4514095  
Bar Code: 4006825655292  
Einhell Accessory



2x 5,2Ah & Twincharger Kit  
PXC-Starter-Kit  
Item No.: 4512108  
Bar Code: 4006825652376  
Einhell Accessory



18V 4-6Ah & 6A Boostcharger  
PXC-Starter-Kit  
Item No.: 4512143  
Bar Code: 4006825667653  
Einhell Accessory



Spare Chain 40cm 1.3 56T 3/8  
Chain Saw Accessory  
Item No.: 4500367  
Bar Code: 4006825681857  
Einhell Accessory



5,2 Ah Power X-Change Plus  
Battery  
Item No.: 4511437  
Bar Code: 4006825616606  
Einhell Accessory



PXC+ 18V 4,0Ah SEALED  
Battery  
Item No.: 4511627  
Bar Code: 4006825673227  
Einhell Accessory



PXC+ 18V 3,0Ah SEALED  
Battery  
Item No.: 4511618  
Bar Code: 4006825672794  
Einhell Accessory



3,0 Ah Power X-Change Plus  
Battery  
Item No.: 4511501  
Bar Code: 4006825644197  
Einhell Accessory



4,0 Ah Power X-Change  
Battery  
Item No.: 4511396  
Bar Code: 4006825610376  
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack  
Battery  
Item No.: 4511526  
Bar Code: 4006825656695  
Einhell Accessory



18V 3Ah PXC Plus Twinpack  
Battery  
Item No.: 4511631  
Bar Code: 4006825673692  
Einhell Accessory



2x2 Power X-Quattrocharger 4A  
Charger  
Item No.: 4512102  
Bar Code: 4006825649536  
Einhell Accessory



Power X-Twincharger 3A  
Charger  
Item No.: 4512069  
Bar Code: 4006825629729  
Einhell Accessory



Power X-Boostcharger 8A  
Charger  
Item No.: 4512155  
Bar Code: 4006825670554  
Einhell Accessory



18V 2,5Ah PXC Starter Kit  
PXC-Starter-Kit  
Item No.: 4512097  
Bar Code: 4006825646962  
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1  
PXC-Starter-Kit  
Item No.: 4512112  
Bar Code: 4006825655766  
Einhell Accessory



18V 4,0Ah PXC Starter Kit B1  
PXC-Starter-Kit  
Item No.: 4512042  
Bar Code: 4006825613704  
Einhell Accessory

# Battery-Running-Times



cutting<sup>1</sup>  
(pieces)

One Battery for All

1.5 Ah	81
2.0 Ah	108
2.5 Ah	134
3.0 Ah	159
4.0 Ah	212
5.2 Ah	276
6.0 Ah	319
8.0 Ah	425

For best performance select a battery with at least 5.2 Ah

Test setup:

1) wood - scantling 70x70 mm