



Einhell

CLASSIC



Cordless Hedge Trimmer

GC-CH 18/40 Li Solo

Item No.: 3410940

Ident No.: 21011

Bar Code: 4006825661125

The Einhell GC-CH 18/40 Li Solo cordless hedge trimmer is a small, light and handy hedge trimmer from the Power X-Change series. The robust metal gearing is designed for a long service life and caters for perfect delivery of the cordless power to the laser-cut and diamond-ground steel blades. A two-hand safety switch protects the user during operation. This product comes with an aluminium cover for the cutters, an impact guard with holder for wall mounting, and a sturdy bag for storage and transport. One 18V battery from the flexible Power X-Change series is needed to operate the cordless hedge trimmer. This product comes without a battery or charger.

Features & Benefits

- Member of the Power X-Change family, 1x18V batteries necessary
- Small and easy to handle
- Low weight for user-friendly operation
- Blades made of laser-cut and diamond-ground steel
- Metal gearing for a long life
- Two-hand safety switch
- Aluminium cover over cutters
- Shock guard with holder for wall mount
- Sturdy cutter guard for storage and transportation
- Supplied without battery and charger (available separately)



Technical Data

- | | |
|-------------------------|------------------------|
| - Blade length | 475 mm |
| - Cutting length | 400 mm |
| - Spacing between teeth | 13 mm |
| - Cuts per minute | 2400 min ⁻¹ |

Logistic Data

- | | |
|--------------------------------------|--------------------|
| - Product weight | 2 kg |
| - Gross weight single packaging | 2.8 kg |
| - Dimensions single packaging | 865 x 205 x 163 mm |
| - Pieces per export carton | 4 Pieces |
| - Gross weight export carton | 12.76 kg |
| - Dimensions Export Carton | 870 x 425 x 245 mm |
| - Container quantity (20"/40"/40"HC) | 1152 2412 2680 |



Available as special accessories



2x 3,0Ah & Twincharger Kit
PXC-Starter-Kit
Item No.: 4512083
Bar Code: 4006825638509
Einhell Accessory



18V 4-6Ah Multi-Ah PXC Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210
Einhell Accessory



18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



18V 2,0Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



18V 4,0Ah Power X-Change 1
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



18V 4,0Ah PXC Starter Kit 1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



18V 2,5Ah Power X-Change
Battery
Item No.: 4511516
Bar Code: 4006825650518
Einhell Accessory



Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



18V 5,2Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



2x 5,2Ah & Twincharger Kit
PXC-Starter-Kit
Item No.: 4512108
Bar Code: 4006825652376
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



Maintenance spray
Hedge Trimmer Accessory
Item No.: 3403099
Bar Code: 4006825654608
Einhell Accessory



18V Battery Charger 3,0A - PXC
Charger
Item No.: 4514095
Bar Code: 4006825655292
Einhell Accessory



Power X-Car Charger 3A
Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1
PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory



2x 18V 2,5Ah PXC-Twinpack CB
Battery
Item No.: 4511524
Bar Code: 4006825656206
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack
Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory



5,2Ah & 4A Fastcharger
PXC-Starter-Kit
Item No.: 4512114
Bar Code: 4006825656787
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB 1
Battery
Item No.: 4511489
Bar Code: 4006825638578
Einhell Accessory



18V 2,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory



18V 4,0Ah Power-X-Change Plus
Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory



Power X-Boostcharger 6A
Charger
Item No.: 4512064
Bar Code: 4006825629019
Einhell Accessory



18V 3,0Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



18V 3,0 Ah Power-X-Change 2
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory

Battery-Running-Times



One Battery for All

cutting¹
(min.)

1.5 Ah	40
2.0 Ah	53
2.5 Ah	67
3.0 Ah	80
4.0 Ah	106
5.2 Ah	139
6.0 Ah	160
8.0 Ah	212

Test setup:

1) -