



Einhell

EXPERT



Cordless Lawn Trimmer

GE-CT 18/28 Li-Solo

Item No.: 3411242

Ident No.: 21024

Bar Code: 4006825655193

The Einhell cordless lawn trimmer GE-CT 18/28 Li-Solo is a lightweight and powerful Power X-Change system device and is easy to use thanks to the infinitely adjustable second handle, softgrip and the infinitely adjustable telescopic guide rail for individual adaptation to each user's height. The motor head, which can be tilted into 3 different positions, can be rotated through 180°, so that even vertical surfaces and lawn edges can be processed flexibly. The flowerguard protects plants and trees from damage. A thread spool (5 m) with fully automatic thread tracking is included in delivery. Delivery does not include battery or charger. 1x 18 volt battery is required for operation of the cordless lawn trimmer.

Features & Benefits

- Member of the Power X-Change family, 1x18V battery necessary
- Infinitely adjustable second handle
- Telescopic long handle, infinitely adjustable
- Motor head rotatable 180° for vertical surfaces + lawn edges
- Motor head tiltable at 3 settings - versatile working
- Flower guard - protecting flowers and trees against damage
- Incl. line spool (5m) with fully-automatic line feed
- Softgrip - perfect comfort
- Supplied without battery and charger (available separately)

Technical Data

- | | |
|---------------------------|----------------|
| - Revolutions of thread | 8000 rpm |
| - Cutting width of thread | 280 mm |
| - Thread length | 500 cm |
| - Thread diameter | 1.6 mm |
| - Readjustment of thread | Full automatic |
| - Cutting feature | Single line |

Logistic Data

- | | |
|---------------------------------|---------------------|
| - Product weight | 2.1 kg |
| - Gross weight single packaging | 3.4 kg |
| - Dimensions single packaging | 1045 x 241 x 125 mm |
| - Pieces per export carton | 4 Pieces |
| - Gross weight export carton | 14.9 kg |
| - Dimensions export carton | 1060 x 500 x 270 mm |





TILT- AND TURNABLE



FLOWERGUARD



TELESCOPIC



Available as special accessories



Spare line spool GE-CT 18/28
Lawn Trimmer Accessory
Item No.: 3405116
Bar Code: 4006825655216
Einhell Accessory



PXC+ 18V 5-8Ah MULTI
Battery
Item No.: 4511600
Bar Code: 4006825665055
Einhell Accessory



PXC+ 18V 4,0Ah
Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory



PXC+ 18V 4,0Ah SEALED
Battery
Item No.: 4511627
Bar Code: 4006825673227
Einhell Accessory



PXC 18V 3,0Ah
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory



4,0 Ah Power X-Change
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



PXC 18V 2,5Ah
Battery
Item No.: 4511516
Bar Code: 4006825650518
Einhell Accessory



18V 4Ah PXC Plus Twinpack
Battery
Item No.: 4511629
Bar Code: 4006825673685
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB
B1
Battery
Item No.: 4511489
Bar Code: 4006825638578



Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



Power X-Car Charger 3A
Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



18V Battery Charger 3,0A - PXC
Charger
Item No.: 4514095
Bar Code: 4006825655292
Einhell Accessory



18V 4,0Ah PXC Starter Kit A1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



18V 4-6Ah & 6A Boostcharger
PXC-Starter-Kit
Item No.: 4512143
Bar Code: 4006825667653
Einhell Accessory



5,2 Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



3,0 Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



PXC 18V 4,0Ah
Battery
Item No.: 4514079
Bar Code: 4006825674316
Einhell Accessory (Discounter)



PXC+ 18V 3,0Ah SEALED
Battery
Item No.: 4511618
Bar Code: 4006825672794
Einhell Accessory



2,0 Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



4-6 Ah Multi-Ah Power X-Change
Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210



2x 18V 5,2Ah PXC-Twinpack
Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory



18V 3Ah PXC Plus Twinpack
Battery
Item No.: 4511631
Bar Code: 4006825673692
Einhell Accessory



2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



Power X-Boostcharger 8A
Charger
Item No.: 4512155
Bar Code: 4006825670554
Einhell Accessory



18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1
PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory



18V 2,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory



5,2 Ah PXC Starter-Kit
PXC-Starter-Kit
Item No.: 4512147
Bar Code: 4006825675153
Einhell Accessory



4Ah PLUS PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512159
Bar Code: 4006825680331
Einhell Accessory

Battery-Running-Times



trimming¹
(null)

One Battery for All

1.5 Ah	30
2.0 Ah	40
2.5 Ah	45
3.0 Ah	50
4.0 Ah	60
5.2 Ah	70
6.0 Ah	90
8.0 Ah	120

Test setup:
1) lawn