

# CORDLESS CHAIN & BLADE SHARPENER

OPCS-036

EH-Art. No: 30.003.53  
 Ident No: 11018  
 Barcode: 9319510022411  
 Bunnings Item No: 0119785

The Cordless Chain & Blade Sharpener is designed for fast consistent chain and blade sharpening.

The push button variable speed control allows you to adjust the speed to suit the application, providing added control and accuracy.

With the chainsaw chain accessory, you can bring a sharp edge back to your chain to achieve optimal cutting performance. Alternatively, you can use the blade sharpening accessory to maintain a sharp edge on your tool blades, such as mower blades, garden shovels or shears.

## FEATURES & BENEFITS

**Chainsaw Chain Sharpener** – *Brings a sharp edge back to your chainsaw chain to achieve optimal cutting performance.*

**Blade Sharpener** – *Sharpen a range of blades such as mower blades or garden shears.*

**Variable Speed** – *Control the speed to suit the application.*

**Spindle Lock** – *Makes changing accessories easy.*

**USB Charging** – *For increased convenience charge directly from any USB outlet.*



## SPECIFICATIONS

Input – 3.6V

No Load Speed – 5,000 – 18,000/min

Collet Size – 3.2mm

Battery – 1.5Ah Li-Ion

Charge Time – 3-5 Hours

Speeds: 1 - 6

## CONTENTS

- 1 x Cordless Blade & Chain Sharpener
- 1 x Chainsaw Sharpening Guide
- 1 x Blade Sharpening Guide
- 1 x Sharpening Stone
- 3 x Diamond Sharpening Bits, 4, 4.8 & 5mm
- 1 x Wrench
- 1 x AC Charging Adaptor
- 1 x USB Cable
- 1 x Instruction Manual

## LOGISTICS

- Product Weight – 0.2kg
- Single Box Dimensions (LxWxH) - 220 x 50 x 120mm
- Outer Carton Qty – 8 units
- Pallet Quantity - 512 units

