

Cordless Grass Shear RGS 7,2

Art.-No.: 34.104.20

Bar code: 4006825538397

Sales unit: 6 pcs

The mobile Einhell cordless grass shear enables you to trim edges and corner of the lawn neatly and comfortably. The integrated powerful power pack makes you independent of power supply. The power pack can be re-charged with the supplied battery charger. The safety switch blocks an unintended start of the unit. The especially ergonomic designed shear allows a comfortable and fatigue-free operation.

The attachable guide handle makes it possible to work in an upright position. A safety switch is also integrated in the guidance handle itself.

Features:

- Safety switch (1)
- Attachable guide handle (2)
- Castors for easy guidance (3)
- Grass cutting blade (4)
- Charger (not illustrated)

Technical data:

- NiCd-battery: 7.2 V / 1500 mAh
- Cutting width: 85 mm
- Max. running time: 90 min.
- Weight: 2 kg
- Packing dimensions: 600 x 110 x 160 mm

