



# Einhell

# CLASSIC



## Cordless Drill Kit TC-CD 18/35 Li +39 (2x2,0 Ah)

Item No.: 4513957

Ident No.: 21033

Bar Code: 4006825655346

The Einhell cordless drill/screwdriver set TC-CD 18/35 Li +39 (2x2.0 Ah) is a versatile assistant on screwdriving and drilling jobs. PXC technology enables cordless freedom. Equipped with electronic speed control for adjustment to the specific material and application, this cordless drill/screwdriver is ready to provide you with valuable service in many everyday situations. It is always ready-for-use thanks to li-ion technology with zero self-discharge. For operation in dark areas there is an integral LED lamp. Exceptionally easy handling results from the tool's ergonomic design and Softgrip. This product comes with two 2.0 Ah PXC batteries and a high-speed charger, a 39-piece set of bits, 200 screws and a practical E-Box case.

## Features & Benefits

- A member of the Power X-Change family
- Speed electronics for material and application suitable working
- Always Ready-for-use due to Li-ion technology without discharging
- LED lighting for optimum operation in dark areas
- Extremely easy to work with due to ergonomic design and Softgrip
- Supplied with two 2.0 Ah batteries and a Fastcharger
- Incl. 39 pieces bit and drill set and 200 screws
- Supplied in practical storage case E-Box



## Technical Data

- Accumulator	18 V   2000 mAh   Li-Ion
- Charging time	40min
- Number of gears	1
- Idle speed (gear 1)	0-550 min <sup>-1</sup>
- Max. torque hard joint	35 Nm
- Number of torque steps	22 settings
- Drill chuck	10 mm   double sleeve
- Number of accumulators	2 Pieces



## Logistic Data

- Product weight	1.45 kg
- Gross weight single packaging	3.9 kg
- Dimensions single packaging	345 x 95 x 340 mm
- Pieces per export carton	4 Pieces
- Gross weight export carton	17.34 kg
- Dimensions export carton	430 x 365 x 355 mm
- Container quantity (20"/40"/40"HC)	2008   4160   4880



## Available as special accessories



4-6 Ah Multi-Ah Power X-Change Plus Battery  
Item No.: 4511502  
Bar Code: 4006825644210



4,0 Ah Power X-Change Battery  
Item No.: 4511396  
Bar Code: 4006825610376  
Einhell Accessory



2x2 Power X-Quattrocharger 4A Charger  
Item No.: 4512102  
Bar Code: 4006825649536  
Einhell Accessory



2x 5,2Ah & Twincharger Kit PXC-Starter-Kit  
Item No.: 4512108  
Bar Code: 4006825652376  
Einhell Accessory



18V 3,0 Ah Power-X-Change 1 Battery  
Item No.: 4511341  
Bar Code: 4006825590593  
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1 PXC-Starter-Kit  
Item No.: 4512112  
Bar Code: 4006825655766  
Einhell Accessory



5,2Ah & 4A Fastcharger PXC-Starter-Kit  
Item No.: 4512114  
Bar Code: 4006825656787  
Einhell Accessory



3,0 Ah Power X-Change Plus Battery  
Item No.: 4511501  
Bar Code: 4006825644197  
Einhell Accessory



18V 5-8Ah Multi-Ah PXC Plus Battery  
Item No.: 4511600  
Bar Code: 4006825665055  
Einhell Accessory



Handy Bitbox Impact 12tlg. Akku-Bohrschrauber-Zubehör  
Item No.: 49155025  
Bar Code: 4009311550255  
Einhell Accessory



Bitsatz 34 tlg. S-Box Akku-Bohrschrauber-Zubehör  
Item No.: 49108801  
Bar Code: 4009311088017  
Einhell Accessory



Bit-Bohrerbox 39tlg. L-Box Akku-Bohrschrauber-Zubehör  
Item No.: 49108956  
Bar Code: 4009311089564  
Einhell Accessory



5,2 Ah Power X-Change Plus Battery  
Item No.: 4511437  
Bar Code: 4006825616606  
Einhell Accessory



18V 4Ah PXC Plus Twinpack Battery  
Item No.: 4511629  
Bar Code: 4006825673685  
Einhell Accessory



18V 2,5Ah PXC Starter Kit PXC-Starter-Kit  
Item No.: 4512097  
Bar Code: 4006825646962  
Einhell Accessory



18V 4,0Ah PXC Starter Kit A1 PXC-Starter-Kit  
Item No.: 4512042  
Bar Code: 4006825613704  
Einhell Accessory



Power X-Fastcharger 4A Charger  
Item No.: 4512103  
Bar Code: 4006825650228  
Einhell Accessory



Power X-Twincharger 3A Charger  
Item No.: 4512069  
Bar Code: 4006825629729  
Einhell Accessory



Power X-Car Charger 3A Charger  
Item No.: 4512113  
Bar Code: 4006825655377  
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack Battery  
Item No.: 4511526  
Bar Code: 4006825656695  
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB A1 Battery  
Item No.: 4511489  
Bar Code: 4006825638578



Power X-Caravan Charger 3A Charger  
Item No.: 4512136  
Bar Code: 4006825664010  
Einhell Accessory



18V 4-6Ah & 6A Boostcharger PXC-Starter-Kit  
Item No.: 4512143  
Bar Code: 4006825667653  
Einhell Accessory



Bit-Bohrerbox 22tlg. S-Box Akku-Bohrschrauber-Zubehör  
Item No.: 49108806  
Bar Code: 4009311088062  
Einhell Accessory



Power X-Boostcharger 8A Charger  
Item No.: 4512155  
Bar Code: 4006825670554  
Einhell Accessory



18V 4,0Ah Power-X-Change Plus Battery  
Item No.: 4511553  
Bar Code: 4006825660869  
Einhell Accessory



18V 3Ah PXC Plus Twinpack Battery  
Item No.: 4511631  
Bar Code: 4006825673692  
Einhell Accessory



18V 2.0Ah PXC Starter Kit  
 PXC-Starter-Kit  
 Item No.: 4512040  
 Bar Code: 4006825613681  
 Einhell Accessory




2,0 Ah Power X-Change  
 Battery  
 Item No.: 4511395  
 Bar Code: 4006825610369  
 Einhell Accessory



18V Battery Charger 3,0A - PXC  
 Charger  
 Item No.: 4514095  
 Bar Code: 4006825655292  
 Einhell Accessory

## Battery-Running-Times

One Battery for All	 screwing <sup>1</sup> (pieces)
1.5 Ah	220
2.0 Ah	295
2.5 Ah	366
3.0 Ah	440
4.0 Ah	590
5.2 Ah	760
6.0 Ah	880
8.0 Ah	1180

**Test setup:**

1) softwood - 6x60 mm