



# Einhell

# CLASSIC



**Cordless Orbital Sander**

**TC-OS 18/187 Li Solo**

**Item No.: 4460725**

Ident No.: 11018

Bar Code: 4006825642735

The Einhell TC-OS 18/187 Li Solo cordless orbital sander is a light and handy orbital sander from the PXC family, with all the advantages of the flexible, completely interchangeable system series. The orbital sander is ideally suited for grinding/sanding flat surfaces. Thanks to the micro hook-and-loop fastening and clamping device, changing the abrasive paper is quick and easy, but sheets of abrasive paper without hoop-and-loop fastening can also be clamped. For comfortable handling it has large grip surfaces with soft grips. For a clean workplace there is a dust bag and an adapter for a vacuum cleaner included. The product is supplied complete with one sheet of abrasive paper. Supplied without a rechargeable battery or charger.

## Features & Benefits

- Member of the Power X-Change family
- Light, handy orbital sander
- Ideally suited for sanding flat surfaces
- Easy abrasive paper change using micro hook-and-loop fastening
- Also suitable for abrasive paper without hook-and-loop fastening
- Comfortable to handle thanks to large grip areas and soft grip
- Dust bag collects dust from sanding
- Suitable for connecting to an external dust extractor
- Incl. 1 sheet of abrasive paper so you can get started right away
- Supplied without battery and charger (available separately)




## Technical Data

- Oscillating speed 24000 min<sup>-1</sup>
- Oscillating circuit 2 mm
- Sanding area 187 x 90 mm
- Sandpaper size hook and loop connection 187 x 94 mm
- Sandpaper size clamp-connection 237 x 94 mm



## Logistic Data

- Product weight (kg) 1.17
- Gross weight (kg) 1.59
- Dimensions single packaging 225 x 161 x 111 mm
- Pieces per export carton 8 Pieces
- Gross weight of export carton 12.8 kg
- Dimensions export carton 470 x 240 x 335 mm
- Container quantities (20"|40"|40"HC) 5184 | 10800 | 12600



## Available as special accessories



18V 2,0Ah Power X-Change  
Battery  
Item No.: 4511395  
Bar Code: 4006825610369  
Einhell Accessory



18V 4,0Ah Power X-Change 1  
Battery  
Item No.: 4511396  
Bar Code: 4006825610376  
Einhell Accessory



18V 4,0Ah PXC Starter Kit 1  
PXC-Starter-Kit  
Item No.: 4512042  
Bar Code: 4006825613704  
Einhell Accessory



18V 5,2Ah Power X-Change Plus  
Battery  
Item No.: 4511437  
Bar Code: 4006825616606  
Einhell Accessory



Power X-Twincharger 3A  
Charger  
Item No.: 4512069  
Bar Code: 4006825629729  
Einhell Accessory



18V 2,0Ah PXC Starter Kit  
PXC-Starter-Kit  
Item No.: 4512040  
Bar Code: 4006825613681  
Einhell Accessory



Power X-Boostcharger 6A  
Charger  
Item No.: 4512064  
Bar Code: 4006825629019  
Einhell Accessory



15 Q-Stick Schleifst. 187x93mm  
Schwingschleifer-Zubehör  
Item No.: 49817985  
Bar Code: 4009318179855  
Einhell Accessory



18V 3,0 Ah Power-X-Change 2  
Battery  
Item No.: 4511341  
Bar Code: 4006825590593  
Einhell Accessory

## Battery-Running-Times



running time<sup>1</sup>  
(min.)

One Battery for All

One Battery for All	running time <sup>1</sup> (min.)
1.5 Ah	25
2.0 Ah	34
2.5 Ah	42
3.0 Ah	50
4.0 Ah	67
5.2 Ah	87
6.0 Ah	100
8.0 Ah	134

Test setup:

1) no-load