



# Einhell

## EXPERT PLUS



Cordless Tiller

**GE-CR 30 Li-Solo**

**Item No.: 3431200**

Ident No.: 11029

Bar Code: 4006825615203

The Einhell GE-CR 30 Li - Solo cordless hoe is a handy helper for loosening up the soil in small- to medium-sized front and back yards. As a member of the Power X-Change family it is powered by two 18 V batteries. Four robust cultivator blades offer a working width of 300 mm and a depth of up to 200 mm. For comfortable operation there is, firstly, an ergonomic, folding long handle. Secondly, the hoe also has height-adjustable transport wheels. Extra safety is provided by the two-point safety switch. This product comes without batteries or chargers. These are available separately.

## Features & Benefits

- Member of the Power X-Change family, 2x18V batteries necessary
- Two-point safety switch
- Folding handle
- Ergonomic handle with soft grip
- Robust cultivator blades
- Height-adjustable wheels for easy transportation
- Supplied without battery and charger (available separately)

## Technical Data

- Working width	30 cm
- Working depth	200 mm
- Number of knives	4 Pieces
- No-load speed	140 min <sup>-1</sup>
- Diameter of cultivating blade	200 mm

## Logistic Data

- Product weight (kg)	8.2
- Gross weight (kg)	10.75
- Dimensions single packaging	385 x 338 x 540 mm
- Pieces per export carton	1 Pieces
- Gross weight of export carton	10.65 kg
- Dimensions export carton	385 x 335 x 535 mm
- Container quantity (20"/40"/40"HC)	400   820   952



HEIGHT-ADJUSTABLE WHEELS



4 PCS. CULTIVATOR BLADES




TWO-POINT SAFETY SWITCH




FOLDING HANDLE



36 V  
POWER  
2 x 18 V



WORKING WIDTH  
300 mm



WORKING DEPTH  
max. 200 mm

## Available as special accessories



Power X-Boostcharger 6A  
Charger  
Item No.: 4512064  
Bar Code: 4006825629019  
Einhell Accessory



18V 2,0Ah Power X-Change  
Battery  
Item No.: 4511395  
Bar Code: 4006825610369  
Einhell Accessory



18V 3,0Ah PXC Starter Kit  
PXC-Starter-Kit  
Item No.: 4512041  
Bar Code: 4006825613698  
Einhell Accessory



18V 4,0Ah PXC Starter Kit  
PXC-Starter-Kit  
Item No.: 4512042  
Bar Code: 4006825613704  
Einhell Accessory



18V 4,0Ah Power X-Change  
Battery  
Item No.: 4511396  
Bar Code: 4006825610376  
Einhell Accessory



18V 5,2Ah Power X-Change Plus  
Battery  
Item No.: 4511437  
Bar Code: 4006825616606  
Einhell Accessory




Power X-Twincharger 3A  
Charger  
Item No.: 4512069  
Bar Code: 4006825629729  
Einhell Accessory



18V 3,0 Ah Power-X-Change  
Battery  
Item No.: 4511341  
Bar Code: 4006825590593  
Einhell Accessory

## Battery-Running-Times

One Battery for All	 soil tilling <sup>1</sup> (min.)
1.5 Ah	15
2.0 Ah	20
2.5 Ah	21
3.0 Ah	25
4.0 Ah	35
5.2 Ah	50
6.0 Ah	60

For best performance select a battery with at least 2.5 Ah

Test setup:

1) -