Einhell PROFESSIONAL

POWER X-CHANGE

Cordless Pruning Shears

GP-LS 18/35 Li BL-Solo

Item No.: 3408360

Ident No.: 21014

Bar Code: 4006825684049

The Einhell Professional Cordless Pruning Shears GP-LS 18/35 Li BL-Solo are perfect for trimming roses, shrubs, perennials, and fruit trees - whether for professional or home use. As part of the Power X-Change family, they are compatible with all batteries and chargers in the range. Powered by an Einhell brushless motor, they deliver increased power and a longer lifespan. After online registration, the motor is covered by a 10-year warranty. The sharp SK5 steel bypass blades cut branches up to 35 mm thick without crushing. The cutting capacity can be adjusted to 25 mm at the touch of a button. A metal hook assists in removing cut branches, while a steel frame protects the battery. Supplied without a battery.

Features & Benefits

- Member of the Power X-Change family, requires 1x 18 V battery
- Brushless motor – more power and longer runtime
- Brushless – 10-year motor warranty after registration
- Adjustable cutting capacity for thinner or thicker branches
- Effortless cutting of branches up to 35 mm thick
- Faster cuts on thin branches with 25 mm cutting capacity
- Suitable for working at heights of up to 3 m
- Metal hook for pulling down cut branches
- Bypass blades made of SK5 steel for efficient cutting
- Clean, sharp cuts close to the branch for optimal growth
- Sturdy blade cover for safe storage
- Steel frame for effective battery protection
- Comfortable handling with a slim design and soft grip
- Supplied without battery and charger (available separately)

Technical Data

- Cutting width	35 mm
- Reduced cutting width	25 mm

Logistic Data

- Product weight (kg)	1.6
- Gross weight (kg)	2.3
- Dimensions single packaging	1048 x 80 x 128 mm
- Pieces per export carton	4 Pieces
- Gross weight of export carton	11.9 kg
- Dimensions export carton	1070 x 380 x 280 mm
- Container quantity (20"/40"/40"HC)	1024 | 2112 | 2376

Illustrations can contain accessories, which are not included in standard extent of delivery
Illustration similar (in design), production-wise modifications reserved
GS mark belongs to the product itself only, excluded accessory

Available as special accessories

PXC Battery Mounting Gadget
PXC-Battery Accessory
Item No.: 4514155
Bar Code: 4006825658774
Einhell Accessory

PXC+ 18V 5-8Ah MULTI
Battery
Item No.: 4511600
Bar Code: 4006825665055
Einhell Accessory

PXC+ 18V 4,0Ah
Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory

PXC 18V 3,0Ah
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory

2,0 Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory

4-6 Ah Multi-Ah Power X-Change
Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210

18V 4Ah PXC Plus Twinpack
Battery
Item No.: 4511629
Bar Code: 4006825673685
Einhell Accessory

2x18V 4,0Ah PXC-Twinpack CB
B1
Battery
Item No.: 4511489
Bar Code: 4006825638578

Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory

Power X-Car Charger 3A
Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory

18V Battery Charger 3,0A - PXC
Charger
Item No.: 4514095
Bar Code: 4006825655292
Einhell Accessory

2x 4,0Ah & Twincharger Kit 1
PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory

18V 4,0Ah PXC Starter Kit B1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory

5,2 Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory

PXC+ 18V 4,0Ah SEALED
Battery
Item No.: 4511627
Bar Code: 4006825673227
Einhell Accessory

PXC+ 18V 3,0Ah SEALED
Battery
Item No.: 4511618
Bar Code: 4006825672794
Einhell Accessory

3,0 Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory

4,0 Ah Power X-Change
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory

2x 18V 5,2Ah PXC-Twinpack
Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory

18V 3Ah PXC Plus Twinpack
Battery
Item No.: 4511631
Bar Code: 4006825673692
Einhell Accessory

2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory

Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory

Power X-Boostcharger 8A
Charger
Item No.: 4512155
Bar Code: 4006825670554
Einhell Accessory

18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory

18V 4-6Ah & 6A Boostcharger
PXC-Starter-Kit
Item No.: 4512143
Bar Code: 4006825667653
Einhell Accessory

Illustrations can contain accessories, which are not included in standard extent of delivery
Illustration similar (in design), production-wise modifications reserved
GS mark belongs to the product itself only, excluded accessory

Battery-Running-Times

One Battery for All	cutting[1] (pieces)
1.5 Ah	1300
2.0 Ah	1700
2.5 Ah	2300
3.0 Ah	2800
4.0 Ah	3500
5.2 Ah	4800
6.0 Ah	5600
8.0 Ah	7100

Test setup:

1) wood - round dry beech wood Ø 15 mm

Illustrations can contain accessories, which are not included in standard extent of delivery
Illustration similar (in design), production-wise modifications reserved
GS mark belongs to the product itself only, excluded accessory