



Einhell

EXPERT PLUS



Power Tool Kit

18V 2.0Ah Twinpack

Item No.: 4257214

Ident No.: 21033

Bar Code: 4006825614817

With the Einhell machine set, featuring a practical Power X-Change starter kit and a storage bag, you are well-equipped for the essential basics. The Einhell cordless impact drill TE-CD 18/2 Li-i is a powerful all-rounder for home, workshop, and garage use. The powerful 2-speed gearbox ensures efficient screwing and drilling. For the additionally included Einhell cordless impact wrench TE-CI 18/1 Li in the set, long and large screws pose no problem, just like delicate tasks. The battery impact drill set is delivered with a convenient storage bag, two 2.0 Ah batteries, and a fast charger.

Features & Benefits




- Power X-Change system battery – can also be used for products
- 2x Li-Ion battery: no self-discharging/small/light/easy to handle
- Cordless Impact Drill TE-CD 18/2 Li-i
- 3 functions: screwdriving, drilling, hammer drilling in masonry
- 2-speed gearing for powerful screwdriving and fast drilling
- Powerful motor and metal gearing for high torque
- Single-sleeve 13 mm quick-change drill chuck with Quick-Stop
- Automatic spindle lock for easy tool change
- Cordless Impact Screwdriver TE-CI 18/1 Li
- Impact driver – for easy tightening of large/long screws
- Unique Triathlon motor (powerful, fast, efficient)
- Standard allen screw mount (Recommendation: impact-resistant bit)
- 3 power LEDs included for good allround illumination
- 40 min high-speed charger (Power X-Change system charger)



Technical Data

Logistic Data

- Product weight (kg)	3
- Gross weight (kg)	5.5
- Dimensions single packaging	445 x 235 x 295 mm
- Pieces per export carton	2 Pieces
- Product weight	3 kg
- Gross weight export carton	11.46 kg
- Gross weight single packaging	5.5 kg
- Dimensions export carton	495 x 465 x 325 mm
- Container quantity (20"/40"/40"HC)	748 1544 1790



Available as special accessories



4-6 Ah Multi-Ah Power X-Change Plus Battery
Item No.: 4511502
Bar Code: 4006825644210



4,0 Ah Power X-Change Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



Power X-Fastcharger 4A Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



Power X-Twincharger 3A Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



Power X-Car Charger 3A Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory



PXC Battery Mounting Gadget PXC-Battery Accessory
Item No.: 4514155
Bar Code: 4006825658774
Einhell Accessory



Power X-Caravan Charger 3A Charger
Item No.: 4512136
Bar Code: 4006825664010
Einhell Accessory



18V 4-6Ah & 6A Boostcharger PXC-Starter-Kit
Item No.: 4512143
Bar Code: 4006825667653
Einhell Accessory



5,2 Ah Power X-Change Plus Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



18V 4,0Ah Power-X-Change Plus Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory



18V 4,0Ah SEALED PXC Plus A1 Battery
Item No.: 4511627
Bar Code: 4006825673227
Einhell Accessory



18V 3Ah PXC Plus Twinpack Battery
Item No.: 4511631
Bar Code: 4006825673692
Einhell Accessory



2,0 Ah Power X-Change Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



18V 2,5Ah PXC Starter Kit PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



2x2 Power X-Quattrocharger 4A Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



2x 5,2Ah & Twincharger Kit PXC-Starter-Kit
Item No.: 4512108
Bar Code: 4006825652376
Einhell Accessory



18V 3,0 Ah Power-X-Change 1 Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1 PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory



5,2Ah & 4A Fastcharger PXC-Starter-Kit
Item No.: 4512114
Bar Code: 4006825656787
Einhell Accessory



3,0 Ah Power X-Change Plus Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



18V 5-8Ah Multi-Ah PXC Plus Battery
Item No.: 4511600
Bar Code: 4006825665055
Einhell Accessory



Power X-Boostcharger 8A Charger
Item No.: 4512155
Bar Code: 4006825670554
Einhell Accessory



PXC Battery Protector PXC-Battery Accessory
Item No.: 4140151
Bar Code: 4006825670844
Einhell Accessory



18V 3,0Ah SEALED PXC Plus A2 Battery
Item No.: 4511618
Bar Code: 4006825672794
Einhell Accessory



18V 4Ah PXC Plus Twinpack Battery
Item No.: 4511629
Bar Code: 4006825673685
Einhell Accessory



18V 2,0Ah PXC Starter Kit PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory



18V Battery Charger 3,0A - PXC Charger
Item No.: 4514095
Bar Code: 4006825655292
Einhell Accessory



5,2 Ah PXC Starter-Kit
PXC-Starter-Kit
Item No.: 4512147
Bar Code: 4006825675153
Einhell Accessory



18V 4,0Ah PXC Starter Kit B1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB
B1
Battery
Item No.: 4511489
Bar Code: 4006825638578