



Einhell

BLUE

BG-CG 7,2 Cordless Grass Shear

Art.-No. 34.104.24

The cordless grass shear enables you to trim edges and corner of the lawn neatly and comfortably. The integrated powerful power pack makes you independent of power supply. The power pack can be re-charged with the supplied battery charger. The safety switch blocks an unintended start of the unit. The especially ergonomic designed shear allows a comfortable and fatigue-free operation. The attachable guide handle makes it possible to work in an upright position. A safety switch is also integrated in the guidance handle itself.

Features

- Safety switch (1)
- Grass cutting blade (2)
- Castors for easy guidance (3)
- Attachable guide handle (4)
- Charger (not illustrated)

Technical Data

- | | |
|------------------------|--------------------|
| ■ NiCd-charger: | 7.2 V / 1,200 mAh |
| ■ Cutting width: | 85 mm |
| ■ Max. operating time: | 60 min. |
| ■ Net weight: | 1.4 kg |
| ■ Gross weight: | 2.1 kg |
| ■ Packing dimensions: | 600 x 110 x 160 mm |
| ■ Bar code: | 4006825 548358 |
| ■ Sales unit: | 6 pcs |

