

# GETTING STARTED

1. Connect the charger unit to the power supply.
2. Insert the Grass & Hedge trimmer in to the charger unit.
3. Allow unit to charge for 5-7 hours.
4. Once unit is fully charged, choose required blade and insert in to the unit.
5. Your Grass & Hedge trimmer is now ready for use.

**Please note this machine is designed to be used with one hand only. Your free hand should be kept well clear of the cutting blade at all times**

6. If in any doubt refer to the manual provided.

UK Help line Number: 0044 (0) 151 649 1500

Republic of Ireland Help line Number: 189 094 6244