Einhell

EXPERT

POWER X-CHANGE

Cordless Sliding Mitre Saw

TE-SM 36/10 L Li-Solo

Item No.: 4300885

Ident No.: 21011

Bar Code: 4006825665239

As a member of the Power X-Change family, the Einhell TE-SM 36/10 L Li-Solo cordless sliding cross-cut mitre saw can be used anywhere: No need to search for a socket, and no annoying cables. It features a smooth-running sliding mechanism and a high-quality HW precision blade, while the X-Tend workpiece supports can be easily adjusted with just one hand. The clamping device is used to hold the workpiece securely in place. The turntable enables precise angle adjustments with locking positions, and the saw head can also be tilted up to 45° to the left. A cutting line laser and an LED light make for easy cutting. The tool does not come with a battery or charger.

Features & Benefits

- Member of the Power X-Change family
- Unlimited range of operation, no annoying cables, no need to rewind
- Smooth sliding motion even for wider workpieces
- Rotary table with precise angle adjustment for angled cuts
- Saw head can be tilted up to 45° to the left for mitre cuts
- X-Tend workpiece supports with tool-free single-hand adjustment
- High-quality HW precision saw blade
- Cutting line laser and LED for fast and safe cuts
- Clamping device to hold the workpiece firmly in place
- Chip catcher bag or extractor keep both the workspace and the air clean

Technical Data

- No-load speed (idle speed)	3800 min^-1
- Saw blade	254 x 30 mm
- Mitre cut	45 ° - 0 °
- Swiveling range	47 ° - 47 °
- Cutting capacity 90° x 90°	340 x 85 mm
- Cutting capacity 90° x 45°	240 x 85 mm
- Cutting capacity 45° x 90°	340 x 47 mm
- Cutting capacity 45° x 45°	240 x 47 mm
- Diameter of suction adapter	36 mm

Logistic Data

- Product weight (kg)	13.8 kg
- Gross weight (kg)	18.85 kg
- Dimensions single packaging	810 x 610 x 430 mm
- Pieces per export carton	1 Pieces
- Gross weight of export carton	18.85 kg
- Dimensions export carton	810 x 610 x 430 mm
- Container quantity (20"/40"/40"HC)	125 | 260 | 315



Illustrations can contain accessories, which are not included in standard extent of delivery
Illustration similar (in design), production-wise modifications reserved
GS mark belongs to the product itself only, excluded accessory

Available as special accessories

E-Stand
Stationary Saw Accessory
Item No.: 4310620
Bar Code: 4006825584974
Einhell Accessory

MSS 1608
Stationary Saw Accessory
Item No.: 4310614
Bar Code: 4006825660050
Einhell Accessory

Sbl D 254x30x3,2 T60
Stationary Saw Accessory
Item No.: 49589561
Bar Code: 4009315895611
Einhell Accessory

PXC+ 18V 5-8Ah MULTI
Battery
Item No.: 4511600
Bar Code: 4006825665055
Einhell Accessory

PXC 18V 3,0Ah
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory

2,0 Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory

4-6 Ah Multi-Ah Power X-Change Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210

2x 18V 5,2Ah PXC-Twinpack
Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory

2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory

Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory

18V Battery Charger 3,0A - PXC
Charger
Item No.: 4514095
Bar Code: 4006825655292
Einhell Accessory

2x 5,2Ah & Twincharger Kit
PXC-Starter-Kit
Item No.: 4512108
Bar Code: 4006825652376
Einhell Accessory

18V 4-6Ah & 6A Boostcharger
PXC-Starter-Kit
Item No.: 4512143
Bar Code: 4006825667653
Einhell Accessory

18V 4,0Ah PXC Starter Kit B1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory

MSS 1610
Stationary Saw Accessory
Item No.: 4310615
Bar Code: 4006825637496
Einhell Accessory

Sbl D 254x30x3,2 T48
Stationary Saw Accessory
Item No.: 49589551
Bar Code: 4009315895512
Einhell Accessory

5,2 Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory

PXC+ 18V 4,0Ah
Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory

3,0 Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory

4,0 Ah Power X-Change
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory

PXC 18V 2,5Ah
Battery
Item No.: 4511516
Bar Code: 4006825650518
Einhell Accessory

2x18V 4,0Ah PXC-Twinpack CB B1
Battery
Item No.: 4511489
Bar Code: 4006825638578

Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory

Power X-Car Charger 3A
Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory

18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory

2x 4,0Ah & Twincharger Kit 1
PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory

18V 2,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory

Illustrations can contain accessories, which are not included in standard extent of delivery
Illustration similar (in design), production-wise modifications reserved
GS mark belongs to the product itself only, excluded accessory

Battery-Running-Times

One Battery for All	cutting[1] (number of)	cutting[2] (number of)
1.5 Ah	268	131
2.0 Ah	358	175
2.5 Ah	447	219
3.0 Ah	537	263
4.0 Ah	716	350
5.2 Ah	931	456
6.0 Ah	1074	526
8.0 Ah	1432	701

Test setup:

1) laminate - laminate 195x8 mm

2) softwood - scantling 60x60 mm

Illustrations can contain accessories, which are not included in standard extent of delivery
Illustration similar (in design), production-wise modifications reserved
GS mark belongs to the product itself only, excluded accessory