



Einhell

ACCESSORY

System Carrying Case

E-Case M

Item No.: 4540021

Ident No.: 21024

Bar Code: 4006825667721

The Einhell E-Case M is a member of Einhell's modular E-Case system. The case is suitable for storing and transporting machines and tools. The locking system for easy connection of stacked cases enables safe transport and easy storage. The case is made of polypropylene, which is splash-proof, heat-resistant and impact-resistant thanks to the high-quality material. The inner height of 25 cm is optimised for large Einhell products. A foldable ergonomic handle ensures comfortable wearing. The case can be equipped with a padlock and contains an insert for hand tools and stickers for labelling.

Features & Benefits

- Member of the modular E-Case-System from Einhell
- System case for storing/transporting machines & tools
- Locking system for securely connecting stacked cases
- Easy storage and transport of stacked cases
- Made of high-quality polypropylene
- Heat-resistant and impact-resistant
- Internal height of 25 cm optimal for large Einhell products
- Ease of use: Stacked cases can be opened
- Splash-proof design
- Foldable, ergonomic handle for comfortable carrying
- Sturdy construction for loads up to 90 kg
- Can be equipped with a padlock as an anti-theft device
- Includes 1x insert for hand tools
- Includes stickers for labelling




Technical Data

Logistic Data

- Product weight (kg)	2.71
- Gross weight (kg)	3.4
- Dimensions single packaging	451 x 344 x 323 mm
- Pieces per export carton	1 Pieces
- Gross weight of export carton	3.65 kg
- Dimensions export carton	470 x 345 x 320 mm
- Container quantities (20"/40"/40"HC)	564 1182 1350



E-CASE-SYSTEM



The following Power X-Change devices fit into E-Case M

(1x Power X-Charger + 2x 3,0 Ah PXC Plus Akku)



Item no	Tpg code	Description	Description 2	Product picture
4609990_21023	O-C-01	TE-CF 18 Li-Solo	Cordless Coffee Maker	
3408017_21010	PT-C-BT-02	TC-RA 18 Li BT - Solo	Cordless Radio	
3407995_21014	PT-C-BT-02	TE-CR 18 Li DAB+/FM/BT - Solo	Cordless Radio	
3407995_21014	PT-C-BT-02	TE-CR 18 Li DAB+/FM/BT - Solo	Cordless Radio	
4260025_21023	PT-C-BT-03	TC-SY 18/60 Li-Solo	Cl.Paint Spray Sys (Spray Gun)	
4260025_21023	PT-C-BT-03	TC-SY 18/60 Li-Solo	Cl.Paint Spray Sys (Spray Gun)	
1091320_21014	PT-C-BT-06	TC-ES 18/150/1 Li-Solo	Cordless Energy Station	
1091320_21014	PT-C-BT-06	TC-ES 18/150/1 Li-Solo	Cordless Energy Station	
1091310_21014	PT-C-BT-06	TE-ES 18/150/1 Li-C-Solo	Cordless Energy Station	
1091310_21014	PT-C-BT-06	TE-ES 18/150/1 Li-C-Solo	Cordless Energy Station	
4514150_11019	PT-C-BT-10	TC-SR 18 Li BT - Solo	Cordless Speaker	
4020467_21011	PT-C-DT-01	PRESSITO 18/21	Cordless Air Compressor	
4020420_21011	PT-C-DT-01	PRESSITO 18/25	Cordless Air Compressor	

4020469_21015	PT-C-DT-01	TC-AK 18 Li - Solo	Cordless Air Compressor	
4020469_21015	PT-C-DT-01	TC-AK 18 Li - Solo	Cordless Air Compressor	
4513812_21021	PT-C-EW-01	TE-HD 18 Li-Solo	Cordless Rotary Hammer	
4513970_21023	PT-C-EW-01	TE-HD 18/12 Li - Solo	Cordless Rotary Hammer	
4514107_21015	PT-C-EW-01	TC-BH 18-3B Li - Solo	Cordless Rotary Hammer	
4513997_21010	PT-C-EW-02	TE-CD 18/40 Li BL - Solo	Cordless Drill	
4514210_21010	PT-C-EW-02	TP-CD 18/60 Li BL - Solo	Cordless Drill	
4513927_21021	PT-C-EW-02	TC-CD 18/35 Li - Solo	Cordless Drill	
4513887_21032	PT-C-EW-02	TP-CD 18/50 Li BL-Solo	Cordless Drill	
4513925_11018	PT-C-EW-02	TE-CD 18/40 Li-Solo	Cordless Drill	
4514335_21014	PT-C-EW-02	TP-CD 18/70-C Li BL - Solo	Cordless Drill	
4514365_21015	PT-C-EW-02	TC-CD 18/38 Li - Solo	Cordless Drill	
4514345_21015	PT-C-EW-02	TE-CD 18/50 Li - Solo	Cordless Drill	
4510034_21021	PT-C-EW-06	TE-CI 18/1 Li-Solo	Cordless Impact Driver	
4510085_21013	PT-C-EW-06	TP-CI 18/220 Li BL - Solo	Cordless Impact Driver	

4510095_21014	PT-C-EW-06	TP-CI 18/250-C Li BL - Solo	Cordless Impact Driver	
4326290_21010	PT-C-EW-09	TE-AP 18/26 Li - Solo	Cordless All Purpose Saw	
4326310_21043	PT-C-EW-09	TP-AP 18/28 Li BL - Solo	Cordless All Purpose Saw	
4326315_21013	PT-C-EW-09	TE-AP 18/13 Li - Solo	Cordless All Purpose Saw	
4326300_21043	PT-C-EW-09	TE-AP 18/22 Li-Solo	Cordless All Purpose Saw	
4326300_21043	PT-C-EW-09	TE-AP 18/22 Li-Solo	Cordless All Purpose Saw	
4326295_21014	PT-C-EW-09	TP-AP 18/32 Li BL - Solo	Cordless All Purpose Saw	
4326315_21013	PT-C-EW-09	TE-AP 18/13 Li - Solo	Cordless All Purpose Saw	
4432010_21014	PT-C-EW-10	TE-UC 18/6 Li - Solo	Cordless Multicutter	
4432010_21014	PT-C-EW-10	TE-UC 18/6 Li - Solo	Cordless Multicutter	
4514091_21011	PT-C-EW-11	TC-AL 18 Li - Solo	Cordless Light	
4514145_11019	PT-C-EW-11	TE-CL 18/2500 LiAC-solo	Cordless Light	
4514114_11018	PT-C-EW-11	TE-CL 18/2000 LiAC - Solo	Cordless Light	
4514180_21013	PT-C-EW-11	TE-CL 18/1000 S Li - Solo	Cordless Light	
4514130_21055	PT-C-EW-11	TC-CL 18 Li H-Solo	Cordless Light	

4514130_21055	PT-C-EW-11	TC-CL 18 Li H-Solo	Cordless Light	
4514152_21015	PT-C-EW-11	TE-CL 18/2500 Li - Solo	Cordless Light	
4514180_21013	PT-C-EW-11	TE-CL 18/1000 S Li - Solo	Cordless Light	
4465170_21020	PT-C-EW-12	TC-MG 18 Li-Solo	Cordless Multifunctional Tool	
4465195_21013	PT-C-EW-12	TE-MG 18/1 Li - Solo	Cordless Multifunctional Tool	
4465195_21013	PT-C-EW-12	TE-MG 18/1 Li - Solo	Cordless Multifunctional Tool	
4465197_21015	PT-C-EW-12	TC-MFW 18 Li-Solo	Cordless Multifunctional Tool	
4465197_21015	PT-C-EW-12	TC-MFW 18 Li-Solo	Cordless Multifunctional Tool	
4465160_21055	PT-C-EW-12	VARRITO	Cordless Multifunctional Tool	
4465160_21055	PT-C-EW-12	VARRITO	Cordless Multifunctional Tool	
4465190_21025	PT-C-EW-12	TP-MG 18 Li BL - Solo	Cordless Multifunctional Tool	
4331210_21021	PT-C-EW-13	TP-CS 18/190 Li BL - Solo	Cordless Circular Saw	
4331207_21021	PT-C-EW-13	TE-CS 18/165-1 Li - Solo	Cordless Circular Saw	
4331220_21032	PT-C-EW-13	TE-CS 18/150 Li - Solo	Cordless Circular Saw	
4331225_21013	PT-C-EW-13	TP-CS 18/165 Li BL - Solo	Cordless Circular Saw	

4331225_21013	PT-C-EW-13	TP-CS 18/165 Li BL - Solo	Cordless Circular Saw	
4331230_21014	PT-C-EW-13	TE-CS 18/165-2 Li - Solo	Cordless Circular Saw	
4331230_21014	PT-C-EW-13	TE-CS 18/165-2 Li - Solo	Cordless Circular Saw	
4331235_21014	PT-C-EW-13	TE-CS 18/150-2 Li - Solo	Cordless Circular Saw	
4331213_21014	PT-C-EW-13	TP-CS 18/1900 Z Li BL - Solo	Cordless Circular Saw	
4331240_21014	PT-C-EW-13	TP-CS 18/136-C Li BL - Solo	Cordless Circular Saw	
4331240_21014	PT-C-EW-13	TP-CS 18/136-C Li BL - Solo	Cordless Circular Saw	
4321200_21031	PT-C-EW-14	TE-JS 18/80 Li-Solo	Cordless Jig Saw	
4321260_21011	PT-C-EW-14	TP-JS 18/135 Li BL - Solo	Cordless Jig Saw	
4321209_21031	PT-C-EW-14	TC-JS 18 Li - Solo	Cordless Jig Saw	
4321270_21013	PT-C-EW-14	TE-JS 18/100 Li - Solo	Cordless Jig Saw	
4321270_21013	PT-C-EW-14	TE-JS 18/100 Li - Solo	Cordless Jig Saw	
4513926_21020	PT-C-EW-15	TE-CD 18/48 Li-i-Solo	Cordless Impact Drill	
4514205_21010	PT-C-EW-15	TP-CD 18/60 Li-i BL Solo	Cordless Impact Drill	
4513860_21041	PT-C-EW-15	TP-CD 18 Li-i Brushless-Solo	Cordless Impact Drill	

4513942_21032	PT-C-EW-15	TP-CD 18/50 Li-i BL-Solo	Cordless Impact Drill	
4514315_21013	PT-C-EW-15	TP-CD 18/70 Li-i BL - Solo	Cordless Impact Drill	
4514340_21014	PT-C-EW-15	TP-CD 18/70-C Li-i BL - Solo	Cordless Impact Drill	
4514346_21015	PT-C-EW-15	TE-CD 18/52 Li-i - Solo	Cordless Impact Drill	
4514019_21014	PT-C-EW-15	TE-CD 18/50 Li-i-Solo	Cordless Impact Drill	
4460708_21020	PT-C-EW-16	TE-OS 18/150 Li Solo	Cordless Multiple Sander	
4431165_21011	PT-C-EW-17	TE-AG 18/115 Q Li Solo	Cordless Angle Grinder	
4431168_21013	PT-C-EW-17	TE-AG 18/125-2 Li - Solo	Cordless Angle Grinder	
4431168_21013	PT-C-EW-17	TE-AG 18/125-2 Li - Solo	Cordless Angle Grinder	
4431150_21043	PT-C-EW-17	AXXIO 18/115 Q	Cordless Angle Grinder	
4431154_21024	PT-C-EW-17	AXXIO 18/115	Cordless Angle Grinder	
4431140_21064	PT-C-EW-17	AXXIO 18/125	Cordless Angle Grinder	
4431151_21054	PT-C-EW-17	AXXIO 18/125 Q	Cordless Angle Grinder	
4514410_21024	PT-C-EW-17	TC-AG 18/8500 Li - Solo	Cordless Angle Grinder	
4431161_21015	PT-C-EW-17	TP-AG 36/230-22 Li BL - Solo	Cordless Angle Grinder	

4431160_21024	PT-C-EW-17	AXXIO 36/230 Q	Cordless Angle Grinder	
4431155_21024	PT-C-EW-17	TP-AG 18/125 CE Q Li - Solo	Cordless Angle Grinder	
4431110_21054	PT-C-EW-17	TE-AG 18/115 Li-Solo	Cordless Angle Grinder	
4431130_21034	PT-C-EW-17	TC-AG 18/115 Li-Solo	Cordless Angle Grinder	
4431130_21034	PT-C-EW-17	TC-AG 18/115 Li-Solo	Cordless Angle Grinder	
4431175_21013	PT-C-EW-17	TP-AG 18/125 F Li BL - Solo	Cordless Angle Grinder	
4460725_11018	PT-C-EW-18	TC-OS 18/187 Li Solo	Cordless Orbital Sander	
4460720_11018	PT-C-EW-18	TE-OS 18/230 Li Solo	Cordless Orbital Sander	
4514160_21011	PT-C-EW-30	TE-DA 18/760 Li Solo	Cordless Drain Cleaner	
4257785_21044	PT-C-EW-45	FIXETTO 18/40 S	Cordless Tacker	
4257785_21044	PT-C-EW-45	FIXETTO 18/40 S	Cordless Tacker	
4522200_11018	PT-C-EW-47	TE-CG 18 Li - Solo	Cordless Hot Glue Gun	
3408001_11017	PT-C-EW-49	TE-CB 18/180 Li-Solo	Cordless Blower	
3408045_21015	PT-C-EW-49	TE-CB 18/270 Li - Solo	Cordless Blower	
4462010_21031	PT-C-EW-51	TE-RS 18 Li-Solo	Cordless Rotating Sander	

4345400_11019	PT-C-EW-56	TE-PL 18/82 Li - Solo	Cordless Planer	
4520500_11019	PT-C-EW-58	TE-HA 18 Li - Solo	Cordless Hot Air Gun	
4466270_21011	PT-C-EW-60	TP-BS 18/457 Li BL - Solo	Cordless Belt Sander	
4513960_21023	PT-C-EW-61	TE-ID 18 Li - Solo	Cordless Hammer Drill	
4257790_21010	PT-C-EW-63	TE-CN 18 Li - Solo	Cordless Nailer	
4257800_21014	PT-C-EW-63	TE-CN 18/32 Li - Solo	Cordless Nailer	
4257795_21024	PT-C-EW-63	FIXETTO 18/50 N	Cordless Nailer	
4257795_21024	PT-C-EW-63	FIXETTO 18/50 N	Cordless Nailer	
4257800_21014	PT-C-EW-63	TE-CN 18/32 Li - Solo	Cordless Nailer	
4331100_21022	PT-C-EW-64	TE-CS 18/89 Li - Solo	Cordless Mini Circular Saw	
4350412_21011	PT-C-EW-65	TP-ET 18 Li BL - Solo	Cordless Palm Router	
4350630_21011	PT-C-EW-71	TE-BJ 18 Li - Solo	Cordless Biscuit Joiner	
4350411_21023	PT-C-EW-72	TP-RO 18 Li BL - Solo	Cordless Router	
4350425_21014	PT-C-EW-72	TP-RO 18/55 Li BL - Solo	Cordless Router	
4514320_21024	PT-C-EW-73	TE-RW 18/60 Li-Solo	Cordless Ratchet Wrench	

4514320_21024	PT-C-EW-73	TE-RW 18/60 Li-Solo	Cordless Ratchet Wrench	
4461000_21012	PT-C-EW-74	TE-BF 18 Li - Solo	Cordless Belt File	
4460730_21012	PT-C-EW-75	TE-OS 18/113 3X Li - Solo	Cordless Palm Sander	
4460731_21012	PT-C-EW-75	TE-OS 18/113 Li - Solo	Cordless Palm Sander	
4460731_21012	PT-C-EW-75	TE-OS 18/113 Li - Solo	Cordless Palm Sander	
4350800_21013	PT-C-EW-76	TP-MA 36/30 Li BL - Solo	Cordless Wall Liner	
4350800_21013	PT-C-EW-76	TP-MA 36/30 Li BL - Solo	Cordless Wall Liner	
4331400_21013	PT-C-EW-80	TP-PS 18/165 Li BL - Solo	Cordless Plunge Cut Saw	
4331400_21013	PT-C-EW-80	TP-PS 18/165 Li BL - Solo	Cordless Plunge Cut Saw	
4419360_21012	PT-C-EW-82	TE-MT 18/34 Li Solo	Cl.Grind./Engraving Tool(stat)	
4432000_21013	PT-C-EW-83	TP-CO 18/76-C Li BL - Solo	Cordless Cut-Off Grinder	
4432000_21013	PT-C-EW-83	TP-CO 18/76-C Li BL - Solo	Cordless Cut-Off Grinder	
4468000_21013	PT-C-EW-84	TP-BR 18/32 Li BL - Solo	Cordless Sanding Roller	
4468000_21013	PT-C-EW-84	TP-BR 18/32 Li BL - Solo	Cordless Sanding Roller	
4522300_21014	PT-C-EW-88	TP-GR 18/690 Li - Solo	Cordless Grease Gun	

4520400_21014	PT-C-EW-89	TE-SI 18/480 Li E - Solo	Cordless Soldering Iron	
4520400_21014	PT-C-EW-89	TE-SI 18/480 Li E - Solo	Cordless Soldering Iron	
4510040_21041	PT-C-EW-91	TP-CW 18 Li Brushless-Solo	Cordless Impact Wrench	
4510070_21023	PT-C-EW-91	IMPAXXO 18/450	Cordless Impact Wrench	
4510090_21014	PT-C-EW-91	TP-CW 18/260-C Li BL - Solo	Cordless Impact Wrench	
4510090_21014	PT-C-EW-91	TP-CW 18/260-C Li BL - Solo	Cordless Impact Wrench	
4510065_21014	PT-C-EW-91	TP-CW 18/750-C Li BL - Solo	Cordless Impact Wrench	
4510065_21014	PT-C-EW-91	TP-CW 18/750-C Li BL - Solo	Cordless Impact Wrench	
4510052_21015	PT-C-EW-91	TC-SGS 18 Li 3N - Solo	Cordless Impact Wrench	
4510055_21014	PT-C-EW-91	TP-CW 18/350-C Li BL - Solo	Cordless Impact Wrench	
4510055_21014	PT-C-EW-91	TP-CW 18/350-C Li BL - Solo	Cordless Impact Wrench	
4510080_21023	PT-C-EW-91	IMPAXXO 18/230	Cordless Impact Wrench	
2347120_21031	PT-C-RT-01	TE-VC 18 Li-Solo	Cordless Vacuum Cleaner	
2347190_21011	PT-C-RT-01	TE-HV 18/06 Li - Solo	Cordless Vacuum Cleaner	
3437100_21023	PT-C-RT-02	BRILLIANTO	Cordless Window Cleaner	

4020430_21011	PT-CE-DT-1	PRESSITO 18/25 Hybrid	Hybrid-Compressor	
4020460_11017	PT-CE-DT-1	PRESSITO	Hybrid-Compressor	
4514148_21013	PT-Z-81	TC-CP 18 Li USB A/C-Solo	USB-Battery-Adapter	
4512069_21020	PT-Z-83	Power X-Twincharger 3A	Charger	
4512103_11019	PT-Z-83	Power X-Fastcharger 4A	Charger	
4512102_11019	PT-Z-83	2x2 Power X-Quattrocharger 4A	Charger	
4512155_21012	PT-Z-83	Power X-Boostcharger 8A	Charger	
4512169_21015	PT-Z-83	PXC-Fastcharger 3,5A	Charger	
2093301_11017	GT-C-AZ-01	CE-CB 18/254 Li-Solo	Cordless Car Polisher	
2093320_21021	GT-C-AZ-05	CE-CP 18/180 Li E-Solo	Cl. Polishing/Sanding Machine	
2071010_21010	GT-C-AZ-06	CE-CC 18 Li-Solo	Cordless Car Air Compressor	
2071025_21014	GT-C-AZ-06	CE-CC 18/23 D Li-Solo	Cordless Car Air Compressor	
2071025_21014	GT-C-AZ-06	CE-CC 18/23 D Li-Solo	Cordless Car Air Compressor	
2093330_21014	GT-C-AZ-11	CP-EP 18/125 Li BL-Solo	Cordless Eccentric Polisher	
2093330_21014	GT-C-AZ-11	CP-EP 18/125 Li BL-Solo	Cordless Eccentric Polisher	

3410382_21021	GT-C-GT-01	GC-CG 18/1 Li-Solo	Cordless Grass Shear	
3410313_21010	GT-C-GT-04	GE-CG 18/100 Li-Solo	Cordless Grass- and Bush Shear	
3410370_21021	GT-C-GT-04	GC-CG 18 Li-Solo	Cordless Grass- and Bush Shear	
3415410_11018	GT-C-GT-06	GE-US 18 Li-Solo	Universal Spreader	
4499940_21031	GT-C-GT-20	GE-CS 18 Li-Solo	Cordless Chain Sharpener	
3408290_21023	GT-C-GT-25	GE-GS 18/150 Li-Solo	Cordless Pruning Saw	
3408300_21032	GT-C-GT-26	GE-LS 18 Li-Solo	Cordless Pruning Shears	
3408320_21013	GT-C-GT-26	GP-LS 18/28 Li BL-Solo	Cordless Pruning Shears	
3425240_21012	GT-C-GT-28	GE-WS 18/10 Li-Solo	Cordless Pressure Sprayer	
4600020_21011	GT-C-GT-38	FORTEXXA 18/20 TH	Top-handled Cordless Chain Saw	
4600065_21015	GT-C-GT-40	GC-AAKS 18 Li - Solo	Cordless Pruning Chain Saw	
2320120_21014	GT-C-GT-45	GC-OL 18/1500 Li-Solo	Cordless Outdoor Light	
2320120_21014	GT-C-GT-45	GC-OL 18/1500 Li-Solo	Cordless Outdoor Light	
4181560_21011	GT-C-WT-01	GE-SP 18 LL Li - Solo	Cordless Clear Water Pump	
4181500_21021	GT-C-WT-01	GE-SP 18 Li - Solo	Cordless Clear Water Pump	

4181580_21011	GT-C-WT-04	GE-DP 18/25 Li - Solo	Cordless Dirt Water Pump	
4181590_21012	GT-C-WT-04	GE-DP 18/25 LL Li - Solo	Cordless Dirt Water Pump	
3408310_21010	GT-Z-31	GE-PB 36/18 Li	Battery Belt	
3410835_11016	GT-Z-32	Pruner Unit f. GE-HH18/45Li T	Multifunctional Tool-GT Acces.	
2070110_21010	PT-C-EW-04	CE-AP 18 Li-Solo	Cordless Air Pump	
3408035_21011	PT-C-EW-48	GE-CF 18/2200 Li - Solo	Cordless Fan	
3408061_21013	PT-C-EW-48	GC-CF 18/110 Li-Solo	Cordless Fan	
3408037_21015	PT-C-EW-48	GC-AVL 18 Li - Solo	Cordless Fan	