

## Cordless Lawn Trimmer ART 14,4-1

Art.-No.: **34.112.10**

bar code: 4006825341393

Sales unit: 4 pcs


A versatile lawn trimmer – complete with an integrated replaceable battery pack for user-friendly operation without having to connect to a power socket outlet. Perfect lawn edges in the garden, at home or at your holiday cottage.

### Features:

- Replaceable storage battery pack: 14,4 V/1300 mA(1)
- Adjustable additional handle (2)
- Interlocking system (3) therefore easy to dismantle for space saving storage
- Charger and adapter (4)
- thread adjustment by **Tipp-Automatic** (5)

### Technical data:

battery pack:	14,4 V / 1300 mAh
Running time max:	20 min.
Cutting width:	240 mm
Line length:	8 m
Line-Ø:	1,3 mm
Line speed:	Tipp-Automatic
Charging time:	4 h



### As special accessory available:

Spare battery pack 14,4 V  
1300 mAh  
Spare line 8 m, Ø 1,3 mm  
(1 pc)

Art.-No.: **45.115.38**  
bar code: 4006825456356  
Art.-No.: **34.051.53**  
bar code: 4006825502787

