



Einhell

CLASSIC



Cordless Drill

TC-CD 18/35-2 Li (1x1,5 Ah)

Item No.: 4514255

Ident No.: 21013

Bar Code: 4006825674491

The Einhell cordless drill driver TC-CD 18/35-2 Li (1x 1.5 Ah) is a handy member of the flexibly combinable Power X-Change battery family. The robust metal gearbox enables powerful drilling and screwing, while the speed electronics ensure precise work. With 35 Nm torque, 21 torque stages + drilling stage, the drill driver is incredibly versatile. The double-sleeved 10 mm quick-release chuck makes it easy to change drills and bits. The cordless screwdriver lies comfortably in the hand thanks to its ergonomic design with softgrip and the integrated LED light improves the view of the working area. Delivery includes 1x 1.5 Ah battery and a charger

Features & Benefits

- Member of the Power X-Change family, 1x 18 V battery required
- Metal gearbox for powerful drilling and screwing
- Speed electronics for material-specific work.
- 10 mm quick-release chuck for quick tool change
- Integrated LED light illuminates the working area
- Ergonomic design with softgrip
- Incl. 1x 1.5 Ah Power X-Change battery and 1x charger

Technical Data

- | | |
|--------------------------|--------------------------|
| - Accumulator | 18 V 1500 mAh Li-Ion |
| - Charging time | 2h |
| - Number of gears | 1 |
| - Idle speed (gear 1) | 0-550 min ⁻¹ |
| - Max. torque hard | 35 Nm |
| - Number of torque steps | 21+1 settings |
| - Drill chuck | 10 mm double sleeve |
| - Number of accumulators | 1 Pieces |

Logistic Data

- | | |
|--------------------------------------|--------------------|
| - Product weight | 1.39 kg |
| - Gross weight single packaging | 2.07 kg |
| - Dimensions single packaging | 241 x 104 x 206 mm |
| - Pieces per export carton | 4 Pieces |
| - Gross weight export carton | 14.82 kg |
| - Dimensions export carton | 440 x 258 x 226 mm |
| - Container quantity (20"/40"/40"HC) | 4304 |



ERGONOMIC




LED



ELECTRONIC SPEED CONTROL



INCL.



18 V
1.5 Ah



35 Nm
HIGH POWER



DRILL+
SCREW

Available as special accessories



4-6 Ah Multi-Ah Power X-Change Plus Akku Battery
Item No.: 4511502
Bar Code: 4006825644210



18V 2,5Ah PXC Starter Kit PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



4,0 Ah Power X-Change Akku Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



18V 3,0Ah PXC Starter Kit PXC-Starter-Kit
Item No.: 4512041
Bar Code: 4006825613698
Einhell Accessory



18V 4,0Ah PXC Starter Kit 1 PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



2x2 Power X-Quattrocharger 4A Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



18V 2,5Ah Power X-Change Battery
Item No.: 4511516
Bar Code: 4006825650518
Einhell Accessory



Power X-Fastcharger 4A Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



Power X-Twincharger 3A Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



Power X-Car Charger 3A Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1 PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory



5,2Ah & 4A Fastcharger PXC-Starter-Kit
Item No.: 4512114
Bar Code: 4006825656787
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB 1 Battery
Item No.: 4511489
Bar Code: 4006825638578
Einhell Accessory



Power X-Boostcharger 6A Charger
Item No.: 4512064
Bar Code: 4006825629019
Einhell Accessory



18V 3,0 Ah Power-X-Change 2 Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory



18V 5-8Ah Multi-Ah PXC Plus Battery
Item No.: 4511600
Bar Code: 4006825665055
Einhell Accessory



Bit-Bohrerbox 22tlg. S-Box Akku-Bohrschrauber-Zubehör
Item No.: 49108806
Bar Code: 4009311088062
Einhell Accessory



Bitsatz 34 tlg. S-Box Akku-Bohrschrauber-Zubehör
Item No.: 49108801
Bar Code: 4009311088017
Einhell Accessory



Bit-Bohrerbox 39tlg. L-Box Akku-Bohrschrauber-Zubehör
Item No.: 49108911
Bar Code: 4009311089113
Einhell Accessory



5,2 Ah Power X-Change Plus Akku Battery
Item No.: 4511437
Bar Code: 4006825616606



3,0 Ah Power X-Change Plus Akku Battery
Item No.: 4511501
Bar Code: 4006825644197



18V 4,0Ah Power-X-Change Plus Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory



18V 2,0Ah PXC Starter Kit PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory



2,0 Ah Power X-Change Akku Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory

Battery-Running-Times



screwing¹
(pieces)

One Battery for All

1.5 Ah	220
2.0 Ah	295
2.5 Ah	366
3.0 Ah	440
4.0 Ah	590
5.2 Ah	760
6.0 Ah	880
8.0 Ah	1180

Test setup:

1) softwood - 6x60 mm