







**Cordless Impact Drill** 

TC-SBS 18 Li - Solo

Item No.: 4514234

Ident No.: 21015

Bar Code: 4006825687309

The Einhell Cordless Impact Drill TC-SBS 18 Li - Solo is a flexible all-rounder for ambitious DIY enthusiasts. As part of the Power X-Change family, it is compatible with all batteries and chargers in the system. With its powerful 2-speed gearbox, 44 Nm torque, 18 torque settings, as well as drilling and impact drilling modes, it handles screwdriving and drilling tasks in wood, metal, or masonry with ease. The robust single-sleeve 13 mm metal chuck and Quick-Stop function enable fast tool changes. Speed control, LED light, and belt clip ensure precision and convenience. Supplied without battery and charger.

### **Features & Benefits**

- Member of the Power X-Change family; 1x 18 V battery needed
- Hammer drill function for versatile applications
- 2-speed gearbox for powerful drilling and screwdriving
- Single-sleeve 13 mm quick-release chuck
- Speed control for work suited to the material
- Quick-stop function for fast tool changes
- Safe interim storage thanks to belt clip
- LED light for illuminating the work area
- Ergonomic design with softgrip for comfortable handling
- Supplied without battery or charger (sold separately)

### **Technical Data**

- Number of gears

- Idle speed (gear 1) 0-350 min^-1 - Idle speed (gear 2) 0-1250 min^-1 - Max. torque hard 44 Nm

- Number of torque steps 18+1+1 settings

- Drill chuck 13 mm | single sleeve

- Drilling capacity in concrete 8 mm

- Impact rate (gear 1) 0-5250 min^-1 0-18750 min^-1 - Impact rate (gear 2)

# **Logistic Data**

- Product weight 1.16 kg - Gross weight single packaging 1.41 kg

- Dimensions single packaging 80 x 202 x 233 mm

- Pieces per export carton 4 Pieces - Gross weight export carton 6.2 kg

345 x 250 x 220 mm - Dimensions export carton - Container quantity (20"/40"/40"HC) 5900 | 12224 | 14332











## Available as special accessories



PXC Battery Mounting Gadget PXC-Battery Accessory Item No.: 4514155 Bar Code: 4006825658774 Einhell Accessory

5,2 Ah Power X-Change Plus Battery Item No.: 4511437 Bar Code: 4006825616606



3,0 Ah Power X-Change Plus Battery Item No.: 4511501 Bar Code: 4006825644197



PXC+ 18V 4,0Ah Battery Item No.: 4511553 Bar Code: 4006825660869 Einhell Accessory

Einhell Accessory



PXC 18V 3,0Ah Battery Item No.: 4511341 Bar Code: 4006825590593 **Einhell Accessory** 

**Einhell Accessory** 



2,0 Ah Power X-Change Battery Item No.: 4511395 Bar Code: 4006825610369 **Einhell Accessory** 



4,0 Ah Power X-Change Battery Item No.: 4511396 Bar Code: 4006825610376 Einhell Accessory



4-6 Ah Multi-Ah Power X-Change Battery Item No.: 4511502 Bar Code: 4006825644210



PXC 18V 2,5Ah Battery Item No.: 4511516 Bar Code: 4006825650518 Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack Battery Item No.: 4511526 Bar Code: 4006825656695 Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB C1

Battery Item No.: 4511489 Bar Code: 4006825638578

## **Battery-Running-Times**

One Battery for All	screwing <sup>1</sup>	
	(pieces)	
1.5 Ah	180	
2.0 Ah	240	
2.5 Ah	300	
3.0 Ah	360	
4.0 Ah	480	
5.2 Ah	625	
6.0 Ah	720	
8.0 Ah	960	

Test setup: