



Einhell

EXPERT

POWER X-CHANGE

Cordless Drill

TE-CD 18/40-1 Li (2x1,5 Ah)

Item No.: 4513939

Ident No.: 21033

Bar Code: 4006825649208

The Einhell TE-CD 18/40-1 Li (2x1.5 Ah) cordless drill is equipped with 2-speed gearing for powerful drilling and screwdriving. The electronic speed control with 21 torque settings ensures that the tool can be adjusted to each particular material and application. For easy handling it has an ergonomic design and soft grip. For optimum visibility in the work area there is an integrated LED light. It is supplied in a practical transport and storage case complete with two 1.5 Ah PXC rechargeable batteries and a 30-minute charger. Not only can the PXC batteries be combined with flexibility with every system device, they are also ready for action at any time thanks to the high-quality li-ion technology with zero self-discharge.

Features & Benefits

- A member of the Power X-Change family
- 2-speed gearing for powerful drilling and screwing
- Speed electronics for material and application suitable working
- Always Ready-for-use due to Li-ion technology without discharging
- LED lighting for optimum operation in dark areas
- Extremely easy to work with due to ergonomic design and Softgrip
- Supplied with two 1,5 Ah batteries and 30min charger
- Delivered in a practical case




Technical Data

- Accumulator 18 V | 1500 mAh | Li-Ion
- Charging time 1/2h
- Number of gears 2
- Idle speed (gear 1) 400 min⁻¹
- Idle speed (gear 2) 1500 min⁻¹
- Max. torque hard 40 Nm
- Number of torque steps 21+1 settings
- Drill chuck 13 mm | single sleeve
- Number of accumulators 2 Pieces



Logistic Data

- Product weight 2.2 kg
- Gross weight single packaging 3.62 kg
- Dimensions single packaging 350 x 100 x 320 mm
- Pieces per export carton 4 Pieces
- Gross weight export carton 16.7 kg
- Dimensions export carton 430 x 365 x 355 mm
- Container quantity (20"/40"/40"HC) 2008 | 4160 | 4880



Available as special accessories



4-6 Ah Multi-Ah Power X-Change Plus Battery
Item No.: 4511502
Bar Code: 4006825644210



4,0 Ah Power X-Change Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



2x2 Power X-Quattrocharger 4A Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



2x 5,2Ah & Twincharger Kit PXC-Starter-Kit
Item No.: 4512108
Bar Code: 4006825652376
Einhell Accessory



18V 3,0 Ah Power-X-Change 1 Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1 PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory



5,2Ah & 4A Fastcharger PXC-Starter-Kit
Item No.: 4512114
Bar Code: 4006825656787
Einhell Accessory



3,0 Ah Power X-Change Plus Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



18V 5-8Ah Multi-Ah PXC Plus Battery
Item No.: 4511600
Bar Code: 4006825665055
Einhell Accessory



Handy Bitbox Impact 12tlg. Akku-Bohrschrauber-Zubehör
Item No.: 49155025
Bar Code: 4009311550255
Einhell Accessory



Bitsatz 34 tlg. S-Box Akku-Bohrschrauber-Zubehör
Item No.: 49108801
Bar Code: 4009311088017
Einhell Accessory



Bit-Bohrerbox 39tlg. L-Box Akku-Bohrschrauber-Zubehör
Item No.: 49108956
Bar Code: 4009311089564
Einhell Accessory



5,2 Ah Power X-Change Plus Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



18V 4Ah PXC Plus Twinpack Battery
Item No.: 4511629
Bar Code: 4006825673685
Einhell Accessory



18V 2,5Ah PXC Starter Kit PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



18V 4,0Ah PXC Starter Kit A1 PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



Power X-Fastcharger 4A Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



Power X-Twincharger 3A Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



Power X-Car Charger 3A Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB A1 Battery
Item No.: 4511489
Bar Code: 4006825638578



Power X-Caravan Charger 3A Charger
Item No.: 4512136
Bar Code: 4006825664010
Einhell Accessory



18V 4-6Ah & 6A Boostcharger PXC-Starter-Kit
Item No.: 4512143
Bar Code: 4006825667653
Einhell Accessory



Bit-Bohrerbox 22tlg. S-Box Akku-Bohrschrauber-Zubehör
Item No.: 49108806
Bar Code: 4009311088062
Einhell Accessory



Power X-Boostcharger 8A Charger
Item No.: 4512155
Bar Code: 4006825670554
Einhell Accessory



18V 4,0Ah Power-X-Change Plus Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory



18V 3Ah PXC Plus Twinpack Battery
Item No.: 4511631
Bar Code: 4006825673692
Einhell Accessory



18V 2.0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory




2,0 Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



18V Battery Charger 3,0A - PXC
Charger
Item No.: 4514095
Bar Code: 4006825655292
Einhell Accessory

Battery-Running-Times

One Battery for All	 screwing ¹ (pieces)
1.5 Ah	230
2.0 Ah	305
2.5 Ah	380
3.0 Ah	460
4.0 Ah	610
5.2 Ah	770
6.0 Ah	920
8.0 Ah	1220

Test setup:

1) screws - 6x60 mm