



Einhell ACCESSORY

Case

E-Box S35

Item No.: 4530045

Ident No.: 11017

Bar Code: 4006825629750

The Einhell S35 E-Box keeps everything neat and tidy and provides mobility - at all times. Always ready to hand, tools and accessories are immediately to hand and stored well-arranged. The case provides a universal storage facility which is comfortable to transport even when loaded to full capacity of 12 kilograms. Thanks to the ergonomic handle. The splash-proof design provides reliable protection against routine and adverse conditions, whether it be in the workshop, the car boot or on site. The soft foam inner lining guarantees no scratches during transportation. This also ensures that Einhell tools are protected - for a long service life for the tools and devices.

Features & Benefits

- Case for the universal storage of tools and accessories
- Soft foam inner lining for transporting without scratching
- Splash-proof design for safe storage
- Ergonomic handle for carrying comfortably
- Maximum load capacity up to 12 kg possible



Technical Data

- | | |
|----------------------|---------------------|
| - Inside dimensions | 250 x 310 x 89.5 mm |
| - Outside dimensions | 330 x 350 x 110 mm |
| - Max. payload | 12 kg |

Logistic Data

- | | |
|--------------------------------------|--------------------|
| - Product weight (kg) | 1.645 |
| - Gross weight (kg) | 1.72 |
| - Pieces per export carton | 10 Pieces |
| - Gross weight of export carton | 19.08 kg |
| - Dimensions export carton | 700 x 595 x 360 mm |
| - Container quantity (20"/40"/40"HC) | 1700 3400 3800 |



Suitable for E-Box S35

All unmarked articles also fit including two 2,0Ah PXC-Batteries and a high-speed charger



TE-CD 18 Li Brushless-Solo
Cordless Drill
Item No.: 4513850
EAN-Code: 4006825611366
Einhell Expert Plus



TE-CD 18 Li E-Solo
Cordless Drill
Item No.: 4513870
EAN-Code: 4006825617740
Einhell Expert Plus



TE-CD 18 Li-i Brushless-Solo
Cordless Impact Drill
Item No.: 4513860
EAN-Code: 4006825612417
Einhell Expert Plus



TE-CD 18/48 Li-i-Solo
Cordless Impact Drill
Item No.: 4513926
EAN-Code: 4006825635775
Einhell Expert



TE-CD 18/40 Li-Solo
Cordless Drill
Item No.: 4513925
EAN-Code: 4006825635768
Einhell Expert



TE-CD 18/2 Li
Cordless Drill
Item No.: 4513830
EAN-Code: 4006825607321
Einhell Expert Plus



TE-CD 18/50 Li-Solo
Cordless Drill
Item-No.: 4513887
EAN-Code: 4006825644838
Einhell Expert Plus



TE-CD 18/50 Li-i-Solo
Cordless Impact Drill
Item-Nr.: 4513942
EAN-Code: 4006825644265
Einhell Expert Plus



TC-CD 18/35 Li-Solo
Cordless Drill
Item No.: 4513927
EAN-Code: 4006825642452
Einhell Classic



TE-DY 18 Li-Solo
Cordless Drywall Screwdriver
Item No.: 4259980
EAN-Code: 4006825635607
Einhell Expert



TE-CI 18/1 Li-Solo
Cordless Impact Screwdriver
Item No.: 4510034
EAN-Code: 4006825618907
Einhell Expert Plus



TE-CI 18 Li Brushless-Solo
Cordless Impact Screwdriver
Item No.: 4510030
EAN-Code: 4006825613971
Einhell Expert Plus



TE-CW 18 Li BL; Brushless-Solo
Cordless Impact Screwdriver
Item No.: 4510040
EAN-Code: 4006825616323
Einhell Expert Plus



TE-HD 18 Li-Solo
Cordless Rotary Hammer
Item No.: 4513812
EAN-Code: 4006825604054
Einhell Expert Plus



TC-HD 18/12 Li-Solo
Cordless Rotary Hammer
Item No.: 4513970
EAN-Code: 4006825647778
Einhell Classic



AXXIO
Cordless Angle Grinder
Item No.: 4431140
EAN-Code: 4006825630558
Einhell Expert Plus

Only suitable after removing
blade guard & handle!



TC-AG 18/115 Li-Solo
Cordless Angle Grinder
Item No.: 4431130
EAN-Code: 4006825628746
Einhell Classic

Only suitable after removing
blade guard & handle!



TE-AG 18/115 Li-Solo
Cordless Angle Grinder
Item No.: 4431110
EAN-Code: 4006825602593
Einhell Expert Plus

Only suitable after removing
blade guard & handle!



TE-AG 18/150 Li BL
Cordless Angle Grinder
Item No.: 4006825644494
EAN-Code: 4006825602593
Einhell Expert Plus

Only suitable after removing
blade guard & handle!



TE-JS 18 Li-Solo
Cordless Jig Saw
Item No.: 4321200
EAN-Code: 4006825601398
Einhell Expert Plus

Only suitable for
solo article!



TC-JS 18 Li
Akku-Stichsäge
Art.-Nr.: 4321209
EAN-Code: 4006825640052
Einhell Classic

Suitable after removing saw
blade



TE-AP 18 Li-Solo
Cordless All Purpose Saw
Item No.: 4326300
EAN-Code: 4006825601381
Einhell Expert Plus

Only suitable for solo article
& after removing saw blade
and soleplate!



VARRITO
Cordless Multifunctional Tool
Item No.: 4465160
EAN-Code: 4006825618648
Einhell Expert Plus



TC-MG 18 Li-Solo
Cordless Multifunctional Tool
Item No.: 4465170
EAN-Code: 4006825628593
Einhell Classic



TE-CR 18 Li-Solo
Cordless Radio
Item No.: 3408015
EAN-Code: 4006825609196
Einhell Expert Plus



TE-CL 18 Li-Solo
Cordless Light
Item No.: 4514110
EAN-Code: 4006825600032
Einhell Expert Plus



TE-CL 18 Li H-Solo
Cordless Light
Item No.: 4514130
EAN-Code: 4006825610451
Einhell Expert Plus



TE-CG 18 Li
Cordless-Hot Glue Gun
Item No.: 4522200
EAN-Code: 4006825641202
Einhell Expert



TE-HA 18 Li
Cordless-Hot Air Gun
Item No.: 4522200
EAN-Code: 4006825647730
Einhell Expert



TC-SR 18 Li BT
Cordless-Speaker
Item No.: 4514150
EAN-Code: 4006825644531
Einhell Classic



18V 30min Power-X-Change
PXC-Charger
Item No.: 4512011
EAN-Code: 4006825587029
Einhell Accessory



TE-CP 18 Li USB-Solo
USB Power Bank
Item No.: 4514120
EAN-Code: 4006825608878
Einhell Expert Plus



Power-X-Twincharger 3 A
PXC-Charger
Item No.: 4512069
EAN-Code: 4006825629729
Einhell Accessory



Power-X-Boostcharger 6 A
PXC-Charger
Item No.: 4512064
EAN-Code: 4006825629019
Einhell Accessory