



Einhell

EXPERT



Cordless Drill Kit
TE-CD 18/40 Li +69 (2x2,0 Ah)

Item No.: 4513934

Ident No.: 21021

Bar Code: 4006825651621

The Einhell cordless drill set TE-CD 18/40 Li Kit (2x2.0 Ah) is a versatile helper. Being a member of the PXC family means that every rechargeable battery from the system series can be used in with the drill. It is supplied complete with two 2.0 Ah PXC rechargeable batteries and a high-speed charger. The batteries are permanently ready-for-use thanks to the lithium-ion technology with zero self-discharge. The power is transferred on a 2-speed gear unit and electronic speed control ensures that the tool can still be adjusted to the particular material & application. For optimum operation in dark areas there is LED lighting. For good handling it has an ergonomic design and soft grip. The set will be delivered in a practical case.

Features & Benefits

- A member of the Power X-Change family
- 2-speed gearing for powerful drilling and screwing
- Speed electronics for material and application suitable working
- Always Ready-for-use due to Li-ion technology without discharging
- LED lighting for optimum operation in dark areas
- Extremely easy to work with due to ergonomic design and Softgrip
- Supplied with two 2.0 Ah batteries and a high-speed charger
- Supplied in a practical case and with an accessory with 69 pieces





Technical Data

- Accumulator 18 V | 2000 mAh | Li-Ion
- Charging time 40min
- Number of gears 2
- Idle speed (gear 1) 0-400 min⁻¹
- Idle speed (gear 2) 0-1500 min⁻¹
- Max. torque hard joint 40 Nm
- Number of torque steps 21 settings
- Drill chuck 13 mm | single sleeve
- Number of accumulators 2 Pieces

Logistic Data

- Product weight 1.45 kg
- Gross weight single packaging 5.44 kg
- Dimensions single packaging 372 x 130 x 315 mm
- Pieces per export carton 2 Pieces
- Gross weight export carton 11.9 kg
- Dimensions export carton 390 x 320 x 275 mm
- Container quantity (20"/40"/40"HC) 1628 | 3260



Available as special accessories



2x 3,0Ah & Twincharger Kit
PXC-Starter-Kit
Item No.: 4512083
Bar Code: 4006825638509
Einhell Accessory



18V 4-6Ah Multi-Ah PXC Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210
Einhell Accessory



18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



18V 2,0Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



18V 4,0Ah Power X-Change 1
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



18V 4,0Ah PXC Starter Kit 1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



18V 2,5Ah Power X-Change
Battery
Item No.: 4511516
Bar Code: 4006825650518
Einhell Accessory



Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



18V 5,2Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



Power X-Car Charger 3A
Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1
PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory



2x 18V 2,5Ah PXC-Twinpack CB
Battery
Item No.: 4511524
Bar Code: 4006825656206
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack
Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory



5,2Ah & 4A Fastcharger
PXC-Starter-Kit
Item No.: 4512114
Bar Code: 4006825656787
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB 1
Battery
Item No.: 4511489
Bar Code: 4006825638578
Einhell Accessory



18V 2,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory



18V 4,0Ah Power-X-Change Plus
Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory



Power X-Boostcharger 6A
Charger
Item No.: 4512064
Bar Code: 4006825629019
Einhell Accessory



18V 3,0Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



18V 3,0 Ah Power-X-Change 2
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory



18V 5-8Ah Multi-Ah PXC Plus
Battery
Item No.: 4511600
Bar Code: 4006825665055
Einhell Accessory

Battery-Running-Times



screwing¹
(pieces)

One Battery for All

1.5 Ah	230
2.0 Ah	305
2.5 Ah	380
3.0 Ah	460
4.0 Ah	610
5.2 Ah	770
6.0 Ah	920
8.0 Ah	1220

Test setup:

1) wood - 6x60 mm