

BG Ще намерите съответните инструкции/указания по техника на безопасност при инструкциите по техника на безопасност и в оригинала на работната инструкция за съответната машина. **Внимание! Внимателно прочетете всички инструкции и указания по техника на безопасност!**

GR Θα βρείτε τις σχετικές υποδείξεις ασφαλείας / οδηγίες στις υποδείξεις ασφαλείας και στο πρωτότυπο των οδηγιών χρήσης της εκάστοτε συσκευής. **Προειδοποίηση! Διαβάστε προσεκτικά όλες τις υποδείξεις ασφαλείας και τις οδηγίες!**

TR İlgili güvenlik uyarıları / talimatlar güvenlik uyarıları bölümü ve ilgili aletin veya cihazın orijinal kullanma talimatı içinde bulunur. **Uyarı! Açıklanan bütün güvenlik uyarıları ve talimatları okuyun.**

UKR Відповідні вказівки/поради щодо техніки безпеки ви знайдете у правилах техніки безпеки та в автентичній інструкції з експлуатації. **Увага! Уважно прочитайте всі вказівки та поради щодо техніки безпеки!**

D Die entsprechenden Sicherheitshinweise / Anweisungen finden Sie in den Sicherheitshinweisen und der Originalbetriebsanleitung des entsprechenden Gerätes. **Warnung! Lesen Sie alle Sicherheitshinweise und Anweisungen sorgfältig durch!**

GB The corresponding safety information / instructions can be found in the safety information and original operating instructions provided with actual tool. **Warning! Read all the safety information and instructions carefully!**

F Vous trouverez les consignes de sécurité/instructions dans les consignes de sécurité et le mode d'emploi d'origine de l'appareil correspondant. **Avertissement ! Veuillez lire soigneusement toutes les consignes de sécurité et instructions!**

I Le avvertenze di sicurezza e le istruzioni del presente dispositivo non sono riportate separatamente, ma insieme alle istruzioni originali del rispettivo apparecchio. **Avvertimento! Leggete attentamente tutte le avvertenze di sicurezza e le istruzioni!**

DK/N De relevante sikkerhedsanvisninger samt øvrige anvisninger findes under sikkerhedsanvisningerne og i produktets originale betjeningsvejledning. **Advarsel! Læs alle sikkerhedsanvisninger og øvrige anvisninger grundigt igennem.**

S Motsvarande säkerhetsanvisningar / instruktioner finns i säkerhetsanvisningarna och original-bruksanvisningen till resp. maskin. **Obs! Läs igenom alla säkerhetsanvisningar och instruktioner noggrant!**

HR/BIH Odgovarajuće sigurnosne napomene/upute naći ćete u sigurnosnim napomenama i originalnim uputama za uporabu dotičnog uređaja. **Upozorenje! Pažljivo pročitajte sve sigurnosne napomene i upute!**

RS Odgovarajuće bezbednosne napomene/uputstva naći ćete u bezbednosnim napomenama i originalnim uputstvima za upotrebu dotičnog uređaja. **Upozorenje! Pažljivo pročitajte sve bezbednosne napomene i uputstva!**

CZ Příslušné bezpečnostní pokyny / instrukce naleznete v bezpečnostních pokynech a originálním návodu k obsluze příslušného přístroje. **Varování! Přečtěte si pečlivě všechny bezpečnostní pokyny a instrukce!**

SK Príslušné bezpečnostné predpisy/pokyny nájdete v bezpečnostných pokynoch a originálnom návode na obsluhu príslušného prístroja. **Výstraha! Starostlivo si prečítajte všetky bezpečnostné predpisy a pokyny!**

NL De veiligheidsinstructies/aanwijzingen vindt u in de veiligheidsinstructies en de originele gebruiksaanwijzing van het betreffende apparaat. **Waarschuwing! Lees alle veiligheidsinstructies en aanwijzingen zorgvuldig door!**

E Encontrará las instrucciones de seguridad / indicaciones correspondientes en las instrucciones de seguridad y en el manual de instrucciones original del aparato correspondiente. **Aviso: ¡Leer atentamente todas las instrucciones de seguridad e indicaciones!**

P Pode encontrar as instruções de segurança / indicações correspondentes nas instruções de segurança e no manual de instruções original do respectivo aparelho. **Aviso! Leia atentamente todas as instruções de segurança e indicações!**

FIN Laitetta koskevat turvallisuuismääräykset / ohjeet löydät kunkin laitteen turvallisuuismääräyksistä ja alkuperäisestä käyttöohjeesta. **Varoitukset! Lue kaikki turvallisuuismääräykset ja ohjeet huolellisesti kokonaan!**

RUS Соответствующие указания по технике безопасности / инструкции Вы найдете в указаниях по технике безопасности и оригинальном руководстве по эксплуатации определенного устройства. **Предупреждение! Внимательно прочтите все указания по технике безопасности и инструкции!**

EE Asjakohased ohutusnõuanded / -juhised leiad vastava seadme ohutusnõuannetest ja originaalkasutusjuhendist. **Hoiatus! Lugege kõiki ohutusjuhised ja juhendid hoolikalt läbi.**

LV Attiecīgos drošības norādījumus/instrukcijas skatiet attiecīgās ierīces drošības norādījumos un oriģinālajā lietošanas instrukcijā. **Brīdinājums! Rūpīgi izlasiet visus drošības norādījumus un instrukcijas.**

LT Atitinkamus saugos nurodymus (instrukcijas) rasite tam tikro prietaiso saugos nurodymuose ir originalioje naudojimo instrukcijoje. **Įspėjimas! Atidžiai perskaitykite visus saugos nurodymus ir instrukcijas.**

SLO Ustrezna varnostna navodila/napotke najdete v varnostnih navodilih in originalnih navodilih za uporabo ustrezne naprave. **Opozorilo! Natančno preberite vse varnostne napotke in navodila!**

H A megfelelő biztonsági utasítások / utalások a megfelelő kézikönyv biztonsági utasításaiban és az eredeti használati utasításában találhatók. **Figyelmeztetés! Olvasson minden biztonsági utasítást és utalást gondosan át!**

MK Соодветните безбедносни упатства / инструкции можете да ги најдете во Безбедносните упатства и во оригиналното упатство за употреба на соодветниот апарат. **Предупредување! Прочитајте ги внимателно сите безбедносни упатства и инструкции!**

PL Odpowiednie wskazówki bezpieczeństwa / instrukcje znajdują się we wskazówkach bezpieczeństwa i oryginalnej instrukcji obsługi danego urządzenia. **Ostrzeżenie! Przeczytać dokładnie wszystkie wskazówki bezpieczeństwa i instrukcje!**

RO Indicațiile de siguranță / instrucțiunile corespunzătoare le găsiți în broșura cu instrucțiuni de siguranță și în instrucțiunile de utilizare originale ale aparatului respectiv. **Avertisment! Citiți cu grijă toate indicațiile de siguranță și instrucțiunile!**

ELECTRICAL SAFETY

⚠ WARNING! When using electric tools basic safety precautions should always be followed to reduce the risk of fire, electric shock and personal injury.

Read the whole manual carefully and make sure you know how to switch the tool off in an emergency, before operating the tool. Save these instructions and other documents supplied with this tool for future reference.

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

This appliance is compatible and only to be used with all batteries & chargers from the Power X-Change range. Refer to the Power X-Change battery and charger manuals for information regarding charging, use and storage.

⚠ WARNING! Always remove the battery from the tool:

- when the batteries are to be charged,
- when the tool is left unattended,
- when the tool is being checked, cleaned, or having maintenance work done,
- when the tool is to be stored, or if the tool vibrates abnormally.

Do not combine different types of batteries.

Do not use modified or damaged batteries.

GENERAL POWER TOOL SAFETY

⚠ WARNING! Read all safety warnings, instructions, illustrations and specifications provided with this power tool. Failure to follow all instructions listed below may result in electric shock, fire and/or serious injury.

Save all warnings and instructions for future reference.

The term "power tool" in the warnings refers to your mains-operated (corded) power tool or battery-operated (cordless) power tool.

1) Work area safety

- Keep work area clean and well lit.** Cluttered or dark areas invite accidents.
- Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases or dust.** Power tools create sparks which may ignite the dust or fumes.
- Keep children and bystanders away while operating a power tool.** Distractions can cause you to lose control.

2) Electrical safety

- Power tool plugs must match the outlet. Never modify the plug in any way. Do not use any adapter plugs with earthed (grounded) power tools.** Unmodified plugs and matching outlets will reduce risk of electric shock.
- Avoid body contact with earthed or grounded surfaces, such as pipes, radiators, ranges and refrigerators.** There is an increased risk of electric shock if your body is earthed or grounded.
- Do not expose power tools to rain or wet conditions.** Water entering a power tool will increase the risk of electric shock.
- Do not abuse the cord. Never use the cord for carrying, pulling or unplugging the power tool. Keep cord away from heat, oil, sharp edges or moving parts.** Damaged or entangled cords increase the risk of electric shock.
- When operating a power tool outdoors, use an extension cord suitable for outdoor use.** Use of a cord suitable for outdoor use reduces the risk of electric shock.
- If operating a power tool in a damp location is unavoidable, use a residual current device (RCD) protected supply.** Use of an RCD reduces the risk of electric shock.

3) Personal safety

- Stay alert, watch what you are doing and use common sense when operating a power tool. Do not use a power tool while you are tired or under the influence of drugs, alcohol or medication.** A moment of inattention while operating power tools may result in serious personal injury.
- Use personal protective equipment. Always wear eye protection.** Protective equipment such as a dust mask, non-skid safety shoes, hard hat or hearing protection used for appropriate conditions will reduce personal injuries.
- Prevent unintentional starting. Ensure the switch is in the off-position before connecting to power source and/or battery pack, picking up or carrying the tool.** Carrying power tools with your finger on the switch or energising power tools that have the switch on invites accidents.
- Remove any adjusting key or wrench before turning the power tool on.** A wrench or a key left attached to a rotating part of the power tool may result in personal injury.
- Do not overreach. Keep proper footing and balance at all times.** This enables better control of the power tool in unexpected situations.
- Dress properly. Do not wear loose clothing or jewellery. Keep your hair and clothing away from moving parts.** Loose clothes, jewellery or long hair can be caught in moving parts.
- If devices are provided for the connection of dust extraction and collection facilities, ensure these are connected and properly used.** Use of dust collection can reduce dust-related hazards.
- Do not let familiarity gained from frequent use of tools allow you to become complacent and ignore tool safety principles.** A careless action can cause severe injury within a fraction of a second.

4) Power tool use and care

- Do not force the power tool. Use the correct power tool for your application.** The correct power tool will do the job better and safer at the rate for which it was designed.
- Do not use the power tool if the switch does not turn it on and off.** Any power tool that cannot be controlled with the switch is dangerous and must be repaired.

- c) **Disconnect the plug from the power source and/or remove the battery pack, if detachable, from the power tool before making any adjustments, changing accessories, or storing power tools.** Such preventive safety measures reduce the risk of starting the power tool accidentally.
- d) **Store idle power tools out of the reach of children and do not allow persons unfamiliar with the power tool or these instructions to operate the power tool.** Power tools are dangerous in the hands of untrained users.
- e) **Maintain power tools and accessories. Check for misalignment or binding of moving parts, breakage of parts and any other condition that may affect the power tool's operation. If damaged, have the power tool repaired before use.** Many accidents are caused by poorly maintained power tools.
- f) **Keep cutting tools sharp and clean.** Properly maintained cutting tools with sharp cutting edges are less likely to bind and are easier to control.
- g) **Use the power tool, accessories and tool bits etc. in accordance with these instructions, taking into account the working conditions and the work to be performed.** Use of the power tool for operations different from those intended could result in a hazardous situation.
- h) **Keep handles and grasping surfaces dry, clean and free from oil and grease.** Slippery handles and grasping surfaces do not allow for safe handling and control of the tool in unexpected situations.

5) Battery tool use and care

- a) **Recharge only with the charger specified by the manufacturer.** A charger that is suitable for one type of battery pack may create a risk of fire when used with another battery pack.
- b) **Use power tools only with specifically designated battery packs.** Use of any other battery packs may create a risk of injury and fire.
- c) **When battery pack is not in use, keep it away from other metal objects, like paper clips, coins, keys, nails, screws or other small metal objects, that can make a connection from one terminal to another.** Shorting the battery terminals together may cause burns or a fire.
- d) **Under abusive conditions, liquid may be ejected from the battery; avoid contact. If contact accidentally occurs, flush with water. If liquid contacts eyes, additionally seek medical help.** Liquid ejected from the battery may cause irritation or burns.
- e) **Do not use a battery pack or tool that is damaged or modified.** Damaged or modified batteries may exhibit unpredictable behaviour resulting in fire, explosion or risk of injury.
- f) **Do not expose a battery pack or tool to fire or excessive temperature.** Exposure to fire or temperature above 130 °C may cause explosion.
- g) **Follow all charging instructions and do not charge the battery pack or tool outside the temperature range specified in the instructions.** Charging improperly or at temperatures outside the specified range may damage the battery and increase the risk of fire.

6) Service

- a) **Have your power tool serviced by a qualified repair person using only identical replacement parts.** This will ensure that the safety of the power tool is maintained.
- b) **Never service damaged battery packs.** Service of battery packs should only be performed by the manufacturer or authorized service providers.

ADDITIONAL WARNINGS FOR ANGLE GRINDERS AND USE OF PROPER GUARDS

1. Do not use Cutting guard for facial grinding as the cutting guard may interfere with the workpiece causing poor control.
 2. Do not use Grinding guard for cutting off operations with bonded abrasive wheels as there is an increased risk of exposure to emitted sparks and particles as well as exposure to wheel fragments in the event of wheel bust.
 3. When using Cutting or Grinding guard for cutting/grinding operations in concrete or masonry, there is an increased risk of exposure to dust and loss of control resulting in kickback.
 4. If Segmented diamond cutting wheel is used, maximum peripheral gap between segments is 10mm and only a negative rake angle is permitted.
- Maximum grinding wheel thickness is: 6mm.
Maximum cutting wheel thickness is: 3mm.

ADDITIONAL WARNINGS FOR CUT-OFF SAWS

⚠ WARNING! This tool is not suitable for grinding or sanding – please disregard references within manual to grinding or sanding in conjunction with below:

1. Replace 'grinding/sanding wheels' with 'reinforced wheels' in clause f) of the *Safety Information for Cutting-off Machines* section of the *Safety Instructions* booklet.
2. Ignore 'grinding/sanding wheels' in clauses c) and f) of the *Safety Information for Cutting-off Machines* section of the *Safety Instructions* booklet.
3. Ignore 'grinding/sanding wheels' in clauses d), e), h) and i) of the *Safety Information for Cutting-off Machines* section of the *Safety Instructions* booklet.

Kickback and related warnings:

Kickback is a sudden reaction to a pinched or snagged rotating wheel. Pinching or snagging causes rapid stalling of the rotating wheel which in turn causes the uncontrolled power tool to be forced in the direction opposite of the wheel's rotation at the point of the binding. For example, if an abrasive wheel is snagged or pinched by the workpiece, the edge of the wheel that is entering into the pinch point can dig into the surface of the material causing the wheel to climb out or kick out. The wheel may either jump toward or away from the operator, depending on direction of the wheel's movement at the point of pinching. Abrasive wheels may also break under these conditions.

Kickback is the result of power tool misuse and/or incorrect operating procedures or conditions and can be avoided by taking proper precautions as given below.

Selecting the blade

Use only saw blades which comply with standard EN 12413 and EN 13236 and are of the same type as the saw blade supplied with the tool.

- Abrasive cutting discs are recommended to cut metal.
- Turbo diamond cutting discs are recommended to cut cement sheet.

For diamond blades used with this tool, the maximum peripheral gap between segments is 10mm, and only with a negative rake angle.



Einhell
PROFESSIONAL

WARRANTY INFORMATION

EINHELL AUSTRALIA PTY LTD – 25 Fox Drive, Dandenong South, VIC 3175 Australia provides the following warranty in relation to your Einhell Professional tool.

2 YEAR* STANDARD REPAIR WARRANTY

Includes all Einhell Professional power tools and garden tools.

**Subject to an additional 1-year extended warranty upon online registration.*

10 YEAR* BRUSHLESS MOTOR REPAIR WARRANTY

Includes all brushless motors on Einhell Professional tools.

**Subject to online registration.*

www.einhellpro.com.au/registration

3 YEAR STANDARD REPLACEMENT WARRANTY

Includes all Einhell Professional Power X-Change batteries and chargers.

Our goods come with guarantees that cannot be excluded under Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

The benefits provided under this warranty are in addition to other rights and remedies which are available to you under law. The warranty covers manufacturer defects in materials, workmanship and finish under normal use.

EINHELL PROFESSIONAL Warranty Claim Process

Equipment defects covered by the warranty will be repaired or replaced by Einhell Australia's Service Repair centre.

Contact us on

Australia – 1800 929 094

New Zealand – 0800 105 040

Or visit www.einhellpro.com.au/contactus

Or return to your nearest Bunnings Store (special orders desk) to arrange service/repair.

It is important that you have the tool's model number ready and your proof of purchase receipt.

If a fault is diagnosed and your tool is inside the stated warranty period, then your tool will be repaired or replaced at no cost. If your tool is diagnosed faulty but your tool has fallen outside the stated warranty period, the cost of diagnosis or repair will be covered by the user.

Exclusions:

The product has been modified, repaired, or serviced by someone other than an Einhell ANZ authorised service repair centre.

The product has been used other than for the purpose to which it is designed.

The product has been exposed to user abuse such as knocks, bumps and extreme temperatures or conditions, product misuse or product neglect.

Parts which are subject to wear are not covered by warranty – such as drill chucks, chainsaw chains, chainsaw bars, trimming and brush cutter heads and blades, lawn mower and hedge trimmer blades, lawn mower wheels, and accessories such as drill bits, cutting discs etc.